#### PROTECT THE ENVIORNMENT FROM E-WASTE (GUIDELINES)

Meaning of E-waste under E-waste (Management) Rules, 2022 (E-waste rules) - Waste, electrical and electronic equipment, whole or in part of reject from their manufacturing and repair process, which are intended to be discarded.

Our product is RoHS compliant.

 $\overline{\mathbf{M}}$ 

#### Don't dump, electrical and electronic products in garbage bins. DO'S & DONT'S

DO'S	
Run and maintain the air-conditioner as per the instructions given in the	~
operation/instruction manual	· ·
Ensure that an authorised person repairs your air-conditioner	$\checkmark$
	1
Call our local authorised dealer or our toll-free number to dispose your air-conditioner	
Contact an authorised dealer in case or installation or de-installation	$\checkmark$
Consult our local authorised dealer or our toll free number on the lifespan of the air-	.(
conditioner	v

DONT'S	
Do not try to repair your air conditioner on your own	×
Do not sell or dispose your air-conditioner or parts to an unauthorised Kabaadi Wala/Scrap	×
dealer/Rigpickers.	~
Do not dismantle your air-conditioner on your own.	x
Do not get your air conditioner or any parts repaired by an unauthorised person.	x
Do not dispose off the E-waste in landfills.	x
Do not use the air-conditioner as furniture after its use	x

Customer contact number: 011-4031 9300/1860-180-3900

For further information, visit us at www.daikinindia.com



# **OPERATION MANUAL**

**VRV** System Air Conditioner

RXMQ6ARV16 RXMQ8ARY16 Thank you for purchasing this Daikin air conditioner. Carefully read this operation manual before using the air conditioner. It will tell you how to use the unit properly and help you if any trouble occurs. After reading the manual, keep it in your custody for future reference.

See also the operation manual included with the indoor unit for details on the indoor unit.

Store the operation manual included with the indoor unit together with this operation manual in a safe place.

# **Operation manual**

Co	nte	nts	Page	
1.	Defi	nitions		
	1.1	Meaning of warnings and symbols	1	
	1.2	Meaning of used terms	1	
	1.3	Safety Precautions	2	
2.	Intro	oduction	6	
	2.1	General information		
	2.2	Svstem lavout	6	
3.	Bef	ore operation		
۵. ۵		r interface	7	
т. Б	030	ration range		
о. О	Ope		/	
6.	Ope	eration procedure		
	0.1	cooling, fan only, automatic operation	7	
	60	Brogram dry operation		
	6.2	Adjusting the air flow direction	Ο Ω	
	6.0	Setting the master user interface	o	
	6.5	Precautions for group control system of		
	0.0	two user interface control system	10	
7	Eno	ray saving and optimum operation	10	
/. 0	Mai	ngy saving and optimum operation		
ο.	0 1	Meintenance		
	0.1	(o g at the beginning of the season)		
	82	Maintenance before a long stop period		
	0.2	(e.g. at the end of the season)	11	
٥	Svm	ontoms that are not air conditioner		
9.	trou		10	
	0.1	The system does not operate	12	
	9.1 Q 2	Fan operation is possible, but cooling	12	
	5.2	do not work	12	
	93	The fan strength does not correspond		
	0.0	to the setting		
	9.4	The fan direction does not correspond		
		to the setting	12	
	9.5	White mist comes out of a unit	12	
	9.6	The user interface display reads "U4"		
		or "U5" and stops, but then restarts after	ər	
		a few minutes	12	
	9.7	Noise of air conditioners	12	
	9.8	Dust comes out of the unit		
	9.9	The units can give off odours		
	9.10	) The outdoor unit fan does not spin		
	9.11	The display shows " 🛱 🖉		
	9.12	2 The compressor in the outdoor unit	10	
	0.10	The incide of an outdoor unit is warm	13	
	9.10	oven when the unit has stopped	12	
	Q 1/	Does not cool very well		
10	Troi	blochooting	12	
10	. 11 UL		1.1.1	
11	.Alle			
	11.1	Atter-sales service		
	11.2 Snortening of "maintenance cycle" and			
		replacement cycle" needs to be	4 5	
	11 3	Malfunction codes	כו בו	
	11.0			

### 1. Definitions

### 1.1 Meaning of warnings and symbols

Warnings in this manual are classified according to their severity and probability of occurrence.

#### ▲ DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

### MARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

### **NOTICE**

Indicates situations that may result in equipment or property-damage accidents only.

### **INFORMATION**

This symbol identifies useful tips or additional information. Some types of danger are represented by special symbols:

#### A Electric current.

Danger of burning and scalding.

#### 1.2 Meaning of used terms

#### Installation manual:

Instruction manual specified for a certain product or application, explaining how to install, configure and maintain it.

#### **Operation manual:**

Instruction manual specified for a certain product or application, explaining how to operate it.

#### Maintenance instructions:

Instruction manual specified for a certain product or application, which explains (if relevant) how to install, configure, operate and/or maintain the product or application.

#### **Dealer:**

Sales distributor for products as per the subject of this manual.

#### Installer:

Technical skilled person who is qualified to install products as per the subject of this manual.

#### User:

Person who is owner of the product and/or operates the product.

#### Service company:

Qualified company which can perform or coordinate the required service to the unit.

#### **Applicable legislation:**

All international, European, national and local directives, laws, regulations and/or codes which are relevant and applicable for a certain product or domain.

#### Accessories:

Equipment which is delivered with the unit and which needs to be installed according to instructions in the documentation.

#### **Optional equipment:**

Equipment which can optionally be combined to the products as per the subject of this manual.

#### **Field supply:**

Equipment which needs to be installed according to instructions in this manual, but which are not supplied by Daikin.

#### 1.3 Safety Precautions

To gain full advantage of the air conditioner's functions and to avoid malfunction due to mishandling, we recommend that you read this instruction manual carefully before use. Read the precautions thoroughly to avoid misuse of the equipment.

This air conditioner is classified under "appliances not accessible to the general public".

- The precautions described herein are classified as WARNING and CAUTION. They both contain important information regarding safety. Be sure to observe all precautions without fail.
- There are two kinds of safety precaution and tips listed in the following.

- WARNING ..... Failure to follow these instructions properly may result in personal injury or loss of life.
  - This unit contains electrical and hot parts.
  - Before operating the unit, be sure the installation has been carried out correctly by an installer. If you feel unsure about operation, contact your installer for advice and information.
- CAUTION ...... Failure to observe these instructions properly may result in property damage or personal injury, which may be serious depending on the circumstances.
- After reading, keep this manual in a convenient place so that you can refer to it whenever necessary. If the equipment is transferred to a new user, be sure also to hand over the manual.

### -/! WARNING -

· Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit. Leaves are a hotbed for small animals which can enter the unit.

Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.

 Consult your local dealer about installation work.

Doing the work yourself may result in water leakage, electric shocks or fire hazards.

- Do not insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.
- Never let the indoor unit or the user interface get wet.

It may cause an electric shock or a fire.

- Do not put user interface in risk to wet place. If water into controller, risk to electric leakage and cause to electronics parts damaged.
- · Be sure to use fuses with the correct ampere reading.

Do not use improper fuses, copper or other wires as a substitute, as this may result in electric shock, fire, injury or damage to the unit.

- Consult your local dealer regarding what to do in case of refrigerant leakage. When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of leakage. Otherwise, this may lead to an accident due to oxygen depletion.
- Beware of fire in case of refrigerant leakage. If the air conditioner is not operating correctly, i.e. not generating cool air, refrigerant leakage could be the cause.

Consult your dealer for assistance. The refrigerant within the air conditioner is safe and normally does not leak. However, in the event of a leakage, contact with a naked burner, heater or cooker may result in generation of noxious gas. Do not longer use air conditioner until a qualified service person confirms that the leakage has been repaired.

- Do not use the air conditioner until a service person confirms that the portion where the refrigerant leaks is repaired.
- Turn off any combustible heating devices, ventilate the room and contact the dealer where you purchased the unit.
- Improper installation or attachment of equipment or accessories could result in electric shock, short circuit, leaks, fire or other damage to the equipment.
- Consult your local dealer regarding modification, repair and maintenance of the air conditioner.
   Improper workmanship may result in water

leakage, electric shocks or fire hazards.

 Consult your local dealer regarding relocation and reinstallation of the air conditioner.

Improper installation work may result in leakage, electric shocks or fire hazards.

 Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.
 Otherwise, an electric shock and injury may

result.

• Do not operate the air conditioner with wet hands.

An electric shock may result.

• Do not wash the air conditioner with water, as this may result in electric shocks or fire.

- Be sure to install an earth leakage breaker. Failure to install an earth leakage breaker may result in electric shocks or fire. In order to avoid electric shock or fire, make sure that an earth leak detector is installed.
- Consult the dealer if the air conditioner submerges owing to a natural disaster, such as a flood or typhoon.

Do not operate the air conditioner in that case, or otherwise a malfunction, electric shock, or fire may result.

 Do not start or stop operating the air conditioner with the power supply breaker turned ON or OFF.

Otherwise, fire or water leakage may result. Furthermore, the fan will rotate abruptly if power failure compensation is enabled, which may result in injury.

- Do not use the product in the atmosphere contaminated with oil vapour, such as cooking oil or machine oil vapour. Oil vapour may cause crack damage, electric shocks, or fire.
- Do not install the air conditioner at any place where there is a danger of flammable gas leakage.

In the event of a gas leakage, build-up of gas near the air conditioner may result in fire hazards.

 Contact professional personnel about attachment of accessories and be sure to use only accessories specified by the manufacturer.

If a defect results from your own workmanship, it may result in water leaks, electric shock or fire.

• Do not use the product in places with excessive oily smoke, such as cooking room, or in places with flammable gas, corrosive gas, or metal dust.

Using the product in such places may cause fire or product failures.

- When the air conditioner is malfunctioning (giving off a burning odour, etc.) turn off power to the unit and contact your local dealer. Continued operation under such circumstances may result in a failure, electric shocks or fire hazards.
- Do not place flammable sprays or operate spray containers near the unit as this may result in fire.
- Do not clean the product with organic solvents such as paint thinner. The use of organic solvents may cause crack damage to the product, electric shocks, or fire.

• Be sure to use a dedicated power supply for the air conditioner.

The use of any other power supply may cause heat generation, fire, or product failures.

- Consult your dealer regarding cleaning the inside of the air conditioner. Improper cleaning may cause breakage of plastic parts, water leakage and other damage as well as electric shocks.
- Be sure the air conditioner is electrically earthed.

In order to avoid electric shock, make sure that the unit is grounded and that the earth wire is not connected to gas or water pipe, lightning conductor or telephone earth wire.

- Do not place a flower vase or anything containing water on the unit. Water may enter the unit, causing an electric shock or fire.
- Avoid placing the controller in a spot which can be splashed with water. Water entering the machine may cause an electric leak or may damage the internal electronic parts.
- Be aware that prolonged, direct exposure to cool air from the air conditioner, or to air that is too cool can be harmful to your physical condition and health.

### 

- **Do not remove the outdoor unit's fan guard.** The guard protects against the unit's high speed fan, which may cause injury.
- Do not place objects that are susceptible to moisture directly beneath the indoor or outdoor units.

Under certain conditions, condensation on the main unit or refrigerant pipes, air filter dirt or drain blockage may cause dripping, resulting in fouling or failure of the object concerned.

- To avoid oxygen depletion, ensure that the room is adequately ventilated if equipment such as a burner is used together with the air conditioner.
- Do not place flammable sprays near the unit as this can cause explosions.
- Do not place appliances that produce naked flames in places exposed to the air flow from the unit as this may impair combustion of the burner.
- Do not place burners or heaters in places exposed to the air flow from the unit as this may impair combustion of the burner or heater.

- Do not place heaters directly below the unit, as resulting heat can cause deformation.
- Do not allow a child to mount on the outdoor unit or avoid placing any object on it. Falling or tumbling may result in injury.
- Do not block air inlets or outlets. Impaired air flow may result in insufficient performance or trouble.
- Arrange the drain hose to ensure smooth drainage.

Imperfect drainage may cause wetting of the building, furniture etc.

- Be sure that children, plants or animals are not exposed directly to airflow from the unit, as adverse effects may ensue.
- Arrange the drain hose to ensure smooth drainage. Imperfect drainage may cause wetting.
- Do not wash air conditioner or user interface, causing an electric shock or fire.
- Do not put flammable containers, such as spray cans, within 1 m from the blow-off mouth.

The containers may explode because the warm air output of the outdoor unit will affect them.

• Arrange the drain to ensure complete drainage.

If proper drainage from the outdoor drain pipe does not occur during air conditioner operation, there could be a blockage due to dirt and debris build-up in the pipe.

This may result in a water leakage from the indoor unit. Under these circumstances, stop air conditioner operation and consult your dealer for assistance.

- The appliance is not intended for use by unattended young children or infirm persons. Impairment of bodily functions and harm to health may result.
- Children should be supervised to ensure that they do not play with the unit or its user interface.

Accidental operation by a child may result in impairment of bodily functions and harm health.

• To avoid injury, do not touch the air inlet or aluminium fins of the unit. These fins are sharp and could result in cutting injuries. • Never touch the internal parts of the controller.

Do not remove the front panel. Touching certain internal parts will cause electric shocks and damage to the unit. Please consult your dealer about checking and adjustment of internal parts.

• Do not leave user interface wherever there is a risk of wetting.

If water gets into the remote controller there is a risk of electrical leakage and damage to electronic components.

• Turn off the main power switch when the air conditioner is not to be used for prolonged periods.

When the main power switch is left on, some electric power (watts) is still consumed even if the air conditioner is not operating. Therefore, switch off the main power switch to save energy. When resuming operation, to ensure smooth running, turn on the main power switch 6 hours before operating the air conditioner again.

• Watch your steps at the time of air filter cleaning or inspection.

High-place work is required, to which utmost attention must be paid.

If the scaffold is unstable, you may fall or topple down, thus causing injury.

- Take care of scaffolding and exercise caution when working high above ground level.
- Do not operate with the control panel lid open.

If water gets inside the panel, it may result in equipment failure or electric shock.

• Do not sit or place objects on the outdoor unit.

Falling yourself or objects could cause injury.

• Do not let children play on or around the outdoor unit.

If they touch the unit carelessly, injury may be caused.

• Never operate user interface buttons with hard, pointed objects.

This may result in remote controller damage.

- **Do not pull or twist user interface cord.** This may cause malfunctioning.
- Do not use the air conditioner for purposes other than those for which it is intended. Do not use the air conditioner for cooling precision instruments, food, plants, animals or works of art as this may adversely affect the performance, quality and/or longevity of the object concerned.

- After prolonged use, check the unit stand and its mounts for damage. If left in a damaged condition, the unit may fall and cause injury.
- Do not place items which might be damaged by moisture under the indoor unit. Condensation may form if the humidity is above 80%, if the drain outlet is blocked or the filter is polluted.
- Ensure that user interface is not exposed to direct sunlight.

This will cause discoloration of the LCD display with resulting loss of readability.

- Do not wipe the controller panel with benzene or other organic solvent. This will cause discoloration and/or peeling. If the panel needs cleaning, use a damp cloth with some water-diluted neutral detergent. Wipe with a dry cloth afterwards.
- Do not operate the air conditioner when using a room fumigation type insecticide. Fumigation chemicals deposited in the unit could endanger the health of those who are hypersensitive to touch chemicals.

### **Installation Site**

#### **Regarding places for installation**

- Install the air conditioner in a well-ventilated place that is free of obstructions.
- Do not use the air conditioner in the following kinds of places:
  - a. Where there is considerable use of mineral oil such as cutting oil.
  - b. Where there is much salt such as a beach area.
  - c. Where there is sulphur gas such as in a hot spring resort.
  - d. Where there are considerable voltage fluctuations such as a factory.
  - e. Where there are motor vehicles or marine vessels.
  - f. Where there is considerable atmospheric oil such as in cooking areas.
  - g. Where there are machines generating electromagnetic radiation.
  - h. Where the air contains acidic or alkaline steam or a vapour.

#### Wiring

• All wiring must be performed by an authorized electrician.

Always consult your dealer about wiring. Never do it by yourself.

• Only use the dedicated power supply circuit provided for this air conditioner.

#### Also pay attention to operating noise.

- Select the following kinds of location:
  - a. A place that can sufficiently withstand the weight of the air conditioner with less running noises and vibrations.
  - b. A place where warm airflow from the air outlet of the outdoor unit and operating noise do not cause a nuisance to neighbours.
- Be sure there are no obstructions near the air outlet of the outdoor unit.
- Obstructions may result in poor performance and increased operating noise. If abnormal noise occur, ask your dealer for advise.
- Make sure that the piping is heat insulated. If the piping is frozen and broken, scalding or water leakage may result. Consult your installer.
- System relocation
- Consult your Daikin about remodelling and relocation.

### 2. Introduction

#### 2.1 General information

The indoor unit part of VRV cooling system can be used for cooling applications. The type of indoor unit which can be used depends on the outdoor units series.

### NOTICE

For future modifications or expansions of your system:

A full overview of allowable combinations (for future system extensions) is available in technical engineering data and should be consulted. Contact your installer to receive more information and professional advice.

In general following type of indoor units can be connected to a VRV cooling system (not exhaustive list, depending on outdoor unit model and indoor unit model combinations):

• VRV direct expansion indoor units (air to air applications).

Combination of VRV direct expansion indoor units is allowed.

For more specifications, see technical engineering data.

#### 2.2 System layout

Your VRV series outdoor unit can be one of following models:

RXMQ: Single continuous cooling model. Depending on the type of outdoor unit which is chosen, some functionality will or will not exist. It will be indicated throughout this operation manual when certain features have exclusive model rights or not.



- 1 VRV outdoor unit
- 2 Refrigerant piping
- 3 VRV direct expansion indoor unit
- 4 User interface (dedicated depending on indoor unit type)
- **5** User interface (wireless, dedicated depending on indoor unit type)

### 3. Before operation

This operation manual is for the following systems with standard control. Before initiating operation, contact your dealer for the operation that corresponds to your system type and mark. If your installation has a customized control system, ask your dealer for the operation that corresponds to your system.

Operation modes (depending on indoor unit type):

- " 🔆 " Cooling (air to air).
- " 🔁 " Fan only operation (air to air).
- " I Dry operation.
- " 🖽 " Automatic operation.

Dedicated functions exist depending on the type of indoor unit, refer to dedicated installation/operation manual for more information.

### 4. User interface

This operation manual will give a non-exhaustive overview of the main functions of the system.

Detailed information on required actions to achieve certain functions can be found in the dedicated installation and operation manual of the indoor unit.

Refer to the operation manual of the installed user interface.

## 5. Operation range

Use the system in the following temperature and humidity ranges for safe and effective operation.

	*
Outdoor temperature	0~52°C DB
Indoor temperature	21~32°C DB 14~25°C WB
Indoor humidity	≤80% <sup>(a)</sup>

(a) To avoid condensation and water dripping out of the unit. If the temperature or the humidity is beyond these conditions, safety devices may be put in action and the air conditioner may not operate.

Above operation range is only valid in case direct expansion indoor units are connected to the VRV system.

### 6. Operation procedure

- Operation procedure varies according to the combination of outdoor unit and user interface. Read the chapter "**3. Before operation**".
- To protect the unit, turn on the main power switch 6 hours before operation. And do not turn off the power supply during the air conditioning season because of smoothly start up.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

# 6.1 Cooling, fan only, automatic operation and dry operation

- The operation mode cannot be changed with the remote controller whose display shows
   " The image is a structure of the operation mode with user interface whose display does not show " The image is a structure of the operation is
- When the display " 🗈 " (changeover under centralized control) flashes, refer to "6.4 Setting the master user interface".
- The air flow rate may adjust itself depending on the room temperature or the fan may stop immediately. This is not a malfunction.

#### Starting the system

#### BRC1C62

#### BRC1E62



- Press the operation mode selector button several times and select the operation mode of your choice.
  - " 🔆 " Cooling operation
  - " 🗞 " Fan only operation
  - " Dry operation
  - " 🖽 " Automatic operation.
- Press the ON/OFF button.

The operation lamp lights up and the system starts operation.

#### ADJUSTMENT

For adjustment the desired temperature, fan speed and air flow direction (only for the remote controller, follow the procedure shown below).

Press the temperature setting button.

#### For BRC1C62



Each time this button is pressed, the

temperature setting rises or lowers 1°C.

#### For BRC1E62



Each time this button is pressed, the temperature setting rises or lowers 1°C.

#### NOTE -

- Set the temperature within the operation range.
- The temperature setting is impossible for fan only operation.

#### For BRC1C62

- Press the fan speed control button and select the fan speed of your preference.
- Press air flow direction adjust button. Refer to the chapter "6.3 Adjusting the air flow direction" for details.

#### For BRC1E62

Press air flow setting button.



To select air volume or direction setting, press " ◀▶ " buttons.

•

With air volume selected, using the " $\checkmark \blacktriangle$ " buttons.

With direction selected, using the "▼▲" buttons.

#### Stopping the system

- Press the ON/OFF button once again. The operation lamp goes off and the system stops operation.

### NOTICE

- Do not turn off the power immediately after the unit stops, but wait for at least 5 minutes.
- The system need at least 5 minutes for residual operation of drain pump device. Turning off the power immediately will cause water leak or trouble.

#### 6.2 Program dry operation

- The function of this program is to decrease the humidity in your room with minimal temperature decrease (minimal room cooling).
- The microcomputer automatically determines temperature and fan speed (cannot be set by the user interface).
- The system does not go into operation if the room temperature is low (<20°C).</li>

#### Starting the system

BRC1C62

#### BRC1E62





- Press the operation mode selector button several times and select " I " (program dry operation).
- Press the ON/OFF button of the user interface. The operation lamp lights up and the system starts operating.
- Press the air flow direction adjust button (only for double-flow, multi-flow, corner, ceiling-suspended and wall-mounted).
   Refer to "6.3 Adjusting the air flow direction".

#### Stopping the system

Press the ON/OFF button of the user interface once again. The operation lamp goes off and the system stops operating.



#### NOTICE

Do not turn off power immediately after the unit stops, but wait for at least 5 minutes.

#### 6.3 Adjusting the air flow direction

#### For BRC1C62



Press the air flow direction button to select the air direction.

The air flow flap display swings as shown right and the air flow direction continuously varies. (Automatic swing setting)



Press the air flow direction adjust button to select the air direction of your choice.

> The air flow flap display stops swinging and the air flow direction is fixed. (Fixed air flow direction setting)



8

#### For BRC1E62



Press air flow setting button



- To select air volume or direction setting, press " ◀ ► " buttons.
- With direction selected, using the "▼▲" buttons.

#### Movement of the air flow flap



Double-flow+multi-flow units

Corner units



Ceiling-suspended units



Wall-mounted units

For the following conditions, a microcomputer controls the air flow direction which may be different from the display.

#### COOLING

- When the room temperature is lower than the set temperature.
- When operating continuously at horizontal air flow direction.
- When continuous operation with downward air flow is performed at the time of cooling with a ceiling-suspended or a wall-mounted unit, the microcomputer may control the flow direction, and then
- the user interface indication will also change.

The air flow direction can be adjusted in one of the following ways:

- The air flow flap itself adjusts its position.
- The air flow direction can be fixed by the user. Automatic " √" or desired position " ✓".



mounted).

#### • The movable limit of the flap is changeable. Contact your dealer for details. (only for double-flow, multi-flow, corner, ceiling-suspended and wall-

 Avoid operating in the horizontal direction
 "...-"". It may cause dew or dust to settle on the ceiling or flap.

#### 6.4 Setting the master user interface



- 1 VRV outdoor unit VRV direct expansion
- 2 indoor unit
- **3** User interface (dedicated depending on indoor unit type)
- **4** User interface (wireless, dedicated depending on indoor unit type)

When the system is installed as shown in the figure above, it is necessary to designate one of the user interfaces as the master user interface.

The displays of slave user interfaces show " **L** " (changeover under centralized control) and slave user interfaces automatically follow the operation mode directed by the master user interface.

Only the master user interface can select cooling or fan only mode.

#### How to designate the master user interface

## BRC1C62

#### **BRC1E62**

۲

لہ

5

**t** 



# In case only VRV indoor units are connected to the VRV system:

Press the operation mode selector button of the controller that you wish to designate as the master user interface. Then designation is completed.

This user interface is designated as the master user interface and the display showing " SA" (changeover under centralized control) vanishes. The displays of other user interfaces show " SA" (changeover under centralized control).

#### 6.5 Precautions for group control system or two user interface control system

This system provides two other control systems beside individual control system (one user interface controls one indoor unit). Confirm the following if your unit is of the following control system type:

#### Group control system

One user interface controls up to 16 indoor units. All indoor units are equally set.

#### Two user interface control system

Two user interfaces control one indoor unit (in case of group control system, one group of indoor units). The unit is individually operated.

#### 

Contact your dealer in case of changing the combination or setting of group control and two user interface control systems.

#### 

For another user interfaces refer to the operation manual of the operation procedure user interface.

# 7. Energy saving and optimum operation

Observe the following precautions to ensure the system operates properly.

- Adjust the air outlet properly and avoid direct air flow to room inhabitants.
- Adjust the room temperature properly for a comfortable environment. Avoid excessive heating or cooling.
- Prevent direct sunlight from entering a room during cooling operation by using curtains or blinds.
- Ventilate often. Extended use requires special attention to ventilation.

- Keep doors and windows closed. If the doors and windows remain open, air will flow out of your room causing a decrease in the cooling effect.
- Be careful not to cool too much. To save energy, keep the temperature setting at a moderate level.
- Never place objects near the air inlet or the air outlet of the unit.
   It may cause deterioration in the effect or stop the operation.
- Turn off the main power supply switch to the unit when the unit is not used for longer periods of time. If the switch is on, it consumes electricity. Before restarting the unit, turn on the main power supply switch 6 hours before operation to ensure smooth running. (Refer to "Maintenance" in the indoor unit manual.)
- When the display shows " , The air filter), ask a qualified service person to clean the filters. (Refer to "Maintenance" in the indoor unit manual.)
- Keep the indoor unit and user interface at least 1 m away from televisions, radios, stereos, and other similar equipment. Failing to do so may cause static or distorted pictures.
- Do not place items under the indoor unit, they may be damaged by water.
- Condensation may form if the humidity is above 80% or if the drain outlet gets blocked.

Your system is equipped with advanced energy saving functionality. Depending on the priority emphasis can be put on energy saving or comfort level. Several parameters can be selected, resulting in the optimal balance between energy consumption and comfort for your particular application.

Several patterns are available and roughly explained below. Contact your installer or dealer for advice or to modify the parameters to the needs of your building.

Detailed information is given for the installer in the installation manual. He can help you to realize the best balance between energy consumption and comfort.

### 8. Maintenance

#### 

Pay attention to the fan. It is dangerous to inspect the unit while the fan is running.

Be sure to turn off the main switch and to remove the fuses from the control circuit located in the outdoor unit.

# 8.1 Maintenance after a long stop period (e.g., at the beginning of the season)

- Check and remove everything that might be blocking inlet and outlet vents of indoor units and outdoor units.
- Clean air filters and casings of indoor units.<sup>(b)</sup> Refer to the operation manual supplied with the indoor units for details on how to proceed and make sure to install for details on how to proceed and make sure to install cleaned air filters back in the same position.
- Turn on the power at least 6 hours before operating the unit in order to ensure smoother operation. As soon as the power is turned on, the user interface display appears.

(b) Contact your dealer or maintenance person to clean air filters and casings of the indoor unit. Maintenance tips and procedures for cleaning are provided in the installation/operation manuals of dedicated indoor units.

# 8.2 Maintenance before a long stop period (e.g., at the end of the season)

• Let the indoor units run in fan only operation for about half a day in order to dry the interior of the units.

# Refer to "6.1 Cooling, fan only, automatic operation and dry operation".

- Turn off the power. The user interface display disappears.
- Clean air filters and casings of indoor units. Refer to the operation manual supplied with the indoor units for details on how to proceed and make sure to install cleaned air filters back in the same position.

# 9. Symptoms that are not air conditioner troubles

Following symptoms are not air conditioner troubles:

#### 9.1 The system does not operate

- The air conditioner does not start immediately after the ON/OFF button on the user interface is pressed. If the operation lamp lights, the system is in normal condition. To prevent overloading of the compressor motor, the air conditioner starts 5 minutes after it is turned ON again in case it was turned OFF just before. The same starting delay occurs after the operation mode selector button was used.
- If "Under Centralized Control" is displayed on the user interface and pressing the operation button causes the display to blink for a few seconds indicating that the central device is controlling the unit. The blinking display indicates that the user interface cannot be used.
- The system does not start immediately after the power supply is turned on. Wait one minute until the microcomputer is prepared for operation.

# 9.2 Fan operation is possible, but cooling do not work

• Immediately after the power is turned on. The microcomputer is getting ready to operate and is performing a communication check with all indoor units. Please wait 12 minutes (max.) till this process is finished.

# 9.3 The fan strength does not correspond to the setting

• The fan speed does not change even if the fan speed adjustment button is pressed. This is to prevent cold air blowing directly on occupants of the room.

# 9.4 The fan direction does not correspond to the setting

• The fan direction does not correspond with the user interface display. The fan direction does not swing. This is because the unit is being controlled by the microcomputer.

#### 9.5 White mist comes out of a unit

- When humidity is high during cooling operation If the interior of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the interior of the indoor unit. Ask your dealer for details on cleaning the unit. This operation requires a gualified service person.
- Immediately after the cooling operation stops and if the room temperature and humidity are low. This is because warm refrigerant gas flows back into the indoor unit and generates steam.

# 9.6 The user interface display reads "U4" or "U5" and stops, but then restarts after a few minutes

• This is because the user interface is intercepting noise from electric appliances other than the air conditioner. The noise prevents communication between the units, causing them to stop. Operation automatically restarts when the noise ceases.

#### 9.7 Noise of air conditioners

- 1 Indoor unit
  - A "zeen" sound is heard immediately after the power supply is turned on. The electronic expansion valve inside an indoor unit starts working and makes the noise. Its volume will reduce in about one minute.
  - A continuous low "shah" sound is heard when the system is in cooling operation or at a stop.

When the drain pump (optional accessories) is in operation, this noise is heard.

- A low "sah", "choro-choro" sound is heard while the indoor unit is stopped. When the other indoor unit is in operation, this noise is heard. In order to prevent oil and refrigerant from remaining in the system, a small amount of refrigerant is kept flowing.
- 2 Indoor unit, outdoor unit
  - A continuous low hissing sound is heard when the system is in cooling operation. This is the sound of refrigerant gas flowing through both indoor and outdoor units.
  - A hissing sound which is heard at the start or immediately after stopping operation. This is the noise of refrigerant caused by flow stop or flow change.

- 3 Outdoor unit
  - When the tone of operating noise changes. This noise is caused by the change of frequency.
  - Treble clef without operation. This noise from compressor pre-heat operation to prevent compressor damage when start operation.

#### 9.8 Dust comes out of the unit

• When the unit is used for the first time in a long time.

This is because dust has gotten into the unit.

#### 9.9 The units can give off odours

• The unit can absorb the smell of rooms, furniture, cigarettes, etc., and then emit it again.

#### 9.10 The outdoor unit fan does not spin

• The speed of the fan is controlled in order to optimise product operation.

#### 9.11 The display shows "

• This is the case immediately after the main power supply switch is turned on and means that the user interface is in normal condition. This continues for one minute.

# 9.12 The compressor in the outdoor unit does not stop

• This is to prevent oil and refrigerant from remaining in the compressor. The unit will stop after 5 to 10 minutes.

# 9.13 The inside of an outdoor unit is warm even when the unit has stopped

• This is because the pre-heat operation is warming the compressor crankcase so that the compressor can start smoothly.

#### 9.14 Does not cool very well

• Program dry operation. Program dry operation is designed to lower the room temperature as little as possible refer to "6.2 Program dry operation".

## 10. Troubleshooting

If one of the following malfunctions occur, take the measures shown below and contact your dealer.

#### MARNING

Stop operation and shut off the power if anything unusual occurs (burning smells etc.). Leaving the unit running under such circumstances may cause breakage, electric shock or fire. Contact your dealer.

The system must be repaired by a qualified service person:

- If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates or the ON/OFF switch does not properly work. Measure: Turn off the main power switch.
- If water leaks from the unit. Measure: Stop the operation.
- The operation switch does not work well. Measure: Turn off the power.
- If the user interface display " TEST " indicates the unit number, the operation lamp flashes and the malfunction code appears. Measure: Notify your installer and report the malfunction code.

If the system does not properly operate except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system according to the following procedures. If it is impossible to fix the problem yourself after checking all the above items, contact your dealer. Let him know the symptoms, system name, and model name (listed on the warranty card).

- 1 If the system does not operate at all:
  - Check if there is no power failure. Wait unit power is restored. If power failure occurs during operation, the system automatically restarts immediately after the power supply is recovered.
  - Check if no fuse has blown or breaker has worked. Change the fuse or reset the breaker if necessary.

Turn the power on with the breaker switch in the off position. Do not turn the power on with the breaker switch in the trip position. (Contact your dealer.)



- 2 If the system goes into fan only operation, but as soon as it goes into cooling operation, the system stops:
  - Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles. Remove any obstacle and make it well-ventilated. Check if the user interface display shows " (a) and a clean the operation manual of the indoor unit and clean the air filter".
- 3 The system operates but cooling is insufficient:
  - Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles.
  - Remove any obstacle and make it wellventilated.
  - Check if the air filter is not clogged (refer to "Maintenance" in the indoor unit manual).
  - Check the temperature setting.
  - Check the fan speed setting on your user interface.
  - Check for open doors or windows. Shut doors and windows to prevent wind from coming in.
  - Check if there are too many occupants in the room during cooling operation. Check if the heat source of the room is excessive.
  - Check if direct sunlight enters the room. Use curtains or blinds.
  - Check if the air flow angle is proper.

If the checking all above items, it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the air conditioner (with manufacturing number if possible) and the installation date (possibly listed on the warranty card).

### 11. After-sales service

#### 11.1 After-sales service

# 11.1.1 Recommendations for maintenance and inspection

Since dust collects when using the unit for several years, performance of the unit will deteriorate to some extent. As taking apart and cleaning interiors of units requires technical expertise and in order to ensure the best possible maintenance of your units, we recommend to enter into a maintenance and inspection contract on top of normal maintenance activities. Our network of dealers has access to a permanent stock of essential components in order to keep your air conditioner in operation as long as possible. Contact your dealer for more information.

# When asking your dealer for an intervention, always state:

- The complete model name of the air conditioner.
- The manufacturing number (stated on the nameplate of the unit).
- The installation date.
- The symptoms or malfunction, and details of the defect.

#### 🕂 WARNING

- Do not modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electric shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and non-combustible, but it will generate toxic gas when it accidentally leaks into a room where combustible air from fan heaters, gas cookers, etc. is present. Always have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.
- Do not remove or reinstall the unit by yourself. Incorrect installation may cause electrical shock or fire. Contact your dealer.

# 11.1.2 Recommended inspection and maintenance cycles

Be aware that the mentioned maintenance and replacement cycles do not relate to the warranty period of the components.

Table 1 assumes the following conditions of use:

- Normal use without frequent starting and stopping of the unit.
   Depending on the model, we recommend not starting and stopping the machine more than 6 times/hour.
- Operation of the unit is assumed to be 10 hours/ day and 2,500 hours/year.

Table 1*: "Inspection	Cycle"	and	"Maintenai	nce
Cycle" list				

Component	Inspection cycle	Maintenance cycle (replacements and/or repairs)
Electric motor (fan, damper, etc.)		20,000 hours
PCB boards		25,000 hours
Heat exchanger		5 years
Sensor (thermistor, etc.)	1 year	5 years
User interface and switches		25,000 hours
Drain pan		8 years
Expansion valve		20,000 hours
Electromagnetic valve		20,000 hours

\*Actual inspection and maintenance cycle also depends on installation site

#### 

- Table 1 indicates main components. Refer to your maintenance and inspection contract for more details.
- Table 1 indicates recommended intervals of maintenance cycles. However, in order to keep the unit operational as long as possible, maintenance work may be required sooner. Recommended intervals can be used for appropriate maintenance design in terms of budgeting maintenance and inspection fees. Depending on the content of the maintenance and inspection contract, inspection and maintenance cycles may in reality be shorter than listed.

#### 11.2 Shortening of "maintenance cycle" and "replacement cycle" needs to be considered in following situations

#### The unit is used in locations where:

- Heat and humidity fluctuate out of the ordinary.
- Power fluctuation is high (voltage, frequency, wave distortion, etc.) (the unit cannot be used if power fluctuation is outside the allowable range).
- Bumps and vibrations are frequent.
- Dust, salt, harmful gas or oil mist such as sulphurous acid and hydrogen sulphide may be present in the air.
- The machine is started and stopped frequently or operation time is long (sites with 24 hour air conditioning).

Recommended replacement cycle of wear parts Table 2\*: "Replacement Cycle" list

Component	Inspection cycle	Maintenance cycle (replacements and/or repairs)
Air filter		5 years
High efficiency filter (Optional accessory)	1 year	1 year
Fuse		10 years

\*Actual maintenance cycle also depends on installation site



#### NOTICE

- Table 2: "Replacement Cycle" list indicates main components. Refer to your maintenance and inspection contract for more details.
- Table 2: "Replacement Cycle" list indicates recommended intervals of replacement cycles. However, in order to keep the unit operational as long as possible maintenance work may be required sooner.

Recommended intervals can be used for appropriate maintenance design in terms of budgeting maintenance and inspection fees. Contact your dealer for details.

#### **INFORMATION**

Damage due to taking apart or cleaning interiors of units by anyone other than our authorized dealers may not be included in the warranty.

#### Moving and discarding the unit

- Contact your dealer for removing and reinstalling the total unit. Moving units requires technical expertise.
- This unit uses hydrofluorocarbon. Contact your dealer when discarding this unit. It is required by law to collect, transport and discard the refrigerant in accordance with the "hydrofluorocarbon collection and destruction" regulations.

#### 11.3 Malfunction codes

In case a malfunction code appears on the indoor unit user interface display, contact your installer and inform the malfunction code, the unit type, and serial number (you can find this information on the nameplate of the unit).

For your reference, a list with malfunction codes is provided. You can, depending on the level of the malfunction code, reset the code by pushing the ON/OFF button. If not, ask your installer for advice.

Malfunction code	Contonto	
Main code	Contents	
80	External protection device was activated	
R	EEPROM failure (indoor)	
RB	Drain system malfunction (indoor)	
86	Fan motor malfunction (indoor)	
87	Swing flap motor malfunction (indoor)	
89	Expansion valve malfunction (indoor)	
RF	Drain malfunction (indoor unit)	
RH	Filter dust chamber malfunction (indoor)	
RJ	Capacity setting malfunction (indoor)	
C I	Transmission malfunction between main PCB and sub PCB (indoor)	
СЧ	Heat exchanger thermistor malfunction (indoor; liquid)	
C5	Heat exchanger thermistor malfunction (indoor; gas)	
C9	Suction air thermistor malfunction (indoor)	
ER	Discharge air thermistor malfunction (indoor)	
CE	Movement detector or floor temperature sensor malfunction (indoor)	
EJ	User interface thermistor malfunction (indoor)	
El	PCB malfunction (outdoor)	
E3	High pressure switch was activated	
ЕЧ	Low pressure malfunction (outdoor)	
E5	Compressor lock detection (outdoor)	
E5	Compressor damage alarm	
EN	Fan motor malfunction (outdoor)	
E9	Electronic expansion valve malfunction (outdoor)	
FB	Discharge temperature or overload protector was activated (outdoor)	
FЧ	Abnormal suction temperature (outdoor)	
F6	Refrigerant overcharge detection	
НЗ	High pressure switch was activated	
HS	Overload protector malfunction	
НП	Fan motor trouble (outdoor)	
HS	Ambient temperature sensor malfunction (outdoor)	
J I	Pressure sensor malfunction	
ΕL	Discharge temperature sensor malfunction (outdoor)	
J5	Suction temperature sensor malfunction (outdoor)	
רר	Liquid temperature sensor (after subcool HE) malfunction (outdoor)	
J8	Liquid temperature sensor (coil) malfunction (outdoor)	
JS	Gas temperature sensor (after subcool HE) malfunction (outdoor)	

Malfunction code	Contents
Main code	
JR	High pressure sensor malfunction (S1NPH)
JE	Low pressure sensor malfunction (S1NPL)
LI	INV circuit abnormal
LH	Fin temperature abnormal
L5	INV circuit faulty
L8	Compressor over current detected
19	INV compressor startup abnormal
LE	INV circuit transmission trouble
PI	INV unbalanced power supply voltage
P2	Autocharge operation related
РЧ	Fin thermistor malfunction
P8	Autocharge operation related
P9	Autocharge operation related
PJ	Capacity setting malfunction (outdoor)
LID	Refrigerant shortage warning
U2	INV voltage power shortage
UЭ	System test run not yet executed
UH	Faulty wiring indoor/outdoor
US	Abnormal user interface - indoor communication
U8	Abnormal main-sub user interface communication
US	System mismatch. Wrong type of indoor units combined. Indoor unit malfunction.
UR	Connection malfunction over indoor units or type mismatch
UE	Centralized address duplication
UE	Malfunction in communication centralized control device - indoor unit
ШF	Auto address malfunction (inconsistency)
ШH	Auto address malfunction (inconsistency)

### DAIKIN AIRCONDITIONING INDIA PVT. LTD.

12th Floor, Building No. 9, Tower A, DLF Cyber City, DLF Phase - III Gurgaon - 122002, Haryana (India) Tel: +91-0124-4555444 Fax: +91-0124-4555333



ļ



1



## 2P633133-1

**Installation Manual (2)** Be sure to read this manual before installation

and follow the instructions contained in it

### Installation location

#### <Precautions to side-by-side installation>

• In the figure below, the connection piping is lead out from the front, the bottom, or the side.

An interspace of over 100mm should be kept when installing side-by-side. To lead out the piping from the back, the interspace of over 250mm should be kept on the right side of the outdoor unit. (unit : mm)

#### (A) Where there is an obstacle on the suction side: No obstacle above

#### **①** Stand-alone installation







- 2 Series installation (2 or more) Obstacle on both sides
- Obstacle above,too
  - **(1)** Stand-alone installation
    - Obstacle on the suction side.too



1000 or

- 2 Series installation (2 or more) • Obstacle on the suction side and both sides
- (B) Where there is an obstacle on the discharge side:
  - No obstacle above
  - **(1)** Stand-alone installation



 Obstacle above,too 1 Stand-alone installation





Pattern 1Where the obstacles on the discharge side is higher than the unit:<br/>(There is no height limit for obstructions on the intake side.)

#### No obstacle above

- ① Stand-alone installation
- ② Series installation (2 or more)

L>H



## Obstacle above.too

**①** Stand-alone installation

The relations between H, A and L are as follows:

		1	Δ
		L	
L≤H	124	0 <l≤1 2h<="" td=""><td>750</td></l≤1>	750
		1/2H <l≤h< td=""><td>1000</td></l≤h<>	1000
H <i <h<="" as:="" i="" set="" stand="" td="" the=""><td>d as: I <h< td=""></h<></td></i>		d as: I <h< td=""></h<>	

(Note) Close the bottom of the installation frame to prevent the discharged air from being bypassed.

### 2 Series installation (2 or more)

The relations between H, A and L are as follows:		
L A		
L≤H	0 <l≤1 2h<="" td=""><td>1000</td></l≤1>	1000
	1/20/20	1250



H<I Set the stand as: L≤H. (Note1) Close the bottom of the installation frame to prevent the discharged air from being bypassed. (Note2) Only two units can be installed for this series.





Pattern 2 (There is no height limit for obstructions on the intake side.)

#### No obstacle above

(1) Stand-alone installation

L≤H

**2** Series installation (2 or more) The relations between H, A and L are as follows:

L	А
0 <l≤1 2h<="" th=""><th>250</th></l≤1>	250
1/2H <l≤h< th=""><th>300</th></l≤h<>	300

### Obstacle above,too

#### (1) Stand-alone installation

The relations between H, A and L are as follows:

$\square$	L	А	
L≤H	0 <l≤1 2h<="" td=""><td>100</td></l≤1>	100	
	1/2H <l≤h< td=""><td colspan="3">≤H 200</td></l≤h<>	≤H 200	
H <l< td=""><td colspan="3">Set the stand as: L≤H.</td></l<>	Set the stand as: L≤H.		

(Note) Close the bottom of the installation frame to prevent the discharged air from being bypassed.

#### ② Series installation (2 or more)

The relations between H, A and L are as follows:









150 or more



2 Series installation (2 or more)



2 Series installation (2 or more)



- Obstacle on the suction side and both sides



#### (D) Double-decker installation

#### (1) Obstacle on the discharge side

(Note 1) Up to 2 layers can be overlapped. (Note 2) For the drain pipe installation of the upper outdoor unit, the interspace of 100mm around is needed. (Note 3) Seal Z part (interspace between the upper and lower outdoor units) to prevent the exhaust bypass from being formed.

#### **(2)** Obstacle on the suction side

(Note 1) Up to 2 layers can be overlapped. (Note 2) For the drain pipe installation of the upper outdoor unit, the interspace of 100mm around is needed. (Note 3) Seal Z part (interspace between the upper and lower outdoor units) to prevent the exhaust bypass from being formed.

(Note1) Close the bottom of the installation frame to prevent the discharged air from being bypassed. (Note2) Only two units can be installed for this series.

- (E) Multiple rows of series installation (on the rooftop, etc.)
  - **(1)** One row of stand-alone installation
  - 2 Rows of series installation (2 or more)

The relations between H, A and L are as follows:

	L	A		
1 < 1	0 <l≤1 2h<="" td=""><td>250</td></l≤1>	250		
	1/2H <l≤h< td=""><td>300</td></l≤h<>	300		
H <l< td=""><td colspan="4">Cannot be installed.</td></l<>	Cannot be installed.			





IP642349-1 DAIKIN INSTALLATION MANUAL (1) RXMQ8ARY16 Be sure to read this manual before installation and conduct installation according to this manual.	Introduction         Combination       The indoor units can be connected in the following range.         • Be sure to install the dedicated indoor units.         Refer to the product catalogue for the model names of the indoor units which can be connected with this unit.         • Combination capacity ratio and number of the indoor units.         Outdoor unit       Combination capacity ratio (%)
<ol> <li>This series air conditioner uses R410A refrigerant. Strictly observe the precautions under the         <ul> <li>Refrigerant piping connection as there are strict requirements for how to prevent entry of impurities (mineral oils such as specialized lubricating oil and moisture) for R410A.</li> <li>Clean and dry             Strict measures must be taken to keep impurities (including SUNISO oil and other mineral oils as well as moisture) out of the system.         </li> <li>Tightly sealed             R410A contains no chlorine, does not destroy the ozone layer and so does not reduce the earth's protection against harmful ultraviolet radiation. R410A will contribute only slightly to the greenhouse effect if released into the atmosphere.         </li> <li>Since the design pressure is 4.0MPa, refer to the        Refrigerant piping connection         for selection of pipe thickness.         </li> <li>Since R410A is a mixed refrigerant, it must be charged in liquid phase. (If the refrigerant is charged in gaseous phase, its composition can change and the system may not work properly.)         </li> <li>Be sure to connect a special indoor unit for R410A. Refer to the product catalogue for the model names of the indoor units which can be connected with this unit. (If connected with other indoor units, the air conditioning system will not operate normally.)         <li>Power voltage of this series product is 3N~ 380-415V, 50Hz.</li> </li></ul> </li></ol>	RXMQ8ARY16       VRV only       50~130       13         Standard operation range       Standard operation range         The values below are the supposed working environment for the outdoor and indoor units:       Equivalent piping length7.5m         Difference in height0m       A Outdoor temperature (°CDB)         B Indoor temperature (°CWB)       B Range for continuous operation         Range for pull down operation
Please read the these "SAFETY PRECAUTIONS" carefully before installing air conditioning unit and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation.         Please instruct the customer on how to operate the unit and keep it maintained.         The precautions described herein are classified as WARNING and CAUTION, following which is the important safety information, it is strongly recommended to observe.         This air conditioner comes under the term "appliances not accessible to the general public".         Meaning of WARNING and CAUTION notices.         Martine and the proper handling may result in major accidents such as death and serious injury.         Martine and information, perform a test run to check for normal operation and explain to the customer how to operate and maintain the air conditioner.         After completing installation, perform a test run to check for normal operation and explain to the customer how to operate and maintain the air conditioner.         In addition, ask the customer to keep this installation manual together with the operation manual for future reference.         Also, inform customers that they should store this installation manual along with the operation manual for future reference.	Image: Normal System       Image: Normal System <td< th=""></td<>
Ask the dealer or specialized personnel to carry out the installation work. Do not install the machine by yourself. Otherwise, it may result in water leakage, electric shocks or fire hazards. Perform installation work following the instructions contained in this manual. Improper installation may result in water leakage, electric shocks or fire hazards. When installing the units in a small room, take proper measures to ensure the amount of any leaked refrigerant under the concentration limit in the event of refrigerant leakage. Contact your dealer for appropriate measures. Excessive refrigerant concentration in a closed ambient space may result in oxygen deficiency. Be sure to use the specified accessories and parts for installation. Failure to use the specified accessories and parts for installation. Failure to use the specified parts may result in water leakage, electric shocks, fire hazards or the unit failing to operate normally. Install the unit on a solid foundation which can withstand the weight of the unit. A foundation of insufficient strength may result in the unit failing and causing injuries. Install the unit at designated places by taking into consideration strong winds such as typhoons and earthquakes. Improper installation may result in the unit failing and causing accidents. Make sure that all electrical work is carried out by the specialized personnel in accordance with local laws and regulations and this manual, and a special power supply circuit is provided for the unit. A ninsufficient power supply circuit capacity or improper electrical operation may lead to electric shocks or fire hazards. Use the specified wires and attach them securely, with no external forces acting on the terminal connections or wires. Improper connecting the indoor and outdoor units and the power supply wiring, to avoid the service lid being protruded and deformed, lay the wires in a smooth and regular way to attach the shell plate properly. Otherwise, the terminals will give out heat and may result in electric shocks	Pergency suppryFrequency horozotal diage to diage 
After completing installation, make sure that no residual voltage exists on the live parts (such as the terminals of earth leakage circuit breakers and terminal blocks) before operating the breakers such as changing. Consult your local dealer regarding what to do in case of refrigerant leakage. When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen depletion. Do not directly touch refrigerant that has leaked from refrigerant pipes or other areas, as there is a danger of frostbite. Do not allow children to climb on the outdoor unit and avoid placing objects on the unit. Injury may result if the unit becomes loose and falls.	2 Before installation Hot be a handles at both sides as shown in the figure below and move it slowly. They attention not to touch the fins at the back. Image: Strate Strat
<ul> <li>Keep the indoor unit, outdoor unit, power wiring and transmission wiring at least 1m away from televisions and radios to prevent image or noise interference. (A distance of 1m or more may not be sufficient to eliminate the noise in the case of strong radio wave.)</li> <li>Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit as far away from fluorescent lamps as possible.</li> <li>Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.</li> <li>Do not install the air conditioner in the following locations: <ul> <li>(a) Where mineral oil mist, oil spray or vapour is produced, for example, in a kitchen.</li> <li>Plastic parts may be aged and damaged, and result in water leakage.</li> <li>(b) Where corrosive gas, such as sulphurous acid gas, is produced.</li> <li>Corroding copper pipes or soldered parts may result in refrigerant leakage.</li> <li>(c) Near machinery emitting electromagnetic waves.</li> <li>Electromagnetic waves may disturb the operation of the control system and cause the unit malfunction.</li> <li>(d) Where flammable gas may leak, where there is a rborne carbon fibre or ignitable dust, or where volatile flammables such as gasoline or thinner are placed. Operating the unit in such conditions may result in fire hazards.</li> <li>(e) Do not install the outdoor unit at the place where there is a shelter of the small animals.</li> <li>Once in the unit, leaves and small animals making contact with the electrical parts can cause malfunction, smoke or fire. Ask the customer to maintain a clean and tidy environment around the outdoor unit.</li> <li>Do not wash the outdoor unit or place objects on it. Falling or tumbling may result in injury.</li></ul></li></ul>	Cutdoor unit Handles     Casing while moving the unit. Failure to do so may sufficient of the corner of the unit with your hands.     Cutdoor unit with your hands.     Cutdoor unit with the specified parts to install the required parts.     Code the accessories or the specified parts to install the required parts.     Code the accessories or the specified parts to install the required parts.     Code the accessories or the specified parts to install the required parts.     Code the accessories or the specified parts to install the required parts.     Code the accessories or the specified parts to install the required parts.     Code the accessories or the specified parts to install the required parts.     Code ventilation     Code ventilation that meets the following conditions and get the accessories of the small animals.     Code ventilation     Code
[Note] • For how to install the indoor unit and the remote controller, refer to the installation manual of each equipment.	wind wind wind wind wind wind wind wind



## 

\_\_\_\_\_ 

Refrigerant piping connection				Charging refrigerant		Be sure to inform other installers or a	ttach the front panel well before you leaving wit	th the power supply turned on for the outdoor unit.	$\bigcirc$
<ul> <li>Precautions to piping connection</li> <li>If there is a possibility that the condensed water on the stop valve might flow into the indoor unit through gaps between the insulation material and piping because the outdoor unit is located higher than the indoor unit, caulk the gaps at the connection.</li> <li>[How to prevent entry of small animals]</li> <li>Caulk the piping through holes with putty or insulation material (field supply)</li> </ul>	<ul> <li>Selection of piping material</li> <li>NOTICE</li> <li>Joint less phosphor-deoxidized copper pipe.</li> <li>Installation shall be done by a licensed installer, the choice of materials and installation shall conform completely with the applicable nation and international codes.</li> <li>Foreign materials inside pipes (including oils for fabrication) must be ≤30 mg/10 m.</li> </ul>	Selection pipe thickness         • The pipe thickness of the refrigerant piping shall comply with the applicable legislation. The minimal pipe thickness         • for R410A piping must be in accordance with the table         Pipe Ø (mm)       Minimal thickness t (mm)         Ø6.4 (1/4")	6-6. Piping insulation         • The connection piping (liquid side, gas side) and the refrigerant branch kit must be insulated. (Otherwise, it may cause water dripping.)         • Reinforce the insulation on the refrigerant piping according to the installation environment.         Ambient temperature       Humidity         ≤30°C       75% to 80% RH       15 mm	7-1. Before charging         • Check the following works are comp         • Piping work • Electrical work • Air to         7-3. Location of value	refrigerant pleted in accordance with the installation man tight test and vacuum drying es	<ul> <li>7-2. About refrigerant tank</li> <li>Check whether the tank has a siphon pipe befiproperly so that the refrigerant is charged in the</li> <li>7-4. Charging refrigerant</li> </ul>	ore charging and place the tank e liquid phase (see the right figure).	ht and charge. ht and charge. hipe within the tank, there's no e tank to charge).	1ks
as shown in the right figure to prevent gaps. (For the outdoor unit, entry by insects could cause short circuit of the electrical component box.)	Temper grade: use piping with temper grade in function of the pipe diameter as listed in table below.      Pipe Ø (mm)     Temper grade of piping material     ≤15.9 (5/8")     O (annealed)     ≥19.1 (3/4")     1/2H (half hard)      DEENET	Ø9.5 (3/8")         0.80           Ø12.7 (1/2")         0.99           Ø15.9 (5/8")         0.99           Ø19.1 (3/4")         0.80           Ø22.2(7/8")         0.80           Ø25.4(1")         0.88	>30°C     ≥80% RH     20 mm       (Be sure to use heat resistant polyethylene foam which can withstand a temperature of 70°C for liquid piping and polyethylene foam which can withstand a temperature of 120°C for gas pip       Image: Constraint of the piping connected locally, wrap the insulation material till the piping connections. The naked piping may result in condensation and burns.	ng.) $3$	-7 	<ul> <li>7.4.1 Flow chart</li> <li>Step 1 <ul> <li>Automatic refrigerant charge procedure</li> <li>Push 1 x BS2: "888"</li> <li>Push BS2 for more than "E 0 I" pressure equalization</li> </ul> </li> </ul>	5 seconds on Cooling charging ("Łⅅȝ" startup control) ("Łⅅȝ" waiting for stable cooling) • Push BS2 within 5 minute • Open valve C	tes Display show "Lu3" and low pressure valve with an interval of 1 second. Refrigerant will be charged automatically "PG" = charging finished Fill in the amount on the "Service Precautions" label • Go to test run (see " <b>9. About test run</b> ")	Finished
(Connecting 4 indoor units)	Outdoor unit (A-C)			1 Measuring instrument 2 Refrigerant R410A tank (siphon sys	15 № 10 № 11 № 11 № 12 13 ⇔ 14 9 Needle valve stem) 10 Stop valve	NOTICE In case of maintenance a contain any refrigerant a charged with its original 7.4.2 Charging method	and the system (outdoor unit+field piping+indoor units) does not ny more (e.g., after refrigerant reclaim operation), the unit has to be amount of refrigerant (refer to the nameplate on the unit).	Cooling (middle segment indicates "[]") Automatic charging will continue, the segment indication shows the current low pressure and the status indication " <i>E</i> [] 3" intermittent. When the unit stops operating, close valve C and check whether the segment indication user interface of indoor unit shows " <i>P</i> <sup>g</sup> ". This indicates the automatic charging in cooling program was finished successfully.	ure value
Max. allowable length       Between outdoor unit and indoor unit       Actual piping length         Allowable height difference       Between outdoor unit and indoor unit       Difference in height         Allowable length after the branch       Actual piping length	Indoor units (1~4)       L4         Piping length between outdoor unit and indoor unit ≤120r         Equivalent piping length between outdoor unit and indoor         Total piping length from outdoor unit to all indoor units ≤3         t       Difference in height between outdoor unit and indoor unit         t       Difference in height between indoor units (H2) ≤15m for I         p       Piping length from the first refrigerant branch kit (BEENE)	a Take connection of 4 indoor units as example: a + b + unit ≤150m (Assume equivalent piping length of REFNE 00m (H1) ≤50m (Max 40m if the outdoor unit is in the lower p XMQ8ARY16.	c + d ≤120m. ET joint to be 0.5m that of REFNET header to be 1m.) part) + c + d ≤40m	4 Gas side stop valve 5 Liquid side stop valve 6 Refrigerant auto charge port 7 Outdoor unit 8 To indoor unit	12 Stop valve with service port 13 Field piping 14 Gas flow 15 Stop valve service port	As explained during vacual refrigerant charging can si A flow chart is available w (see " <b>7.4.1 Flow chart</b> "). Follow the steps as descri charge function.	hich gives an overview of the possibilities and actions to be taken bed below and take into account whether you use the automatic	<ul> <li>When "<i>E</i><sup><i>D</i></sup>3" starts to flash, push BS2 within 5 minutes. Be aware that refrigerant will n added to the system immediately after BS2 is pushed, however this is not a malfunction. The system will automatically begin adding refrigerant once the liquid conditions are st</li> <li>INFORMATION</li> <li>When a malfunction is detected during the procedure (e.g, in case of closed stop val a malfunction code will be displayed. In that case, refer to "Malfunction code list" and</li> </ul>	l not be tion. stable. valve), and solve
Selecting refrigerant branch kit Selecting the piping size [Precautions to select connection piping] If the equivalent piping length between outdoor and indoor units is over 90m, size of the main pipe on the gas side must be increased. In addition, depending on the distance of the refrigerant piping, size of the main pipe alog on the gas picture distance and	<ul> <li>Piping between outdoor unit and refrigerant branch kit</li> <li>Should correspond to the size of the connection piping of outdoor unit.</li> <li>Size of the piping connected to outdoor unit. (Unit: mm)</li> </ul>	Piping between refrigerant branch kits   • Select piping size based on the following tab	Piping between refrigerant branch kit and indoor unit • Should correspond to the size of the connection piping of indoor unit. (Unit: mm) Size of the piping connected to indoor unit. (Unit: mm)	<ul> <li>Charging with an unsuitable substar the appropriate refrigerant (R410A)</li> <li>M CAUTION</li> <li>If automatic refrigerant charging is (Malfunction code "IJ∃" will be disp</li> <li>If charge refrigerant without autom</li> </ul>	nce may cause explosions and accidents, so is charged. Refrigerant containers must be o s not executed, system operation is not possil played.) matic charging procedure, refrigerant amount	<ul> <li>always make sure that oppened slowly.</li> <li>The unit's internal pipi connecting the charge</li> <li>After adding the refrige The tightening torque</li> <li>In order to ensure unif to start up after the unit</li> <li>1 Adding refrigerant by use</li> </ul>	ng is already factory charged with refrigerant, so be careful when hose. erant, do not forget to close the lid of the refrigerant charging port. for the lid is 11.5 to 13.9 N·m. orm refrigerant distribution, it may take the compressor ±10 minutes it has started operation. This is not a malfunction.	<ul> <li>the malfunction accordingly. Resetting the malfunction can be done by pushing BS1 The procedure can be restarted from 2).</li> <li>Aborting the automatic refrigerant charge is possible by pushing BS1. The unit will stop and return to idle condition.</li> <li>Information which may occur during additional refrigerant charging procedures: <i>PB</i>: Indoor unit freeze up prevention Action: Close valve C. Reset malfunction by pushing BS1. Retry auto charge procedure</li> </ul>	\$1.
Image: State of the stat	Outdoor unit capacity type (HP)     Piping size (outer diameter)       8     Ø19.1 (3/4")     Ø9.5 (3/8")	Total capacity index of connected indoor units         Gas pipe         Lie           X<150         Ø15.9 (5/8")         4           150≤X<200         Ø19.1 (3/4")         Ø9           X≥200         Ø22.2(7/8")         100	quid pipePiping size (outer diameter)Indoor unit capacity typeGas side pipingLiquid side piping≤50Ø12.7 (1/2")Ø6.4 (1/4")≥63Ø15.9 (5/8")Ø9.5 (3/8")	<ul> <li>quantity and result to liquid hammediately and result to liquid hammediately. If the tank is left with may get off point. More refrigerant</li> <li>NOTICE</li> <li>If the power of some units is turned.</li> </ul>	her. I protect your eyes when charging refrigerant. becedure is done or when pausing, close the van in the valve open, the amount of refrigerant wh that may be charged by any remaining pressure ed off the charging procedure cannot be finis!	t. valve of the refrigerant tank hich is properly charged e after the unit has stopped. bed properly t. valve of the refrigerant tank is properly charged e after the unit has stopped. bed properly t. 2 Breacture	<b>J</b> It charging has limits as described below. 0°C DB~43°C DB. 0°C DB~32°C DB. Prature is lower than 5°C, the refrigerant tank should be warmed during	<ul> <li>P2: Abnormal low pressure drop</li> <li>Action: Close valve C. Reset malfunction by pushing BS1. Check following items bef retry auto charge procedure:         <ul> <li>Check if the gas side stop valve is opened correctly.</li> <li>Check if the valve of the refrigerant cylinder is opened.</li> </ul> </li> <li>Check if the air inlet and outlet of the indoor units are not obstructed.</li> <li>Other malfunction code: Close valve C. Confirm the malfunction code and take correspondation, "Malfunction code list".</li> </ul>	efore
How to calculate the additional refrigerant to be charged Additional refrigerant to be charged: R(kg) (R should be rounded off in units of 0.1 kg.)	$R = \left( \begin{array}{c} \text{Total length of} \\ \text{liquid side piping} \\ \text{size at } \emptyset 12.7 \end{array} \right) \times 0.12 + \left( \begin{array}{c} \text{Total length of} \\ \text{liquid side piping} \\ \text{size at } \emptyset 9.5 \end{array} \right)$ <b>INFORMATION</b> The refrigerant amount that can be automatically charge	$(x_{0.059}) + \left( \begin{array}{c} \text{Total length of} \\ \text{liquid side piping} \\ \text{size at } \emptyset 6.4 \end{array} \right) \times 0.022 \text{Example: } \mathbf{R} = \boxed{\mathbf{R}}$	gerant branch piping with REFNET joint $25\times0.059$ + $15\times0.022$ =1.805a: $09.5\times10m$ d: $06.4\times5m$ g: $06.4\times5m$ b+c+fd+e+g1.8c: $09.5\times5m$ e: $09.5\times5m$ f: $09.5\times5m$ s provided from calculations, but there are no problems in performance and quality.	<ul> <li>Make sure to turn ON the power 6 crankcase by pre-heating operatio</li> <li>If operation is performed within 12 the compressor will not operate be outdoor unit and indoor units.</li> <li>Before starting charging procedure PCB is as normal. If a malfunction</li> <li>Make sure all connected indoor units</li> </ul>	6 hours before starting the operation. This is r on (automatic). 2 minutes after the indoor and outdoor units a before the communication is established in a c res, check if the segment display indication of n code is present, see "Malfunction code list". inits are recognised.	are turned on,       Push BS2 once, indice         correct way between       Push BS2 for more the         of the outdoor unit A1P       Segment display indice         Vertice unit A1P       When "LB3" starts flat         If BS2 is not pushed week       Cooling operation is	s shown. ation "BBB". an 5 seconds, wait while the unit is preparing for operation. cation: " $LD$ I" (pressure control is executed): started: indication " $LDD$ " till " $LDD$ " will be displayed (start up control; g operation). shing (ready for charging), push BS2 within 5 minutes. Open valve C. within 5 minutes, a malfunction code will appear: nalfunction code " $PD$ " will appear. Push BS3 to restart the procedure.		
Pipe size selection Choose from the following table in accordance with out	Itdoor unit total capacity type, connected downstream.	(Unit: mm)		8 After installation compl	leted				
Symbol         Between outdoor and first refrigerant branch kit	a RXMQ8ARY16 Ø19.1 (3/4")	r) Liquid pipe Ø9.5 (3/8")		Be sure to check the following a 1) Incorrect power wiring and loose so 2) Incorrect transmission wiring and loose 3) Incorrect refrigerant piping 4) Piping size and insulation	after installation screws — Refer to 5-3. oose screws — Refer to 5-4. Refer to 6-2.	. Precautions to power wiring connection . . Precautions to wiring connection between units . Refrigerant piping connection . Selecting piping material , 6-6. Piping insulation .	5) Stop valves Check if 6) Record refrigerant charge Keep a 7) Insulation test on main power circuit Use 50 • Do not	if the liquid side and gas side stop valves are opened). record in the "Refrigerant charge" in the "Service Precautions" label). DOV insulation tester. t use it in low voltage circuit less than 220V. (Connection wiring between outdoor and indoor	or units)
(a) The refrigerant sound from the outdoor unit can be transmitted.	connected indoor units         Gas pipe           X<150         Ø15.9 (5/8")           150≤X<200         Ø19.1 (3/4")           X≥200         Ø22.2(7/8")	Ø9.5 (3/8")		9 About test run ) To st	Be sure to inform other in well before leaving with to outdoor unit.	on the power supply to the heating co installers or attach the front panel the power supply turned on for the	<ul> <li>After test run is completed, operate the unit normally.</li> <li>1) Check the indoor and outdoor units are in normal operation.</li> <li>2) Operate each indoor unit one by one and check the operate of complete the operation of the operation.</li> <li>3) Check to see if cold (or hot) air is coming out from the operation.</li> </ul>	eration. d compression of the compressor, stop the unit immediately.) corresponding outdoor unit is also in operation. le indoor unit.	
<ul> <li>(b) A liquid/gas size up is required for all the piping between the branch kit and V</li> <li>(c) In some indoor units, the piping size is different. Choose from the size of each</li> <li>6-7. Air tight test and vacuum drying</li> <li>Air tight test</li> <li>- Always use nitrogen. (Refer to Stop valve operation procedure for se</li> <li>[Procedure] : Pressurize the liquid side piping and the gas side piping to 4.0MPa (do not If the pressure does not drop within 24 hours, the system passes the test. If</li> </ul>	VRV unit. If the piping diameter of the sized up piping exceeds the indoor units.	AUTION To those doing piping work • Be sure to drying. (find the second	ranch kit, then the latter also requires a liquid/gas size up. to open the stop valves after completing wiring connection, air tight test and vacuu Operation with the stop valve closed will result in compressor malfunction.)	<ul> <li>Before powering on</li> <li>Protect the electronic components with the To ensure safety, check the indoor of O-1. Powering on ~ 1</li> <li>Make sure to perform a test run first af the malfunction code "U3" will be indica.</li> <li>After turning on the power supply, do r PC board (A1P). (For positions of the board (A1P).</li> </ul>	with insulating tape in accordance with the "Ser outdoor unit will operate automatically after pow unit installation has been completed. <b>test run</b> after installation. (If the unit is operated with the indo ated on the display of the remote controller and the not touch any switches excluding push button switch button switches (BS1-3) and DIP switches (DS1, 2)	prvice Precautions" label attached to the front panel. wering on. boor unit's remote controller but without performing test run, a unit will not operate normally.) ches and DIP switches when setting the outdoor unit's 2) on PC board, refer to the "Service Precautions" label.)	<ul> <li>4) Press the fan direction and strength buttons of the indicators of the in</li></ul>	n if the ON/OFF button of the remote controller is pressed. controller, the outdoor unit may continue operating for further 1 minute at maximum. run at first installation, the malfunction code "U3" will be displayed. In this case, ering on ~ test run . (check the remote controller connected with the indoor unit)	
<ul> <li>Vacuum drying - Use a vacuum pump able to evacuate the system to -100.7 kPa (5Te [Procedure] : Evacuate the system from the liquid side piping and gas side piping using a Keep the system under this condition for more than 1 hour, check if the vac (If it rises, the system may either contain moisture inside or have gas leak.)</li> <li>If moisture might enter the piping (e.g. if doing work during the rainy season, if the actu After performing the vacuum drying for 2 hours, pressurize to 0.05 MPa (vacuum breakdown the vacuum pump (vacuum drying).</li> <li>(If the pressure does not reach -100.7 kPa even after depressurizing for at least 2 hours, repaid make sure the pressure does not rise by monitoring with a vacuum gauge.</li> </ul>	Forr, -755mmHg) or less. a vacuum pump for more than 2 hours to -100.7 kPa or less. cuum gauge indication rises or not. ) ual work takes long enough that condensation may form on the ins m) with nitrogen gas, then depressurize down to -100.7 kPa or epeat the vacuum breakdown-vacuum drying process.) After va	de of the pipes, if rain might enter the pipes during work, e ess and hold for an hour using cuum drying, maintain the vacuum for an hour	tc.)	<ul> <li>Check the state of the outdoor units and the front panel of the outdoor units and the front panel of the outdoor units and the front panel of the outdoor units and the power supply of the outdoor units and the power to the outdoor units and the front panel of the front panel of the front panel of the outdoor units and th</li></ul>	oor unit. butdoor and indoor units. Int are set. unit and the connected indoor units. lation is existing. Push BS2 for 5 seconds or r tically carried out, the outdoor unit display will ol" will display on the user interface of indoor u	more. The unit will start test operation. Il indicate "ED I" and the indication "Test operation" units.	Malfunction code         Contents           Main         Sub code         Contents           code         Master         Contents           E3         01         High pressure switch was activated (S1PH) - A           02         • Refrigerant overcharge.           • Stop valve closed.         13           E4         01         Low pressure malfunction:           • Stop valve closed.         • Stop valve closed.           • Stop valve closed.         • Stop valve closed.	Solution Solution Check stop valve situation or abnormalities in (field) piping or airflow over air cooled of Check refrigerant amount+recharge unit. Open liquid stop valve. Open liquid stop valve. Open stop valve. Check refrigerant amount+recharge unit. Check the user interface's display or Transmission wiring betwee	ed coil.
Charge hose Pressure-reducing valve Charge hose Charge	bing system valve (close) to charge port			"LDF" : control before start up - "LDF" : control before start up - "LDF" : cooling start up contr - "LDF" : cooling stable conditi - "LDF" : communication check - "LDF" : stop valve check - "LDF" : pipe length check - "LDF" : refrigerant amount ch - "LDF" : pump down operation	pressure equalization) trol ck wheck		E9       03       Electronic expansion valve malfunction (subcoded in the second constraints)         F3       01       Discharge temperature too high (R21T) : <ul> <li>Stop valve closed.</li> <li>Refrigerant shortage.</li> <li>Stop valve closed.</li> </ul> F6       02       Performation vercharge.         Valve closed.       Stop valve closed.         H9       01       Ambient temperature sensor malfunction (R1T)	the outdoor unit and the indoor unit. iol) (Y2E) - A1P(X22A). Check connection on PCB or actuator. erant auto charge) (Y4E) - A1P(X25A). Check connection on PCB or actuator. • Open stop valve. • Check refrigerant amount+recharge unit. • Check refrigerant amount+recharge unit. • Open stop valve. • Check connection on PCB or actuator.	
Vacuum pump Measuring instrument	door unit $\downarrow \qquad \downarrow \qquad$			- "E IC" : unit stop  INFORMATION  If the automatic refrigerant chat already been checked during a  During test operation, it is not p The unit will stop after ±30 sec	arge function has been used, "上口"," will not be displa automatic refrigerant charge operation. possible to stop operation of the unit from a user inte conds.	layed during the test run, as they have Iterface. To abort operation, press BS3.	J3       16       Discharge temperature sensor malfunction (R2         17       Discharge temperature sensor malfunction (R2         J5       01       Suction temperature sensor malfunction (R3T)         J6       01       De-icing temperature sensor malfunction (R7T)         J7       06       Liquid temperature sensor (after subcool HE) m         J8       01       Liquid temperature sensor (coil) malfunction (R         J9       01       Gas temperature sensor (after subcool HE) ma         J8       06       High pressure sensor malfunction (S1NPH): op	21T): open circuit - A1P (X19A).       Check connection on PCB or actuator.         21T): short circuit - A1P (X19A).       Check connection on PCB or actuator.         2-A1P (X30A).       Check connection on PCB or actuator.         (Y) - A1P (X30A)       Check connection on PCB or actuator.         (T) - A1P (X30A)       Check connection on PCB or actuator.         (T) - A1P (X30A)       Check connection on PCB or actuator.         (T) - A1P (X30A).       Check connection on PCB or actuator.         (R4T) - A1P (X30A).       Check connection on PCB or actuator.         (R4T) - A1P (X30A).       Check connection on PCB or actuator.         (R6T) - A1P (X30A).       Check connection on PCB or actuator.         (P) - A1P (X30A).       Check connection on PCB or actuator.         (R4T) - A1P (X30A).       Check connection on PCB or actuator.         (P) - A1P (X32A).       Check connection on PCB or actuator.	
Valve C (close) Note) Be sure to shut off the liquid side and gas side stop valves. Otherwise, it may cause refrigerant leakage of the outdoor unit.	port			Crieck the test operation results on the operation results on the operation results on the operation of a completion: indication of a completion: indication of Refer to "Correcting after abnormal completed When the test operation is fully completed In case of a displayed malfunction of Carry out the test operation again an	In outdoor unit segment display. on the segment display (idle) f malfunction code on the segment display completion of the test operation" to take action for c inpleted, normal operation will be possible after 5 min etion of the test operation d if there is no malfunction code displayed on the us code, perform correcting actions as explained in the i nd confirm that the abnormality is properly corrected	correcting the abnormality. nutes. ser interface or outdoor unit segment display. malfunction code table. rd.	JE         07         High pressure sensor malfunction (STNPH): sign pressure sensor malfunction (STNPL): ope 07           Low pressure sensor malfunction (STNPL): sho           LE         14         Transmission outdoor unit - inverter: INV1 trans           19         Transmission outdoor unit - inverter: FAN1 trans           P I         01         INV1 unbalanced power supply voltage.           U2         01         INV1 voltage power shortage.           02         INV1 power phase loss.	norr circuit - ATP (X32A).       Check connection on PCB or actuator.         en circuit - ATP (X31A).       Check connection on PCB or actuator.         ort circuit - ATP (X31A).       Check connection on PCB or actuator.         ismission trouble - ATP.       Check connection         nsmission trouble - ATP.       Check connection         Check if power supply is within range.       Check if power supply is within range.         Check if power supply is within range.       Check if power supply is within range.	
Stop valve operation procedure         Precautions to stop valve operation         • Name of each part should be known before operating the stop valve (as shown in the right fig. When shipped, the stop valve is left closed.         • Simply using a torque wrench to loosen or tighten the flaring nut may cause deformation of th Be sure to fix the flaring nut with a normal wrench, then operate it with the torque wrench.         • When opening or closing the stop valve lid and flaring nut, make sure that the tool does not to	gure). Liquid stop valve Ga he side panel. <u>Service port</u> <u>Service</u>	e port To open	About valve lid  • Position indicated by the arrow has been caulked. Pay attention not to damage it.	INFORMATION     Refer to the installation manual of     G     Be sure to attach the front panel of th     [About test run]     In order to ensure uniform refrigerant     This is not malfunction.     Magning chapter is entered in act to be	of the indoor unit for other detailed malfunction code the outdoor unit after test run is completed. In distribution, it may take up to around 10 minutes for	es related to indoor units.	Image: Second	rge run not yet executed. Execute auto charge function (see manual). Execute test run again. Check (F1/F2) wiring. Check indoor system transmissions wire. Check indoor unit amount and total capacity connected. s combined (R410A, R407C, RA). Check if other indoor units have malfunction and confirm indoor unit mix is allowed.	
It may cause an electric shock or a fire, and cause damage to electrical components. [Stop valve operation procedure] Prepare two inner hexagon wrenches: size 4mm, 6mm. To open 1. Put the inner hexagon wrench to the valve shaft and turn it counterclockwise. 2. Turn it until the shaft stops. The valve is opened. To close 1. Put the inner hexagon wrench to the valve shaft and turn it clockwise. 2. Turn it until the shaft stops. The valve is opened.	o the valve shaft and valve is closed.	Piping connections	<ul> <li>Be sure to tighten the value iid after value operation is completed.</li> <li>About service port <ul> <li>Operate with the charge hose with a pushing stick.</li> <li>Be sure to tighten the value lid after operating. Tightening torque11.5~13.9 N•m</li> <li>Liquid side tightening torque 13.5~16.5N•m</li> <li>22.5~27.5N•m</li> </ul> </li> </ul>	<ul> <li>Meaning of operation check is not to C</li> <li>Test run can't be performed when the</li> <li>Never perform test run with discharg</li> <li>Failure to do so will result in compress</li> <li>9-2. For normal ope</li> <li>[Set the master unit the</li> </ul>	the unit is in other mode such as refrigerant recycling ge pipe thermistor (R2T), suction pipe thermistor (R3 essor damaged. eration (the indoor unit with cooling a	g mode. IST) and pressure sensor (S1NPH, S1NPL) removed. and heating option rights).]	UR         03         Connection malfunction over indoor units or typ           18         Refrigerant type mismatch (Field setting error).           UF         01         Auto address malfunction (inconsistency).           05         Stop valve closed or wrong (during system test           UH         01         Auto address malfunction (inconsistency).           For the case with centralized controller used, refer to the inst	pe mismatch (R410A, R407C, RA).       Check if other indoor units have malfunction and confirm indoor unit mix is allow         .       Check if other indoor units have malfunction and confirm indoor unit mix is allow         Check if other indoor units have malfunction and confirm indoor unit mix is allow         Check if transmission wired unit amount matches with powered unit amount (by monitor mode) or wait till initialization is finished.         t run).       Open stop valves.         Check if transmission wired unit amount matches with powered unit amount (by monitor mode) or wait till initialization is finished.         .       Check if transmission wired unit amount matches with powered unit amount (by monitor mode) or wait till initialization is finished.         .       Check if transmission wired unit amount matches with powered unit amount (by monitor mode) or wait till initialization is finished.         .       tallation manual included with it under service manual.	iowed. lowed. t. d. d. ed.
				<ul> <li>For wired remote controller</li> <li>After test run is completed, symb</li> <li>Set the master unit as customer's</li> <li>Press the operation mode chang</li> <li>Conduct cool/heat changeover w</li> <li>For other remoter controllers exc</li> <li>For wireless remote controller</li> </ul>	bol " $\square$ $\frac{1}{2}$ " flashes on all remote con 's request. (It is recommended to set the indoor geover button on the remote controller of the r with this remote controller and the symbol " cluding the above, symbol " $\square$ $\frac{1}{2}$ " lig	ntrollers connected here. or unit with highest frequency of use as the master unit.) master unit.	No display on the remote controller  • Connection and communication error occurred between the	ne indoor unit and the remote controller. Check wiring connection for the broken and loose.	
				<ul> <li>After test run is completed, timer</li> <li>Set the master unit as customer's</li> <li>Press the operation mode chang and the timer lamps on all indoor</li> <li>The indoor unit has the option rig</li> <li>For details, refer to the installation</li> </ul>	is request. (It is recommended to set the indoor geover button on the remote controller of the r or units go out. ights to change over to cooling/heating operat ion manual included with the indoor unit.	ere. or unit with highest frequency of use as the master unit.) master unit. Then a sound of beeps can be heard ation.			
				CAUTION To th	nose doing piping work • A nose doing electrical work b	After test run is completed, check whe before transferring the air conditioner	ether the casing of the units has been attached a to your customer.	and whether the screws have been tightened	al bar code

