



# Split System Air Conditioner

## INSTALLATION MANUAL <FOR OUTDOOR UNIT>

READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION.

### NEW REFRIGERANT (R32) SERIES

RZVFQ50,71AV16 / RZMFQ50,71A16 ,RZCFQ71CV16

Note : Read the precautions in this manual carefully before operating the unit.  
 This appliance is filled with R32.

### CONTENTS

※ SAFETY PRECAUTIONS.....	1-2-3
1. BEFORE INSTALLATION.....	3
2. SELECTING INSTALLATION SITE.....	3-4
3. INSTALLATION SERVICE SPACE.....	4-5-6
4. PRECAUTIONS ON INSTALLATION.....	7
5. REFRIGERANT PIPING WORK.....	7-8-9-10
6. AIRTIGHTNESS TEST AND AIR-PURGE.....	10
7. CHARGING REFRIGERANT.....	11-12
8. ELECTRICAL WIRING WORK.....	12-13-14
9. CHECK ITEMS BEFORE TEST OPERATION AND FIELD SETTINGS.....	15
10. TEST OPERATION.....	16
11. CAUTION.....	17



### WARNING THERE IS A RISK OF EXPLOSION OR FIRE

- Do not mix air in the refrigerating cycle during pump down operation.
- Do not use oxygen for air tight test.
- Do not use refrigerant other than the specified one or flammable material ( e.g. propane ) in the refrigerant cycle. They may cause over pressure in the refrigerating cycle and result in explosion, fire or injury. Our company assumes no responsibility for failure or malfunction caused by filling or mixing of anything other than the specified refrigerant.



### CAUTION ABOUT ISOLATING RESISTANCE OF COMPRESSOR

If refrigerant accumulates in the compressor after completing installation, the insulation resistance can drop, but if it at least  $1\text{ M}\Omega$ , then the unit will not break down.

- Connect the power supply to the unit and after 6 hours check if the insulation resistance of the compressor rises. (Energize and heat the compressor to vaporize the refrigerant accumulated in the compressor.)
- If the earth leakage breaker actuates, check if the earth leakage breaker is equipped with a device to cope with high harmonics. To prevent wrong actuation of the earth leakage breaker due to the inverter, make sure to adopt an earth leakage breaker equipped with a device to cope with high harmonics.

1. Please make sure to confirm that R32 (new refrigerant) is used in installation work in advance.  
(It may not operate normally, if refrigerant type is different.)
2. The refrigerant R32 requires that strict precautions be observed for keeping the system clean, dry and tightly sealed.
  - Clean and dry  
Strict measures must be taken to keep impurities (Including SUNISO oil and other mineral oils as well as moisture) out of the system.
  - Tightly sealed  
R32 contains no chlorine, does not destroy the ozone layer and so does not reduce the earth's protection against harmful ultraviolet radiation. R32 will contribute only slightly to the greenhouse effect if released into the atmosphere. Therefore, sealing tightness is particularly important in installation.  
Carefully read the chapter **5 REFRIGERANT PIPING WORK** and strictly observe the correct procedures.
3. The design pressure of this unit : High/Low pressure area are shown in the right table.  
The refrigerant piping is a high pressure area,  
Use the refrigerant piping which supports the design pressure.  
The piping specifications, please refer to chapter **5 REFRIGERANT PIPING WORK**
4. Be sure to connect the indoor unit, which is dedicated to R32. See the catalog for indoor unit models which can be connected.  
(Normal operation is not possible when connected to other units.)

Outdoor Unit	Design pressure	Cooling
RZVFQ50/71AV16 RZMFQ50/71A16 RZCFQ71CV16	High	4.17
	Low	2.21

(Units: MPa)

## READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION

- This manual classifies the precautions into **WARNINGS** and **CAUTIONS**.  
Be sure to follow all the precautions below. They are all important for ensuring safety.

### **WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

### **CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.  
It may also be used to alert against unsafe practices.

- After the installation is completed, test the air conditioner and check if the air conditioner operates properly.  
Give the user adequate instructions concerning the use and cleaning of the indoor unit according to the operation manual.  
In particular, make sure to explain with regard to "SAFETY PRECAUTIONS" and "Not malfunction of the air conditioner".  
Ask the user to keep this manual and the operation manual together in a handy place for future reference.
- This air conditioner comes under the term "appliances not accessible to the general public".

### **WARNING**

- Ask your local dealer or qualified personnel to carry out installation work.  
Improper installation may result in water leakage, electric shocks or a fire.
- Perform installation work in accordance with this installation manual.  
Improper installation may result in water leakage, electric shocks or a fire.
- Consult your local dealer regarding what to do in case of refrigerant leakage.  
When the indoor unit is installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen deficiency.
- Be sure to use only the specified parts and accessories for installation work.  
Failure to use the specified parts may result in the air conditioner fall down, water leakage, electric shocks, a fire, etc.
- Install the air conditioner on a foundation that can withstand its mass.  
Insufficient strength may result in the air conditioner fall down and causing injury.
- Carry out the specified installation work in consideration of strong winds, typhoons, or earthquakes.  
Improper installation may result in an accident such as the air conditioner falling.
- Make certain that all electric work is carried out by qualified personnel according to the applicable legislation (note 1) and this installation manual, using a separate circuit. In addition, even if the wiring is short, make sure to use a wiring that has sufficient length and never connect additional wiring to make the length sufficient. Insufficient capacity of the power supply circuit or improper electric construction may lead to electric shocks or a fire.  
(note 1) Applicable legislation means "All international, national and local directives, laws, regulations and/or codes which are relevant and applicable for a certain product or domain."
- Earth the air conditioner.  
Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring.  
 Incomplete earthing may cause electric shocks or a fire.
- Be sure to install an earth leakage circuit breaker.  
Failure to do so may cause electric shocks or a fire.
- The appliance must be stored in a room without continuously operating ignition sources (for example : open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerant may not contain an odour.
- Comply with national gas regulations.
- Be sure to switch off the unit before touching any electrical parts.  
Touching a live part may result in electric shocks.
- Make sure that all wiring is secure, using the specified wiring and ensuring that external forces do not act on the terminal connections or wiring. Incomplete connection or fixing may cause overheating terminals or fire.
- When wiring between the outdoor and indoor units, and wiring the power supply, from the wiring orderly so that the structural parts such as a cover can be securely fastened.  
If the cover is not in place, electric shocks or a fire may be caused.
- Do not add wiring. It may result in heat generation. Electric shocks or fire.
- When installing or relocating the air conditioner, be sure to bleed the refrigerant circuit to ensure it is free of air, and use only the specified refrigerant (R32).  
The presence of air or other foreign matter in the refrigerant circuit causes abnormal pressure rise, which may result in equipment damage and even injury.
- If refrigerant gas leaks during installation work, ventilate the area immediately.  
Toxic gas may be produced if refrigerant gas comes into contact with a fire.
- After completing the installation work, check to make sure that there is no leakage of refrigerant gas.  
Toxic gas may be produced if refrigerant gas leaks into the room and comes into contact with a source of a fire, such as a fan heater, stove or cooker.
- Never directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.
- Do not stand on the outdoor unit or put things on it.  
The unit may fall down or drop, and cause accidents.
- Do not charge any refrigerant into the refrigeration cycle other than the designated refrigerant.  
It may cause an explosion or a fire due to leakage or a burst due to abnormally high pressure in the refrigeration cycle.
- Do not extend wiring on the way.  
It may cause heat generation, electric shocks or fire.
- At the installation work, install the refrigerant piping firmly before operating the compressor.  
If the compressor is operated without installing firmly and the service valve is in open condition, it sucks the air, etc., and the pressure inside the refrigerant circle becomes abnormally high. It may cause injury and breakage.
- At pump down work, stop the compressor before removing the refrigerant piping.  
If removing the refrigerant piping when the compressor is operated with its service valve in open condition, it sucks the air, etc., and the pressure inside the refrigerant circle become abnormally high, which may cause injury and breakage.
- When flared joints are indoors, the flare part shall be re-fabricated.

## CAUTION

- Install drain piping according to this installation manual to ensure good drainage, and insulate the piping to prevent condensation. Improper drain piping may cause water leakage, make the furniture get wet.
- Install the indoor and outdoor units, power cord and connecting wires at least 1 meter away from televisions or radio to prevent picture interference and noise. (Depending on the incoming signal strength, a distance of 1 meter may not be sufficient to eliminate noise.)
- Install the indoor unit as far as possible from fluorescent lamps. If a wireless remote controller kit is installed, the transmission distance of the remote controller may be shorter in a room where an electronic lighting type (inverter or rapid start type) fluorescent lamp is installed.
- In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- Disposal requirements**  
Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.
- Only qualified personnel can handle, fill, purge and dispose of the refrigerant.
- Do not install the air conditioner in places such as following:
  - Where there is mist of oil, oil spray or vapor for example a kitchen.  
Resin parts may deteriorate, and cause them to fall out or water to leak.
  - Where corrosive gas, such as sulfuric acid gas, is produced.  
Corrosion of copper pipings or brazed parts may cause the refrigerant to leak.
  - Where there is machinery which emits electromagnetic waves.  
Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
  - Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables, such as thinner or gasoline, are handled. If the gas should leak and remain around the air conditioner, it may cause ignition.
  - The place that the vibration or the voltage fluctuation give influence. Vehicles, vessels, etc.  
The vibration may cause a damage and the voltage fluctuation may cause an abnormal operation.
  - Where small animals may build a nest, fallen leaves are accumulated, or weeds are overgrown.  
If small animals touch the electrical parts inside, this may cause malfunction, smoke or a fire.

■ Important information regarding the refrigerant used  
This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.  
Refrigerant type: R32  
GWP<sup>(1)</sup> value: 675  
<sup>(1)</sup>GWP = global warming potential  
• The refrigerant quantity is indicated on the unit name plate.


## 1 BEFORE INSTALLATION

<DO NOT THROW AWAY ACCESSORIES FOR INSTALLATION>

### CAUTION


- Read these instructions carefully before installation.  
For installation of the indoor unit, refer to the indoor unit installation manual.

**RZVFQ50,71AV16**  
**RZMFQ50,71AV16**  
**RZCFQ71CV16**





### HANDLING

As shown in the figure, bring the unit slowly by grabbing the left and right grips.  
(Take care not to let hands or objects come in contact with rear fins.)



Place your hands on the corner instead of holding the suction inlet in the side of the casing, otherwise the casing could be deformed.



### INSTALLATION CONSTRUCTION ACCESSORIES

Be sure only to use accessories made by DAIKIN which are specifically designed for use with the equipment.


### CAUTION

Work in a team of at least two people when carrying the outdoor unit

## 2 SELECTING INSTALLATION SITE (1/2)

- Select the installation location that meets the following conditions and get approval of the customer.

- Places where is no risk of flammable gas leakage.
- Places where the outdoor unit does not bother next-door neighbors.
- Safe places where can withstand the unit's mass and vibration and where the air conditioner can be installed level.
- Places where are well-ventilated and where servicing space can be well ensured.  
The minimum required space is shown in chapter **3 INSTALLATION SERVICE SPACE**
- Where the piping length between the indoor and the outdoor units is ensured within the allowable piping length. (Please see chapter **5 REFRIGERANT PIPING WORK**)
- Do not allow wind from the same direction to blow frequently toward the outlet or inlet of the outdoor unit. If the wind is likely to blow as mentioned above, make sure to keep a sufficient service space and install a wind protective shield.



Inverter air conditioners may cause noise to occur in electrical appliances. As shown in the right drawing, select an installation site well away from radios, PCs, and stereos.

Especially in the areas where the incoming signal strength is weak, keep the indoor remote controller 3 meter or more from electrical appliances.

Put the power supply and transmission wiring in a metal piping and ground the metal piping.

## 2 SELECTING INSTALLATION SITE (2/2)

### CAUTION

- 1) In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- 2) When installing the unit in a place exposed to strong wind, pay special attention to the following. Strong winds of 5 m/sec or more blowing against the outdoor unit's air outlet causes short circuit (suction of discharge air) and this may have the following consequences:
  - Deterioration of the operational capacity.
  - Disruption of operation due to rise of high pressure.
  - When a strong wind blows continuously on the face of the unit, the fan can start rotating very fast until it breaks. Refer to the figures for installation of this unit in a place where the wind direction can be foreseen.
- 3) Following the installation place, it is expected that the influence of the strong wind is great.
  - The flat area which receives the adverse wind such as typhoon directly since there is no obstacles such as buildings and mountains. (Including coast line, shoreline of lake and mountain region.)
  - The installation place that no obstacles around the outdoor unit to prevent the adverse wind, for example, walls and buildings that are higher than the applicable outdoor unit, etc. Please take measures when installing especially on a rooftop.
  - Since the outdoor unit may fall down, attach the fixture for preventing overturning(option).



- 4) Prepare a water drainage channel around the foundation, to drain waste water from around the unit.
- 5) If the water drainage of the unit is not easy, please build up the unit on a foundation of concrete blocks, etc. (the height of the foundation should be maximum 150 mm).
- 6) If you install the unit on a frame, please install a waterproof plate within 150 mm of the underside of the unit in order to prevent the invasion of water from the lower direction.


## 3 INSTALLATION SERVICE SPACE (1/3)

- The installation servicing spaces shown in these drawings are based on the outdoor unit inlet area temperature of 35°C(DB) for COOLING operation. If the planned inlet area temperature exceeds 35°C(DB), or if the heat load of all outdoor units is increased significantly and exceeds the maximum operating capacity, secure a larger space than that indicated by the inlet dimensions in these drawings.
- For installation, consider both pedestrian and air flow paths and choose a suitable pattern from these drawings to match the space available field. (If the number of units to be installed exceeds the patterns in these drawings, consider there is nothing short-circuits.)
- Regarding the front space, position the units with consideration to the space required for the refrigerant piping work. (Consult your dealer if the work conditions do not match those in the drawings.)
- Secure appropriate space when using a side piping outlet.

### STAND-ALONE INSTALLATION


#### No Obstacle above

- 1) Obstacle on the suction side only




- To secure service space, more than 250 mm of each products at right side in needed. (Units: mm)

- 2) Obstacle on both sides and suction side, too




(Units: mm)

- 3) Obstacle on the discharge side only




#### Obstacle above, too


- 1) Obstacle on the suction side, too



- 2) Obstacle on both sides and suction side, too



- 3) Obstacle on the discharge side only, too



### 3 INSTALLATION SERVICE SPACE (2/3)


When there are obstacles on both suction and discharge sides

(Pattern 1) When the obstacles on the discharge side is higher than the unit

1) No obstacle above (There is no limit for the height of obstructions on the suction side.)


2) Obstacle above, too

The relations between H, A and L are as follows.



	L	A
L ≤ H	L ≤ 0.5H	750 or more
	0.5H < L ≤ H	1000 or more
L > H	Set the stand as: L ≤ H	

- \* Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.
- In case of more than dimension in ( ), It is no need to establish the stand although L > H




(Pattern 2) When the obstacle on the discharge side is lower than the unit

1) No obstacle above (There is no limit for the height of obstructions on the suction side.)


2) Obstacle above, too

The relations between H, A and L are as follows.



	L	A
L ≤ H	L ≤ 0.5H	50 or more
	0.5H < L ≤ H	100 or more
L > H	Set the stand as: L ≤ H	

- \* Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.
- In case of more than dimension in ( ), It is no need to establish the stand although L > H




SERIES INSTALLATION (2 OR MORE)

\* Inside extraction, please provide the space of piping.


(Units: mm)

No obstacle above

1) Obstacle on the suction side and both sides




2) Obstacle on the discharge side only




Obstacle above, too

1) Obstacle on the discharge side



2) Obstacle on the suction side and both sides




### 3 INSTALLATION SERVICE SPACE (3/3)

When there are obstacles on both suction and discharge sides

**Pattern 1** When the obstacles on the discharge side is higher than the side unit

1) No obstacle above (There is no limit for the height of obstructions on the suction side.)




2) Obstacle above, too

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	1000 or more
	$0.5H < L \leq H$	1250 or more
$L > H$	Set the stand as: $L \leq H$	

- To secure service space, more than 250 mm of each products at right side in needed.



※ - Close the bottom of the stand to prevent the discharged air from being bypassed.

- The limitation of facilities connection is until 2 unit only.

- In case of more than dimension in ( ), It is no need to establish the stand although  $L > H$


**Pattern 2** When the obstacle on the discharge side is lower than the unit

1) No obstacle above

(There is no limit for the height of obstructions on the suction side.)

The relations between H, A and L are as follows. The relations between H, A and L are as follows.


L	A
$L \leq 0.5H$	150 or more
$0.5H < L \leq H$	200 or more



2) Obstacle above, too

(Units: mm)

	L	A
$L \leq H$	$L \leq 0.5H$	150 or more
	$0.5H < L \leq H$	200 or more
$L > H$	Set the stand as: $L \leq H$	



- Close the bottom of the stand to prevent the discharged air from being bypassed.

- The limitation of facilities connection is until 2 unit only.


- In case of more than dimension in ( ), It is no need to establish the stand although  $L > H$

#### DOUBLE-DECKER INSTALLATION


- Do not stack more than two unit.
- The drain piping construction size of upper side outdoor unit is needed about 100 mm.
- In side extraction, please provide the space of piping.

(Units: mm)

1) Obstacle on the discharge side




2) Obstacle on the suction side



#### MULTIPLE ROWS OF SERIES INSTALLATION (ON THE ROOFTOP, ETC.)


1) One row of stand-alone installation



2) Rows of series installation (2 or more)

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	150 or more
	$0.5H < L \leq H$	200 or more
$L > H$	Can not be installed	



## 4 PRECAUTIONS ON INSTALLATION

- Check the strength and level of the installation ground so that the unit will not cause any operating vibration or noise after installed.
- In accordance with the foundation drawing in Fig. 1, fix the unit securely by means of the foundation bolts. (Prepare 4 sets of M12 foundation bolts, nuts and washers each which are available on the market.)
- It is best to screw in the foundation bolts until their length are 20 mm from the foundation surface.
- Fix the outdoor unit to the foundation bolts using nuts with resin washers. (See the left-hand of Fig. 1 drawing)  
If the coating on the fastening area is stripped off, the nuts rust easily.

### 〈Drain pipe disposal〉

- If drain pipe disposal from the outdoor unit causes trouble, (for example, if the drain water may splash on people) provide the drain piping by using of the drain plug (optional).
- Then, coat the area around the bored holes with rust preventive coating to cover the metal exposure.
- Make sure the drain works properly.




Fig. 1 BOTTOM VIEW

## 5 REFRIGERANT PIPING WORK (1/4)

### CAUTION

#### To plumbing person

- Important information regarding the refrigerant used. This product contains fluorinated greenhouse gases covered by the Kyoto Protocol.  
Do not vent gases into the atmosphere.  
GWP (global warming potential) of R32 refrigerant type = 675
- Use R32 as additional for charging.
- Do not use flux when brazing refrigerant piping.  
Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux.  
(If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)
- After chapter ⑦ CHARGING REFRIGERANT is completed, be sure to open the stop valves before performing ⑨ LOCAL SETUP.  
(Operating the unit with the valve shut will break the compressor.)

#### 〈Precaution when reuse existed refrigerant pipe〉

Please keep below points in order to reuse existed pipe, failure may caused if have a fault.

- Below are pipes shall always make new construction, do not reuse piping.
  - When removed from indoor unit or outdoor unit for a long time.  
(Moisture entry to internal pipe, wastes entry can be occurred.)
  - When copper tube is corroded.
  - When pipe thickness is insufficient (refer to ⑤-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH table).
  - Do not reuse flare for refrigerant leak protection, please make flare processing.
  - Do not reuse flare nut, please use flare nut in product accessories.
  - Make sure to do refrigerant leak check in case there is brazing area while perform field piping.
  - If insulation is deteriorate, make sure to exchange to new one.

#### 5-1 INSTALLATION TOOLS

Be sure to use the dedicated tools to ensure sufficient pressure resistance and prevent the entry of any impurities.

Manifold gauge	To ensure sufficient pressure resistance and prevent the entry of any impurities (mineral oils such as Suniso oil and liquids), use the R410A or R32 dedicated item (the screw specifications for R410A or R32 differ).
Charging hose	Be extremely careful not to flow the pump oil backward to inside the piping when the pump is stopped. Use a pump which enables vacuuming to -0.1 MPa(-755mmHg) of the gauge pressure.

#### 5-2 SELECTION OF PIPING MATERIAL

- Use the piping whose inside and outside are clean and with no harmful substances for use such as sulphur, oxide, dust, dust from cutting, grease, or liquid (contamination) is attached.
- For the refrigerant piping, use the following material.  
Material: Deoxidised phosphorous seamless copper piping  
Temper grade: Use piping with temper grade in function of piping diameter as listed in the table on section ⑤-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

Size: Decide based on section ⑤-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

Thickness: Comply with applicable legislation. The minimal piping thickness for R32 piping must be in accordance with the table on section ⑤-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

- Be sure to perform piping work using measurements within the maximum allowable length and height difference described on section ⑤-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

## 5 REFRIGERANT PIPING WORK (2/4)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

### 5-3 CARE OF PIPE

- Prevent contamination or moisture from getting into the piping.
- Pay special attention when running the copper piping through the through-hole or when leading the edge of the piping outside the room.
- Refrigerant piping must be protected from physical damage. Install a plastic cover or equivalent.

PLACE	INSTALLATION PERIOD	PROTECTION METHOD	PLACE	INSTALLATION PERIOD	PROTECTION METHOD
OUTDOOR	More than a month	Pinch the pipe	INDOOR	Unquestioned	Pinch or tape pipe
	Less than a month	Pinch or tape pipe			

### 5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

- One way maximum allowable piping length means the maximum length of liquid side piping or gas side piping.
- Equivalent length is the pressure loss due to L joints, traps, and so on along the refrigerant piping converted to a straight piping length of the same size and added to the overall value.
- Please see the Engineering Data for calculation of equivalent length.
- Please give the vertical interval between the indoor and outdoor as 20m or less.

#### CAUTION

- This unit is chargeless specification. Due to chargeless length and allowable piping length will be different depend on field pipe size.

#### Piping bend radius

(Units : mm)

Piping diameter	Pipe thickness (material)	Bend radius
Ø 6.35mm	0.8 mm (C1220T-O, Type O)	30mm or more
Ø 12.7mm	0.8 mm (C1220T-O, Type O)	40mm or more
Ø 15.8mm	1.0 mm (C1220T-O, Type O)	50mm or more

#### Refrigerant pipe size and chargeless length

Outdoor unit type	Liquid pipe size (type)	Chargeless length
RZVFQ50 / 71AV16 RZMFQ50 / 71AV16 RZCFQ71CV16	Ø 6.35mm x t 0.8 mm (type O)	10m

#### WARNING


- When flared joints are reused indoors, the flared part shall be re-fabricated.

#### CAUTION

- Use dedicated piping cutters and flaring tools for R410A or R32.
- When making a flare connection, apply ether or ester oil only to the flare inner surface.
- Use only the flare nuts attached to the unit. If other flare nuts are used, it may cause refrigerant leakage.
- To prevent contamination, dust or moisture from getting into the piping, take measures such as pinching or taping the piping.

### 5-5 CONSTRUCTION OF REFRIGERANT PIPING

- Field pipes can be installed in Back - side connection. <Fig.2>
- Do not allow any substances other than the specified refrigerant such as air to mix into the refrigerant circuit.




## 5 REFRIGERANT PIPING WORK (3/4)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

### PREVENTING FOREIGN OBJECTS FROM ENTERING

- Plug the pipe through-holes with putty or insulating material (field supply) to cover all gaps, as shown in the figure.
- Insects or small animals entering the outdoor unit may cause a short circuit in the electrical box.




### CAUTIONS FOR HANDLING STOP VALVE

**DO NOT OPEN THE STOP VALVE UNTIL CHARGING REFRIGERANT FINISHED.**

- The stop valves for indoor-outdoor connecting piping are closed at shipment from the factory. The names of parts are shown in figure on the right.
- Since the side boards may be deformed if only a torque wrench is used when loosening or tightening flare nuts, always lock the stop valve with a wrenches and then use a torque wrench.


When tightening the flare of the stop valves, make sure to tighten by the rated torque. The rated torque is shown on (CAUTION FOR FLARE CONNECTION) (Following)



**DO NOT APPLY FORCE ON THE VALVE CAP, THIS MAY RESULT IN A REFRIGERANT LEAK.**

- For cooling operation under low ambient temperature or any other operation under low pressure, apply silicon pad or similar to prevent freezing of the gas stop valve flare nut (see figure).

Freezing of the flare nut may cause refrigerant leak.




### How to operate the stop valve

Use hexagonal wrenches 5mm.

**Opening the valve** 1. Place the hex wrench on the valve bar and turn counter-clockwise.  
2. Stop when the valve bar no longer turns. (It is now open.)

**Closing the valve** 1. Place the hex wrench on the valve bar and turn clockwise.  
2. Stop when the valve bar no longer turns. (It is now close.)



### CAUTIONS FOR HANDLING VALVE CAP


- A seal is attached to the point indicated by the arrow. Take care not to damage it.
- Be sure to tighten the valve cap securely after operating the valves.

Valve size (mm)	Tightening torque(N·m)	Valve size (mm)	Tightening torque(N·m)
Liquid side 06.35	15.7 ± 1.5	Gas side 012.7	54.9 ± 5.4
		015.8	68.6 ± 6.8

Stop valve (cap attachment)


### CAUTIONS FOR HANDLING SERVICE PORT

- Always use a flexible charge hose with a push-rod and valve to enable recovery of remaining refrigerant in the charge hose.
- After the work, tighten the valve cap in place.
- Tightening torque:  $12.7 \pm 1.2 \text{ N}\cdot\text{m}$



### PRECAUTIONS FOR CONNECTING PIPING

- Take caution so that the refrigerant piping between the outdoor and indoor may not touch and sound proof cover and the plate as shown figure.
- If installing the outdoor unit higher than the indoor unit, caulk the space around insulation and tubes because condensation on the stop valves can seep through to the indoor unit side.



### PRECAUTIONS REGARDING INSULATION

Enhance the insulation of the refrigerant piping according to the installation conditions. If this is not done, condensation may form on the surface of the insulation. Please refer to the target values shown below.

- When the temperature and humidity conditions are  $30^\circ\text{C}$  and RH 75% or more: thickness of the insulation is 15 mm or more.
- When the temperature and humidity conditions are  $30^\circ\text{C}$  and RH 80% or more: thickness of the insulation is 20 mm or more.
- Be sure to insulate the liquid and gas sides interunit piping. It may become the cause of refrigerant leakage if it dose not insulate. (Be sure to use insulating material which can resistant.)




Insulation of interunit piping must be carried out up to the connection inside the casing. If the piping is exposed to the atmosphere, it may cause sweating or burn due to touching the piping, electric shocks or a fire due to the wiring touching the piping.

## 5 REFRIGERANT PIPING WORK (4/4)

### CAUTION FOR FLARE CONNECTION

- Please be sure to remove a flare nut with a two-dish spanner, and to bind after connection of piping using a spanner and a torque wrench.
- Refer to the following table for a flare part processing size.
- When connecting the flare nut, apply refrigerating machine oil to the flare (inside) and at first screw the nut 3 or 4 turns by hand. Coat here with ether or ester oil.
- Refer to the table for the dimensions for processing flares and for the tightening torques. (Too much tightening will end up in splitting of the flare.)
- After completing the installation, carry out a gas leak inspection of the piping connections with nitrogen and such.



PIPING SIZE (mm)	TIGHTENING TORQUE	A DIMENSIONS FOR PROCESSING FLARES (mm)	FLARE SHAPE
06.4	15.7 ± 1.5 N·m	8.9 ± 0.2	
09.5	36.3 ± 3.6 N·m	13.0 ± 0.2	
012.7	54.9 ± 5.4 N·m	16.4 ± 0.2	
015.9	68.6 ± 6.8 N·m	19.5 ± 0.2	
019.1	108.0 ± 10.8 N·m	23.8 ± 0.2	

- If a torque wrench is not available, be aware that the tightening torque may increase suddenly. Do not tighten nuts any further than to the angle as listed.
- When work is completed, be sure to check that there is no gas leakage.
  - A flare nut is bound tight with a spanner to the position whose torque with a bundle increases suddenly.
  - Only the angle of a right table is further bound tight from the position.

PIPING SIZE (mm)	FURTHER TIGHTENING ANGLE	RECOMMENDED ARM LENGTH OF TOOL
06.4	60 to 90 degrees	About 150 mm
09.5	60 to 90 degrees	About 200 mm
012.7	30 to 60 degrees	About 250 mm
015.9	30 to 60 degrees	About 300 mm
019.1	20 to 35 degrees	About 450 mm


### PRECAUTIONS WHEN BRAZING THE REFRIGERANT PIPINGS

- When brazing the refrigerant piping, carry out brazing work (NOTE 2) after substituting nitrogen for air (flow nitrogen into the piping and substitute nitrogen for air (NOTE 1) (see the drawing below)).
- 1. The proper pressure for having nitrogen flow through the piping is approximately 0.02MPa, a pressure that makes one feel like breeze and can be obtained through a pressure reducing valve.
- 2. Do not use flux when brazing refrigerant piping. Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux. (If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)



Do not use anti-oxidants when brazing the piping joints.  
(Residue can clog pipes and break equipment.)


<Do not reuse joint which have been used once already>



## 6 AIRTIGHTNESS TEST AND AIR-PURGE

### AIRTIGHTNESS TEST

- Perform a refrigerant leakage check using nitrogen gas (airtightness test) with the outdoor unit stop valve close, to make sure there are no leakage.
- For the airtightness test, raise the pressure to the design pressure in the high pressure section (4.17 MPa). For the airtightness test, the unit passes the test if the pressure in the high pressure section does not drop for 24 hours after increasing to the design pressure. A correction is required since the pressure decreases approx. 0.01Mpa when the ambient temperature of 1°C decreases.
- If the pressure drop is confirmed, perform the airtightness test again after checking and modifying the leakage points.



### AIR-PURGE

- Evacuate by the vacuum pump for more than 2 hours until the internal pressure decreases below -0.1MP. After that, leave it with -0.1MPa or less for more than one hour and confirm that the value of vacuum gauges does not increase.
- If the value of vacuum gauge increases, there is moisture inside the refrigerant piping or there are leakage points. Perform evacuation again after checking and improving the leakage points.
- NOTE
- After doing an air-purge with a vacuum pump, the refrigerant pressure may not rise even if the stop valves are opened. This is because the refrigerant piping path is closed off by the outdoor unit electronic expansion valve, etc. There are no problems if the outdoor unit is run.


## 7 CHARGING REFRIGERANT (1/2)

Be sure to use R32 as refrigerant.

### ADDITIONAL REFRIGERANT CHARGING

This model is chargeless type, so it is not necessary to charge additionally if pipe does not exceed the maximum allowable length without additional charge.

Please refer to the following table about the maximum allowable length without additional charge.

Liquid piping size	Length for which additional charging is not required	ONE INDOOR UNIT TYPE( PAIR )
ø6.35mm x t 0.8mm	10m	

When piping length exceeds its of a top table,

or only when you perform recharging, Please be correctly charged according to the following.

For future servicing, please describe the amount of additional refrigerant charging, or the amount of recharging in the collective label in accessory set or back side of right side plate.

#### • In case of additional refrigerant charging

Please select the amount of additional refrigerant which suited piping length from the following table, and add it from the service port of liquid stop valve.

Outdoor units type	Liquid piping size	Length for which additional charging is not required	Length of piping exceeding the length for which additional charging is not required, R32 additional amount (kg)
			20m
RZV/MFQ50AV16 RZV/MFQ71AV16 RZCFQ71CV16	ø6.35mm x t0.8mm	10m	20g/mtr

#### • Total refrigerant charging (When recharging due to exchange compressor, etc.)

Please charge refrigerant base on pipe length mentioned on the following table.

Outdoor units type	Liquid piping size	Piping length, R32 complete additional amount (kg)	
		5m-10 m	20m
RZVFQ50AV16	ø6.35mm	0.98	1.180
RZMFQ50AV16	ø6.35mm	0.85	1.050
RZV/MFQ71AV16,RZCFQ71CV16	ø6.35mm	1.04	1.240

## 7 CHARGING REFRIGERANT (2/2)

### Precautions when adding R32

#### Charging a cylinder with an attached siphon



Stand the cylinder upright at charging.

(There is a siphon piping inside, so that cylinder need not be upside-down to charge with liquid.)

- To prevent entry of any impurities and insure sufficient pressure resistance, always use the special tools dedicated for R410A or R32.
- The refrigerant should be charged from the service port of the liquid side stop valve.

#### Charging other cylinders



Stand the cylinder upside-down and charge.

(Turn the cylinder upside-down at charging.)

### WARNING

#### To persons incharge of piping work

- Please be sure to open a stop valve after a refrigerant charging end (if it operates shut, a compressor will break down).
- After complete charging of refrigerant carry out refrigerant leak check and heat insulation work.
- Please do not emit a refrigerant into the atmosphere indiscriminately.

## 8 ELECTRICAL WIRING WORK (1/3)

### WARNING

- Install the earth leakage circuit breaker. (A duty of installation of a earth leakage circuit breaker is imposed for an electric shock and fire accident prevention.)

The inverter is provided in the air conditioner. In order to prevent malfunction of the earth leakage breaker itself, use a breaker resistant to higher harmonics)

- Electrical wiring must be carried out by qualified personnel.
- Before obtaining access to terminal devices, all supply circuits must be interrupted.


### CAUTION

#### To the electricain

- Make sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)
- Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)
- Do not remove the thermistors or sensors when the power supply and transmission wiring are connected. (Operating the unit with the thermistors and sensors removed will break the compressor.)
- Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.
- An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.
- The wiring between the indoor unit and outdoor unit must be for 230V.
- For electric wiring work, refer to also the "WIRING DIAGRAM".
- When doing the electrical wiring, always shut off the power source before working, and do not turn on the branch switch until all work is complete.
- Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.
- Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring.
  - Gas piping.....Ignition or explosion may occur if the gas leaks.
  - Water piping.....Hard vinyl tubes are not effective earths.
  - Lightning conductor or telephone earth wiring.....Electric potential may rise abnormally if struck by a lightning bolt.
- The earth is needed in order to reduce the noise generated by the unit's inverter and influence on other appliances and to release the charged electric charge on the outdoor unit surface by leaked current.
- Do not install a phase advance capacitor for improvement of power factor. Since this unit is mounted with an inverter device, the effect of power factor improvement not only cannot be expected, but also there is a risk of the capacitor getting abnormally overheated due to harmonics.
- Be sure to use earth leakage breaker dedicated for earth leakage protection in combination with the load break switch with fuse or breaker for wiring.
- In case of three-phase. Machine, electric wiring must be connected in normal phase connection.
- For wiring, use the designated power supply wiring and connect firmly, then secure to prevent external force being exerted on the terminal attachment (power supply wiring, transmission wiring, earth wiring).
- Left-over wiring should not be wrapped and stuffed into the outdoor unit.
- To prevent the power wiring from being damaged by the knock hole edges, put it in a wiring piping or use insulated bush, etc. to protect it.
- To prevent the wiring from coming in contact with piping (particularly the high-pressure piping), secure it with the included clamping material as shown page 13.
- When wiring, form the wiring so that the front plate does not float and make sure the front plate is securely fastened.
- Fix the power supply wiring, the earth wiring and the transmission wiring by clamps as shown in the figure.


## 8 ELECTRICAL WIRING WORK (2/3)

- As shown in the following figure, please fix power supply wiring, field wiring and ground wire by clamp material.



- Carry out insulated processing of attaching an insulated sleeve.  
Power supply wiring, wiring between units and ground wire with tying as clamp as shown below.

**⚠ Do not connect power supply to terminal block of transmission wiring. All system may get damaged.**




RZVFQ50,71AV16  
RZMFQ50,71AV16  
RZCFQ71CV16

### Connection of wiring


### Precautions on wiring

- Use a round crimp-style terminal for connection to the power supply terminal board.  
In case it cannot be used due to unavoidable reasons, be sure to observe the following instruction.
- Do not connect wires of different gauge to the same power supply terminal.  
(Looseness in the connection may cause overheating.)



## 8 ELECTRICAL WIRING WORK (3/3)

When connecting wires of the same gauge, connect them according to the below figure.




- Never use the stranded wiring which is soldered.  
(Slack in the electric wiring may cause abnormal heat.)
- Use the required wirings, connect them securely and fix these wirings so that external force may not apply to the terminals.
- Use a proper screw driver for tightening the terminal screws.  
If an improper screw driver is used, it may damage the screw head and a proper tightening cannot be carried out.
- If a terminal is over tightened, it may be damaged. Refer to the table shown below for tightening torque of terminals.

Tightening torque (N·m)	
M4 (Wire between units terminal board)	1.50±0.30
M4 (Power supply terminal board)	1.50±0.30
M4 (Ground wire between units)	1.65±0.25
M5 (Ground wire between units)	3.55±0.50


### Precautions on connecting terminal of grounding

- Ground wiring should be taken out from the cut out section of a cup washer.  
(Otherwise, contact of ground wiring is inadequate and it is ineffective.)



### WIRING OF POWER SUPPLY AND THE UNITS

For details on the wiring of the indoor unit and wiring between units refer to the installation manual of the indoor unit.



#### • SPECIFICATIONS OF STANDARD WIRING COMPONENTS

Outdoor Unit	Power supply		Wire type of wiring between the units
	Wire Type (*)	Size	
RZVFQ50 / 71AV16 RZMFQ50 / 71AV16 RZCFQ71CV16	H05VV-U3G	Wiring size and length must comply with local codes or [IEC 60335-1 (Table 11)]	H05VV-U4G2.5

(\*) Only in protected piping, use H07RN-F when protected pipes are not used.

(Supply cords shall not be lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC 57))

### NOTES

- Select and install the power supply wiring in accordance with [IEC 60335-1 (Table 11)] or local laws and regulations. The maximum current of the outdoor and indoor units are shown on each name plate.
- When installing wiring in a location that can easily come in contact with people, be sure to install an earth leakage breaker coping with high harmonics to prevent electric shock.
- Breaker type and capacity shall be selected in accordance with local laws and regulations.

### CAUTION

#### TO PERSONS INCHARGE OF ELECTRICAL WIRING WORK

- Do not operate the unit until the refrigerant charging is completed. (Running it before the piping is ready will break the compressor.)

## 9 CHECK ITEMS BEFORE TEST OPERATION AND FIELD SETTINGS

### PRE-RUN CHECKS

	ITEM TO CHECK	CHECK
Power supply Wiring	Is the wiring as mentioned on the wiring diagram? make sure no wiring has been forgotten and that there are no missing phases or reverse phases.	
	Does wiring between units put in and changed in continuation installation?	
	Is the unit properly grounded?	
	Are any of the wiring attachment screws loose?	
	Is the insulation resistance at least $1M\Omega$ ? <ul style="list-style-type: none"> <li>• Use a 500V mega-tester when measuring insulation</li> <li>• ※ Do not use a mega-tester for circuits which except 230V.</li> </ul>	
	Is an earth leakage circuit breaker used a current operated type which is compatible to the higher harmonic wave?	
Refrigerant piping	Does the earth leakage circuit breaker have appropriate rated current?	
	Is the size of the piping appropriate?	
	Is the insulation material for the piping attached securely?	
	Are both the liquid and gas pipes insulated?	
Extra refrigerant	Are the stop valves for both the liquid side and the gas side open?	
	Did you write down the extra refrigerant and the refrigerant piping length?	
Indoor unit	Is the indoor unit fully installed? When the test run is started, the fan automatically begins turning.	

### WARNING

- When a power supply is switched on, when you leave from the outdoor unit, be sure to close the cover plate.  
(It becomes the cause of an electric shock).

## 10 TEST OPERATION


### WARNING

- Never perform a test operation with the discharge piping thermistor(R2T) condenser thermistor removed, as this might break the compressor.
- If the technician must leave the outdoor unit for some reason, switch places with another installation technician or close the plates. (It may cause electric shocks.)

#### HOW TO TEST OPERATION

After the indoor and outdoor unit installation, be sure to perform the test operation in accordance with the following procedure.

1. Open the stop valve cover and check that the liquid and gas sides of the stop valves are open.  
<Be sure to close the front plate before the operation (there is a risk of electric shock)>  
Note: After doing an air-purge with a vacuum pump, the refrigerant pressure may not rise even if the stop valves are opened. This is because the refrigerant piping path is closed off by the outdoor unit electronic expansion valve, etc. There are no problems if the unit is run.
2. Attach the stop valve cover to the outdoor unit and turn the power on at least 6 hours before operating the outdoor unit to protect the compressor.
3. Set to COOLING operation with the remote controller.
4. Perform the test operation.
5. Operate normally
6. Confirm function of the indoor and outdoor units according to the operation manual.



### CAUTION

#### To persons incharge of piping work and electric work

- Please check having attached the front board and the piping cover after a test run end when giving production over to customer.

## 11.CAUTION (RZVFQ50,71AV16,RZCFQ71CV16)

THIS IS NECESSARY FOR AFTER SERVICE, SO PLEASE REQUEST CUSTOMER TO KEEP THIS PAPER.

### CAUTION (NEW REFRIGERANT R32 SERIES)



**WARNING**



**ELECTRIC SHOCK CAUTION**

#### Caution about electric shock when do service inspection.

1. After intercept power supply, do not open outside panel for 10 minutes.
2. Follow manufacturing label on electric box cover, please take off outdoor fan motor connector to confirm voltage and body static electricity discharge.

#### General caution items when do service inspection

##### Caution to confirm compressor and fan motor running

Do not directly connect power input (3 Phase 50Hz) to compressor and fan motor. (If not connect to print board (PCB), compressor and fan motor will be burned out.)

##### Caution when recharge refrigerant

1. To prevent the mixing of impurities, pressure resistance and contamination mix, please use manifold gauge especially for R32.
2. Make sure to do Nitrogen blow if brazing when flare connection. Apply ether oil or ester oil at inside flare only.
3. Do air tight test at 4.17MPa
4. Do dry vacuum, make sure to charge refrigerant in liquid condition from liquid side service port. (Compressor will be broken if charge from gas side service port.)

##### Caution when use outdoor PCB

Make sure to touch earth terminal and earthed metal before touch pcb, to prevent electric shock.

##### Caution when break down diagnosis from letter code in remote control

Please refer to service guide or outdoor unit installation manual.

### Charging refrigerant

#### Charging the system with refrigerant

(For more information such as calculation method of additional refrigerant charge, additional charge method, refrigerant charge caution, refer to the Installation Manual and Technical Guide.)



- For refrigerant charge, be sure to charge from the service port of the liquid side stop valve in liquid states. (If you charge from the service port of the gas side stop valve, it may break the compressor.)
- Never charge other than the specified refrigerant. (It may cause fire and bursting.)

Table 1. Chargeless piping length

Liquid piping size	Pipe length which is not required additional charging
Φ6.35 x 10.8mm	10m

#### 1. In case of additional refrigerant charging

Please add refrigerant amount according to the following table.

Outdoor	Liquid piping size	Pipe length which is not required additional charging	Additional ref. amount above 10mtr.	Max. Pipe Length
RZVFQ50,71AV16,RZCFQ71CV16	Φ6.35 x 10.8mm	10m	20gm/mtr	20mtr

#### 2. Total refrigerant charging (Details please see service guide)

1. Please recover the refrigerant until becoming 0.09 Mpa (gauge pressure: -0.011MPa) or less by the refrigerant recovery machine from stop valve service port (liquid·gas side) at the same time.
2. Exchange service parts · Modify leak point.
3. Perform airtightness test air-purge.

Please refer installation manual of outdoor unit or service guide.

4. Charge refrigerant amount selected by table 2 from liquid stop valve service port.

**Caution** Do not turn on power during evacuation. The motor may be damaged due to vacuum discharge.

Table 2. Charge refrigerant amount (After a leak, etc...)

Outdoor	Liquid piping size	Piping length, R32 complete additional amount (g)	
		5~10m	20m
RZVFQ50AV16	Φ6.35 x 10.8mm	980g	1180g
RZVFQ71AV16,RZCFQ71CV16	Φ6.35 x 10.8mm	1040g	1240g

#### • Making a record of the added refrigerant charge amount

Be sure to record the piping length and added refrigerant charge amount or refrigerant recharge amount with an oil-based or other indelible marker so the figures will not fade over time. This information is necessary for after service and maintenance.

Liquid piping size	Φ6.35 mm x 10.8mm
Refrigerant piping length	m
Additional refrigerant charging	kg
Recharge of refrigerant	kg

### How to execute a pumping-down


(for example, when moving or reinstalling an indoor or outdoor unit)

The outdoor unit is equipped with a high pressure switch to protect the compressor.  
**Caution** Never short-circuit the high pressure switch during pump-down operation.

- It is not allowed to let the refrigerant out into the air. The refrigerant should be recovered completely.
- Although pumping-down operation allows most of the refrigerant to be recovered in a short period of time, some refrigerant will remain inside the indoor unit and the refrigerant piping. Using a refrigerant recovery machine, recover remaining refrigerant from the stop valve service port until the pressure falls to 0.09MPa (gauge pressure: -0.011MPa) or less.
- Be sure to execute the pumping-down before refrigerant piping and wiring is taken off.

#### For pumping-down operation

1. Please follow the [caution about electric shock when service inspection] which attached on Top panel (Caution : Do not take off the connector X106A)
2. To prevent electric shock, please protect power input terminal block by insulation sheet refer to below figure.
3. Turn on the power supply and carry out pumping-down operation according to the following procedure.




**Caution** To prevent electric shock when inspection, protect by use insulation sheet on power input terminal block and print board (A2P)

#### For pumping-down operation procedure

1. Remove the valve caps from the liquid stop valve and the gas stop valve.
2. By Long Pressing Switch button (SW1) on PCB for 5 sec then unit will go on pump down operation & LED continuous fast blinking on PCB (A2P).
3. Close the liquid stop valve with a hexagonal wrench.
4. After 2 to 3 minutes, close the gas stop valve and Turn off the main power supply this will automatically deactivate the Pump Down operation.

Pump down operation is allowed on below 2 conditions:-

- (1)The outdoor unit is not abnormal and not in the 3-minute standby mode.
- (2)The outdoor unit is not operating.



**Caution** When installing and relocating, be sure to install the earth leakage breaker to protect from the electric shock disaster and fire due to leakage of electricity. For installing the earth leakage breaker, request to the qualified electrician.

**DAIKIN AIRCONDITIONING INDIA PVT. LTD.**

12th Floor, Building No. 9, Tower A,  
DLF Cyber City, DLF Phase - III  
Gurgaon - 122002, Haryana (India)  
Tel : +91-124-4555444  
Fax: +91-124-4555333



# SPLIT SYSTEM AIR CONDITIONER INSTALLATION MANUAL

[For Outdoor unit] New Refrigerant (R32) Series

RZFQ90AV16	RZMFQ90AV16
RZFQ100AV16	RZMFQ100AV16
RZFQ125AY16	RZVFQ125AY16
RZFQ140AY16	RZVFQ140AY16
RZVFQ90AV16	RZMFQ125AY16
RZVFQ100AV16	RZMFQ140AY16
RZCFQ36CV1	RZCFQ90CV16
	RZCFQ48CY1

## CONTENTS

※ SAFETY PRECAUTIONS .....	19
1. BEFORE INSTALLATION .....	21
2. SELECTING INSTALLATION SITE .....	21
3. INSTALLATION SERVICE SPACE .....	23
4. PRECAUTIONS ON INSTALLATION .....	25
5. REFRIGERANT PIPING WORK .....	25
6. AIRTIGHTNESS TEST AND AIR-PURGE .....	28
7. CHARGING REFRIGERANT .....	29
8. ELECTRICAL WIRING WORK .....	30
9. CHECK ITEMS BEFORE TEST OPERATION .....	33
10. TEST OPERATION .....	34
11. CAUTION .....	35

## SAFETY PRECAUTIONS



Read the precautions in this manual  
carefully before operating the unit.



This appliance is filled with R32.



### WARNING THERE IS A RISK OF EXPLOSION OR FIRE

- Do not mix air in the refrigerating cycle during pump down operation.
- Do not use oxygen for air tight test.
- Do not use refrigerant other than the specified one or flammable material ( e.g. propane ) in the refrigerant cycle. They may cause over pressure in the refrigerating cycle and result in explosion, fire or injury. Our company assumes no responsibility for failure or malfunction caused by filling or mixing of anything other than the specified refrigerant.



### CAUTION ABOUT ISOLATING RESISTANCE OF COMPRESSOR

If refrigerant accumulates in the compressor after completing installation, the insulation resistance can drop, but if it is at least 1 MΩ, then the unit will not break down.

- Connect the power supply to the unit and after 6 hours check if the insulation resistance of the compressor rises. (Energize and heat the compressor to vaporize the refrigerant accumulated in the compressor.)
- If the earth leakage breaker actuates, check if the earth leakage breaker is equipped with a device to cope with high harmonics. To prevent wrong actuation of the earth leakage breaker due to the inverter, make sure to adopt an earth leakage breaker equipped with a device to cope with high harmonics.

1. Please make sure to confirm that R32 (new refrigerant) is used in installation work in advance.  
(It may not operate normally, if refrigerant type is different.)
2. The refrigerant R32 requires that strict precautions be observed for keeping the system clean, dry and tightly sealed.
  - Clean and dry  
Strict measures must be taken to keep impurities (Including SUNISO oil and other mineral oils as well as moisture) out of the system.
  - Tightly sealed  
R32 contains no chlorine, does not destroy the ozone layer and so does not reduce the earth's protection against harmful ultraviolet radiation. R32 will contribute only slightly to the greenhouse effect if released into the atmosphere. Therefore, sealing tightness is particularly important in installation.  
Carefully read the chapter **5 REFRIGERANT PIPING WORK** and strictly observe the correct procedures.
3. The design pressure of this unit : High/Low pressure area are shown in the right table.  
(Units: MPa)

Outdoor Unit	Design pressure	Cooling
RZMVFQ90,100AV16 RZMVFQ125,140AY16 RZFQ90,100AV16 RZFQ125,140AY16 RZCFQ90CV16 RZCFQ36CV1,RZCFQ48CY1	High	4.15
	Low	2.21

## READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION

- This manual classifies the precautions into **WARNINGS** and **CAUTIONS**.

Be sure to follow all the precautions below. They are all important for ensuring safety.

 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

- After the installation is completed, test the air conditioner and check if the air conditioner operates properly. Give the user adequate instructions concerning the use and cleaning of the indoor unit according to the operation manual. In particular, make sure to explain with regard to "SAFETY PRECAUTIONS" and "Not malfunction of the air conditioner". Ask the user to keep this manual and the operation manual together in a handy place for future reference.
- This air conditioner comes under the term "appliances not accessible to the general public".

### **WARNING**

- Ask your local dealer or qualified personnel to carry out installation work. Improper installation may result in water leakage, electric shocks or a fire.
- Perform installation work in accordance with this installation manual. Improper installation may result in water leakage, electric shocks or a fire.
- Consult your local dealer regarding what to do in case of refrigerant leakage. When the indoor unit is installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen deficiency.
- Be sure to use only the specified parts and accessories for installation work. Failure to use the specified parts may result in the air conditioner fall down, water leakage, electric shocks, a fire, etc.
- Install the air conditioner on a foundation that can withstand its mass. Insufficient strength may result in the air conditioner fall down and causing injury.
- Carry out the specified installation work in consideration of strong winds, typhoons, or earthquakes. Improper installation may result in an accident such as the air conditioner falling.
- Make certain that all electric work is carried out by qualified personnel according to the applicable legislation (note 1) and this installation manual, using a separate circuit. In addition, even if the wiring is short, make sure to use a wiring that has sufficient length and never connect additional wiring to make the length sufficient. Insufficient capacity of the power supply circuit or improper electric construction may lead to electric shocks or a fire.  
(note 1) Applicable legislation means "All international, national and local directives, laws, regulations and/or codes which are relevant and applicable for a certain product or domain."
- Earth the air conditioner. Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring. Incomplete earthing may cause electric shocks or a fire. 
- Be sure to install an earth leakage circuit breaker. Failure to do so may cause electric shocks or a fire.
- The appliance must be stored in a room without continuously operating ignition sources (for example : open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerant may not contain an odour.
- Comply with national gas regulations.
- Be sure to switch off the unit before touching any electrical parts. Touching a live part may result in electric shocks.
- Make sure that all wiring is secure, using the specified wiring and ensuring that external forces do not act on the terminal connections or wiring. Incomplete connection or fixing may cause overheating terminals or fire.
- When wiring between the outdoor and indoor units, and wiring the power supply, from the wiring orderly so that the structural parts such as a cover can be securely fastened. If the cover is not in place, electric shocks or a fire may be caused.
- Do not add wiring. It may result in heat generation. Electric shocks or fire.
- When installing or relocating the air conditioner, be sure to bleed the refrigerant circuit to ensure, it is free of air, and use only the specified refrigerant (R32). The presence of air or other foreign matter in the refrigerant circuit causes abnormal pressure rise, which may result in equipment damage and even injury.
- If refrigerant gas leaks during installation work, ventilate the area immediately. Toxic gas may be produced if refrigerant gas comes into contact with a fire.
- After completing the installation work, check to make sure that there is no leakage of refrigerant gas. Toxic gas may be produced if refrigerant gas leaks into the room and comes into contact with a source of a fire, such as a fan heater, stove or cooker.
- Never directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.
- Do not stand on the outdoor unit or put things on it. The unit may fall down or drop, and cause accidents.
- Do not charge any refrigerant into the refrigeration cycle other than the designated refrigerant. It may cause an explosion or a fire due to leakage or a burst due to abnormally high pressure in the refrigeration cycle.
- Do not extend wiring on the way. It may cause heat generation, electric shocks or fire.
- At the installation work, install the refrigerant piping firmly before operating the compressor. If the compressor is operated without installing firmly and the service valve is in open condition, it sucks the air, etc., and the pressure inside the refrigerant circle becomes abnormally high. It may cause injury and breakage.
- At pump down work, stop the compressor before removing the refrigerant piping. If removing the refrigerant piping when the compressor is operated with its service valve in open condition, it sucks the air, etc., and the pressure inside the refrigerant circle becomes abnormally high, which may cause injury and breakage.
- When flared joints are reused indoors, the flare part shall be re-fabricated.

## CAUTION

- Install drain piping according to this installation manual to ensure good drainage, and insulate the piping to prevent condensation. Improper drain piping may cause water leakage, make the furniture get wet.
- Install the indoor and outdoor units, power cord and connecting wires at least 1 meter away from televisions or radio to prevent picture interference and noise. (Depending on the incoming signal strength, a distance of 1 meter may not be sufficient to eliminate noise.)
- Install the indoor unit as far as possible from fluorescent lamps. If a wireless remote controller kit is installed, the transmission distance of the remote controller may be shorter in a room where an electronic lighting type (inverter or rapid start type) fluorescent lamp is installed.
- In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- Disposal requirements**  
Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.
- Only qualified personnel can handle, fill, purge and dispose of the refrigerant.
- Do not install the air conditioner in places such as following:
  - Where there is mist of oil, oil spray or vapor for example a kitchen.  
Resin parts may deteriorate, and cause them to fall out or water to leak.
  - Where corrosive gas, such as sulfuric acid gas, is produced.  
Corrosion of copper pipings or brazed parts may cause the refrigerant to leak.
  - Where there is machinery which emits electromagnetic waves. Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
  - Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables, such as thinner or gasoline, are handled.  
If the gas should leak and remain around the air conditioner, it may cause ignition.
  - The place that the vibration or the voltage fluctuation give influence. Vehicles, vessels, etc.  
The vibration may cause a damage and the voltage fluctuation may cause an abnormal operation.
  - Where small animals may build a nest, fallen leaves are accumulated, or weeds are overgrown.  
If small animals touch the electrical parts inside, this may cause malfunction, smokes or a fire.





■ Important information regarding the refrigerant used.  
This product contains fluorinated greenhouse gases. Do not vent gases into the atmosphere.  
Refrigerant type: R32  
GWP<sup>(1)</sup> value: 675  
<sup>(1)</sup>GWP = global warming potential  
• The refrigerant quantity is indicated on the unit name plate.

## 1 BEFORE INSTALLATION

- Do not throw away accessories for installation.

### HANDLING

As shown in the figure, bring the unit slowly by grabbing the left and right grips.  
(Take care not to let hands or objects come in contact with rear fins.)



### INSTALLATION CONSTRUCTION ACCESSORIES


Be sure only to use accessories made by DAIKIN which are specifically designed for use with the equipment.

### CAUTION

Work in a team of at least two people when carrying the outdoor unit.

## 2 SELECTING INSTALLATION SITE (1/2)

- Select the installation location that meets the following conditions and get approval of the customer.
  - Places where is no risk of flammable gas leakage.
  - Places where the outdoor unit does not bother next-door neighbors.
  - Safe places where can withstand the unit's mass and vibration and where the air conditioner can be installed level.
  - Places where are well-ventilated and where servicing space can be well ensured.  
The minimum required space is shown in chapter **3 INSTALLATION SERVICE SPACE**.
  - Where the piping length between the indoor and the outdoor units is ensured within the allowable piping length. (Please see chapter **5 REFRIGERANT PIPING WORK**)
  - Do not allow wind from the same direction to blow frequently toward the outlet or inlet of the outdoor unit.  
If the wind is likely to blow as mentioned above, make sure to keep a sufficient service space and install a wind protective shield.




Inverter air conditioners may cause noise to occur in electrical appliances. As shown in the right drawing, select an installation site well away from radios, PCs, and stereos.

**CAUTION** Especially in the areas where the incoming signal strength is weak, keep the indoor remote controller 3 meter or more from electrical appliances. Put the power supply and transmission wiring in a metal piping and ground the metal piping.

## 2 SELECTING INSTALLATION SITE (2/2)

### ⚠ CAUTION

1. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
2. When installing the unit in a place exposed to strong wind, pay special attention to the following.  
Strong winds of 5 m/sec or more blowing against the outdoor unit's air outlet causes short circuit (suction of discharge air) and this may have the following consequences:
  - Deterioration of the operational capacity.
  - Disruption of operation due to rise of high pressure.
  - When a strong wind blows continuously on the face of the unit, the fan can start rotating very fast until it breaks.  
Refer to the figures for installation of this unit in a place where the wind direction can be foreseen.
3. Following the installation place, it is expected that the influence of the strong wind is great.
  - The flat area which receives the adverse wind such as typhoon directly since there is no obstacles such as buildings and mountains. (Including coast line, shoreline of lake and mountain region.)
  - The installation place that no obstacles around the outdoor unit to prevent the adverse wind, for example, walls and buildings that are higher than the applicable outdoor unit, etc.  
Please take measures when installing especially on a rooftop.
  - Since the outdoor unit may fall down, attach the fixture for preventing overturning (option).



4. Prepare a water drainage channel around the foundation, to drain waste water from around the unit.
5. If the water drainage of the unit is not easy, please build up the unit on a foundation of concrete blocks, etc.  
(the height of the foundation should be maximum 150 mm).
6. If you install the unit on a frame, please install a waterproof plate within 150 mm of the underside of the unit in order to prevent the invasion of water from the lower direction.


## 3 INSTALLATION SERVICE SPACE (1/3)

- The installation servicing spaces shown in these drawings are based on the outdoor unit inlet area temperature of 35°C(DB) for COOLING operation.  
If the planned inlet area temperature exceeds 35°C(DB), or if the heat load of all outdoor units is increased significantly and exceeds the maximum operating capacity, secure a larger space than that indicated by the inlet dimensions in these drawings.
- For installation, consider both pedestrian and air flow paths and choose a suitable pattern from these drawings to match the space available field. (If the number of units to be installed exceeds the patterns in these drawings, consider there is nothing short-circuits.)
- Regarding the front space, position the units with consideration to the space required for the refrigerant piping work.  
(Consult your dealer if the work conditions do not match those in the drawings.)
- Secure appropriate space when using a side piping outlet.


#### STAND-ALONE INSTALLATION

##### No obstacle above


1. Obstacle on the suction side only



2. Obstacle on both sides and suction side, too




3. Obstacle on the discharge side only




##### Obstacle above, too


1. Obstacle on the suction side, too



2. Obstacle on both sides and suction side, too



3. Obstacle on the discharge side only, too




### 3 INSTALLATION SERVICE SPACE (2/3)

(Units: mm)

#### When there are obstacles on both suction and discharge sides

##### Pattern 1 When the obstacles on the discharge side is higher than the unit

1. No obstacle above (There is no limit for the height of obstructions on the suction side.)




2. Obstacle above, too

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	750 or more
	$0.5H < L \leq H$	1000 or more
$L > H$	Set the stand as: $L \leq H$	


- Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.

• To secure service space, more than 250 mm on the right side of each unit is necessary.



##### Pattern 2 When the obstacle on the discharge side is lower than the unit

1. No obstacle above (There is no limit for the height of obstructions on the suction side.)




2. Obstacle above, too

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	100 or more
	$0.5H < L \leq H$	100 or more
$L > H$	Set the stand as: $L \leq H$	


- Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.



#### SERIES INSTALLATION (2 OR MORE)

##### No obstacle above


1. Obstacle on the suction side and both sides



- To secure service space, more than 250 mm on the right side of each unit is necessary.


(Units: mm)

2. Obstacle on the discharge side only




##### Obstacle above, too

1. Obstacle on the discharge side



2. Obstacle on the suction side and both sides




### 3 INSTALLATION SERVICE SPACE (3/3)

#### When there are obstacles on both suction and discharge sides

- To secure service space, more than 250 mm on the right side of each unit is necessary.

##### Pattern 1 When the obstacles on the discharge side is higher than the side unit

1. No obstacle above (There is no limit for the height of obstructions on the suction side.)





2. Obstacle above, too

The relations between H, A and L are as follows.

	L	A
L ≤ H	$L \leq 0.5H$	1000 or more
	$0.5H < L \leq H$	1250 or more
L > H	Set the stand as: $L \leq H$	

- Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.




(Units: mm)

##### Pattern 2 When the obstacle on the discharge side is lower than the unit

1. No obstacle above (There is no limit for the height of obstructions on the suction side.)

The relations between H, A and L are as follows.

L	A
$L \leq 0.5H$	150 or more
$0.5H < L \leq H$	200 or more




2. Obstacle above, too

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	150 or more
	$0.5H < L \leq H$	200 or more
$L > H$	Set the stand as: $L \leq H$	

- Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.




(Units: mm)



#### DOUBLE-DECKER INSTALLATION

- Do not stack more than two unit.
- The drain piping construction size of upper side outdoor unit is needed about 100 mm.
- In side extraction, please provide the space of piping.

##### 1. Obstacle on the discharge side




##### 2. Obstacle on the suction side



#### MULTIPLE ROWS OF SERIES INSTALLATION (ON THE ROOFTOP, ETC.)


##### 1. One row of stand-alone installation



##### 2. Rows of series installation (2 or more)

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	150 or more
	$0.5H < L \leq H$	200 or more
$L > H$	Can not be installed	



## 4 PRECAUTIONS ON INSTALLATION


- Check the strength and level of the installation ground so that the unit will not cause any operating vibration or noise after installed.
- In accordance with the foundation drawing in **Fig. 1**, fix the unit securely by means of the foundation bolts. (Prepare 4 sets of M8 or M10 foundation bolts, nuts and washers each which are available on the market.)
- It is best to screw in the foundation bolts until their length are 20 mm from the foundation surface.
- Fix the outdoor unit to the foundation bolts using nuts with resin washers. (See **Fig. 1**) If the coating on the fastening area is stripped off, the nuts rust easily.

### <Drain work disposal>

- If drain work disposal from the outdoor unit causes trouble, (for example, if the drain water may splash on people) provide the drain piping by using of the drain plug (optional).
- Then, coat the area around the bored holes with rust preventive coating to cover the metal exposure.
- Make sure the drain works properly.

### <Installation method of fixture for preventing overturning>

- If steps need to be taken to prevent the unit from tipping over, use the fixture for preventing overturning (option) (Wiring system)



## 5 REFRIGERANT PIPING WORK (1/4)

### ⚠ CAUTION

#### To plumbing person

- Important information regarding the refrigerant used. This product contains fluorinated greenhouse gases. Do not vent gases into the atmosphere.  
GWP (global warming potential) of R32 refrigerant type = 675
- Use R32 as additional for charging.
- Do not use flux when brazing refrigerant piping.  
Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux. (If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)
- After chapter **7 CHARGING REFRIGERANT** is completed, be sure to open the stop valves before performing **9 LOCAL SETUP**. (Operating the unit with the valve shut will break the compressor.)

#### 5-1 INSTALLATION TOOLS

Be sure to use the dedicated tools to ensure sufficient pressure resistance and prevent the entry of any impurities.

Manifold gauge	To ensure sufficient pressure resistance and prevent the entry of any impurities (mineral oils such as Suniso oil and liquids), use the R410A or R32 dedicated item (the screw specifications for R410A or R32 differ).
Vacuum pump	Be extremely careful not to flow the pump oil backward to inside the piping when the pump is stopped. Use a pump which enables vacuuming to -0.1 MPa (-755mmHg) of the gauge pressure.

#### 5-2 SELECTION OF PIPING MATERIAL

- Use the piping whose inside and outside are clean and with no harmful substances for use such as sulphur, oxide, dust, dust from cutting, grease, or liquid (contamination) is attached.
- For the refrigerant piping, use the following material.

**Material:** Deoxidised phosphorous seamless copper piping

**Temper grade:** Use piping with temper grade in function of piping diameter as listed in the table on section **5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH**

**Size:** Decide based on section **5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH**

**Thickness:** Comply with applicable legislation. The minimal piping thickness for R32 piping must be in accordance with the table on section **5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH**

- Be sure to perform piping work using measurements within the maximum allowable length and height difference described on section **5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH**

## 5 REFRIGERANT PIPING WORK (2/4)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

### 5-3 CARE OF PIPE

- Prevent contamination or moisture from getting into the piping.
- Pay special attention when running the copper piping through the through-hole or when leading the edge of the piping outside the room.
- Refrigerant piping must be protected from physical damage. Install a plastic cover or equivalent.

PLACE	INSTALLATION PERIOD	PROTECTION METHOD	PLACE	INSTALLATION PERIOD	PROTECTION METHOD
OUTDOOR	More than a month	Pinch the pipe	INDOOR	Unquestioned	Pinch or tape pipe
	Less than a month	Pinch or tape pipe			

### 5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

- Maximum allowable piping length means the maximum length of liquid side piping or gas side piping.
- Equivalent length is the pressure loss due to L joints, traps, and so on along the refrigerant piping converted to a straight piping length of the same size and added to the overall value. Please see the Engineering Data for calculation of equivalent length.
- Please give the vertical interval between the indoor and outdoor as 30 m or less.

#### ⚠ CAUTION

- This unit is chargeless specification. Due to chargeless length and allowable piping length will be different depend on field pipe size.

#### Piping bend radius

Piping diameter	Pipe thickness (material)	Bend radius
Ø 9.5mm	0.8 mm (C1220T-O, Type O)	30mm or more
Ø 15.9mm	1.0 mm (C1220T-O, Type O)	50mm or more

#### Refrigerant pipe size and chargeless length





Outdoor unit type	Liquid pipe size (type)	Chargeless length
RZFQ90,100AV16,RZV/MFQ90,100AV16,RZV/MFQ125,140AY16,RZV/MFQ125,140AY16,RZCFQ90CV16,RZCFQ36CV1,RZCFQ48CY1	Ø9.5 mm x t 0.8 mm (type o)	15m

#### ⚠ WARNING

When flared joints are reused indoors, the flared part shall be re-fabricated.

#### ⚠ CAUTION


- Use dedicated piping cutters and flaring tools for R410A or R32.
- When making a flare connection, apply ether or ester oil only to the flare inner surface.
- Use only the flare nuts attached to the unit. If other flare nuts are used, it may cause refrigerant leakage. To prevent contamination, dust or moisture from getting into the piping, take measures such as pinching or taping the piping.




## 5 REFRIGERANT PIPING WORK (3/4)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

**Back side (rear) connection** Remove the piping outlet plate (rear) for connection.




**Side (lateral) connection** Remove the piping outlet plate (front) for connection.



**CAUTION**

**Preventive against small animals entering into the casing**  
Fill up the space with putty or thermal insulation (field supply) where the piping through as shown **Fig. 6**.  
(If small animals touch the electrical parts inside, this may cause malfunction, smokes or a fire.)




**Fig. 6**

### CAUTIONS FOR HANDLING STOP VALVE

**DO NOT OPEN THE STOP VALVE UNTIL  
CHARGING REFRIGERANT FINISHED.**

- The stop valves for indoor-outdoor connecting piping are closed at shipment from the factory.
- Since the side boards may be deformed if only a torque wrench is used when loosening or tightening flare nuts, always lock the stop valve with a wrenches and then use a torque wrench.

Refrigerant piping must be protected from physical damage. Install a pipe cover or equivalent.



When tightening the flare of the stop valves, make sure to tighten by the rated torque. The rated torque is shown on **CAUTION FOR FLARE CONNECTION** (Following)

**DO NOT APPLY FORCE ON THE VALVE CAP, THIS MAY RESULT IN A REFRIGERANT LEAK.**

- For cooling operation under low ambient temperature or any other operation under low pressure, apply silicon sealant or similar to prevent freezing of the gas stop valve flare nut (see figure).

Freezing of the flare nut may cause refrigerant leak.

#### How to operate the stop valve

Use hexagonal wrenches 4mm and 6mm.

**Opening the valve**

- Place the hex wrench on the valve bar and turn counter-clockwise.
- Stop when the valve bar no longer turns. (It is now open.)

**Closing the valve**

- Place the hex wrench on the valve bar and turn clockwise.
- Stop when the valve bar no longer turns. (It is now close.)

### CAUTIONS FOR HANDLING VALVE CAP


- A seal is attached to the point indicated by the arrow. Take care not to damage it.
- Be sure to tighten the valve cap securely after operating the valves.

Valve size (mm)	Tightening torque (N·m)	Valve size (mm)	Tightening torque (N·m)
Liquid side Ø9.5	15.0 ± 1.5	Gas side Ø15.9	25.0 ± 2.5

Silicon sealant  
(Make sure there is no gap)

### CAUTIONS FOR HANDLING SERVICE PORT

- Always use a flexible charge hose with a push-rod and valve to enable recovery of remaining refrigerant in the charge hose.
- After the work, tighten the valve cap in place.
- Tightening torque:  $12.7 \pm 1.2 \text{ N}\cdot\text{m}$




## 5 REFRIGERANT PIPING WORK (4/4)

### PRECAUTIONS FOR CONNECTING PIPING


(RZV/MFQ125, 140AY16/RZFQ125,140AY16,RZCFQ48CY1)

- Take of a sealing for transportation before connect the connecting pipe.
- Take caution so that the refrigerant piping between the outdoor and indoor may not touch and sound proof cover and the plate as shown figure.
- If installing the outdoor unit higher than the indoor unit, caulk the space around insulation and tubes because condensation on the stop valves can seep through to the indoor unit side.



### CAUTION FOR FLARE CONNECTION

- Be sure to remove the flare nuts using two spanners. Then after the piping connection, tighten them using a spanner and torque wrench.
- Refer to the following table for a flare part processing size.
- When connecting the flare nut, apply refrigerating machine oil to the flare (inside) and at first screw the nut 3 or 4 turns by hand. Coat here with ether or ester oil.
- Refer to the table in indoor installation manual (Refrigerant Piping Work) for the dimensions for processing flares and for the tightening torques. (Too much tightening will end up in splitting of the flare.) After completing the installation, carry out a gas leak inspection of the piping connections with nitrogen and such.
- If a torque wrench is not available, be aware that the tightening torque may increase suddenly. Do not tighten nuts any further than to the angle as listed.
- When work is completed, be sure to check that there is no gas leakage.
  1. A flare nut is bound tight with a spanner to the position whose torque with a bundle increases suddenly.
  2. Only the angle of a right table is further bound tight from the position.



PIPING SIZE (mm)	FURTHER TIGHTENING ANGLE	RECOMMENDED ARM LENGTH OF TOOL
Ø9.5	60 to 90 degrees	About 200 mm
Ø15.9	30 to 60 degrees	About 300 mm

### PRECAUTIONS WHEN BRAZING THE REFRIGERANT PIPINGS

<Do not reuse joint which have been used once already>


- When brazing the refrigerant piping, carry out brazing work (NOTE 2) after substituting nitrogen for air (flow nitrogen into the piping and substitute nitrogen for air (NOTE 1) (see the drawing below)).

#### NOTES

- The proper pressure for having nitrogen flow through the piping is approximately 0.02MPa, a pressure that makes one feel like breeze and can be obtained through a pressure reducing valve.
- Do not use flux when brazing refrigerant piping. Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux. (If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)




Do not use anti-oxidants when brazing the piping joints.  
(Residue can clog pipes and break equipment.)



## 6 AIRTIGHTNESS TEST AND AIR-PURGE

### AIRTIGHTNESS TEST

- Perform a refrigerant leakage check using nitrogen gas (airtightness test) with the outdoor unit stop valve close, to make sure there are no leakage.
- For the airtightness test, raise the pressure to the design pressure in the high pressure section (4.15/4.17 MPa). For the airtightness test, the unit passes the test if the pressure in the high pressure section does not drop for 24 hours after increasing to the design pressure. A correction is required since the pressure decreases approx. 0.01MPa when the ambient temperature of 1°C decreases.
- If the pressure drop is confirmed, perform the airtightness test again after checking and modifying the leakage points.



### AIR-PURGE

- Evacuate by the vacuum pump for more than 2 hours until the internal pressure decreases below -0.1MPa. After that, leave it with -0.1MPa or less for more than 1 hour and confirm that the value of vacuum gauges does not increase.

## PRECAUTIONS FOR CONNECTING PIPING

- If installing the outdoor unit higher than the indoor unit, caulk the space around insulation and tubes because condensation on the stop valves can seep through to the indoor unit side.



Do not use a charging hose of which pressing stick is slipped out from the center. (It may cause refrigerant leakage due to deformation of the valve stem of the service port)


## PRECAUTION REGARDING INSULATION

Enhance the insulation of the refrigerant piping according to the installation conditions. If this is not done, condensation may form on the surface of the insulation. Please refer to the target values shown below.

- When the temperature and humidity conditions are 30°C and RH 75% or more: thickness of the insulation is 15 mm or more.
- When the temperature and humidity conditions are 30°C and RH 80% or more: thickness of the insulation is 20 mm or more.
- Be sure to insulate the liquid and gas sides interunit piping. It may become the cause of refrigerant leakage if it does not insulate. (Be sure to use insulating material which can resistant.)



**CAUTION** Insulation of interunit piping must be carried out up to the connection inside the casing. If the piping is exposed to the atmosphere, it may cause sweating or burn due to touching the piping, electric shocks or a fire due to the wiring touching the piping.



## 7 CHARGING REFRIGERANT (1/2)

< Be sure to use R32 as refrigerant. >

### ADDITIONAL REFRIGERANT CHARGING


This model is chargeless type, so it is not necessary to charge additionally if pipe does not exceed the maximum allowable length without additional charge.

Please refer to the following table about the maximum allowable length without additional charge.

When piping length exceeds its of a top table, or only when you perform recharging, Please be correctly charged according to the following. For future servicing, please describe the amount of additional refrigerant charging, or the amount of recharging in the collective label in back side of right side plate.

#### • In case of additional refrigerant charging

Please select the amount of additional refrigerant which suited piping length from the following table.



Outdoor units type	Liquid piping size	Length for which additional charging is not required	Length of piping exceeding the length for which additional charging is required, R32 additional amount (kg)				
			15m or less	25m or less	30m or less	35m or less	50m or less
RZFQ90,100AV16 RZVMFQ90,100AV16 RZCFQ90CV16 RZCFQ36CV1	$\varnothing 9.5 \text{ mm} \times t0.8 \text{ mm}$	15m	No Extra Charge	0.25	N/A	0.5	0.75
			No Extra Charge	0.25	0.375	N/A	N/A
			No Extra Charge	0.25	N/A	0.5	0.75

#### • Total refrigerant charging (When recharging due to exchange compressor, etc.)

Please charge refrigerant base on pipe length mentioned in the following table.

Outdoor units type	Liquid piping size	Piping length, R32 complete additional amount (kg)					
		5m-10m	15m or less	25m or less	30m or less	35m or less	50m or less
RZFQ90,100AV16 RZVMFQ90,100AV16,RZCFQ90CV16 RZCFQ36CV1	$\varnothing 9.5 \text{ mm}$	1.0	1.0	1.25	N/A	1.5	1.75
		1.30	1.30	1.55	1.675	N/A	N/A
		1.35	1.35	1.60	N/A	1.85	2.1

#### Refrigerant charge label


Please fill in with indelible ink,

- the factory refrigerant charge of the product,
- the additional refrigerant amount charged in the field and
- 1 + 2 the total refrigerant charge

on the refrigerant charge label supplied with the product.

Affix the refrigerant charge label near the manufacturer's label after filling it out.

The filled out label must be adhered in the proximity of the product charging port.



- factory refrigerant charge of the product: see unit name plate
- additional refrigerant amount charged in the field
- total refrigerant charge
- outdoor unit
- refrigerant cylinder and manifold for charging

- If the value of vacuum gauge increases, there is moisture inside the refrigerant piping or there are leakage points.  
Perform evacuation again after checking and improving the leakage points.

**NOTE**

- After doing an air-purge with a vacuum pump, the refrigerant pressure may not rise even if the stop valves are opened. This is because the refrigerant piping path is closed off by the outdoor unit electronic expansion valve, etc. There are no problems if the outdoor unit is run.

When recharging refrigerant, follow the procedure below.

In case of recharge refrigerant (cause of refrigerant leak) please follow suggestion below (reference detail from service manual).

1. Turn on refrigerant recovery mode by the remote controller. Refer to "On site setting" in an installation manual attached to a remote controller.

Content of settings	Mode NO.	FIRST CODE NO.	SECOND CODE NO.
Refrigerant recovery mode	16 (26)	7	01 OFF      03 ON

2. Shut down the power at least 1 minute after setting process (1) is performed.

- If the power is turned on before the process (3) - (6) are completed, the refrigerant recovery mode is turned off and the refrigerant cannot be recovered or charged normally.  
If the power is turned on by necessary, turn on Refrigerant recovery mode again.

3. Recover the refrigerant from both the refrigerant recovery port and liquid stop valve service port (or gas stop valve service port) simultaneously until the pressure drops below 0.09MPa (gauge pressure: -0.011MPa) by using a refrigerant recovery machine.


4. Modify the leakage points.

5. Perform the airtightness test and air-purge accordance with  
**AIRTIGHTNESS TEST AND AIR-PURGE**.



6. Charge the refrigerant from the service port of the liquid side stop valve when recharging refrigerant.

(Note) Do not turn on power during evacuation.

The motor may be damaged due to vacuum discharge.



## 7 CHARGING REFRIGERANT (2/2)



**Precautions when adding R32** • Before charging, check whether the cylinder has a siphon attached or not.

Charging a cylinder with an attached siphon

Stand the cylinder upright at charging.  
(There is a siphon piping inside, so that cylinder need not be upside-down to charge with liquid.)

Charging other cylinders

Stand the cylinder upside-down and charge.  
(Turn the cylinder upside-down at charging.)

- To prevent entry of any impurities and insure sufficient pressure resistance, always use the special tools dedicated for R32.
- For models RZFQ901100, RZV1MFQ901100, RZCFQ90CV16, RZCFQ36CV1 the refrigerant should be charged from the service port of the liquid side stop valve.

### WARNING

To persons incharge of piping work

- Please be sure to open a stop valve after a refrigerant charging end (if it operates shut, a compressor will break down).
- After complete charging of refrigerant carry out refrigerant leak check and heat insulation work.
- Please do not emit a refrigerant into the atmosphere indiscriminately.

## 8 ELECTRICAL WIRING WORK (1/3)

### WARNING

- Make sure to install a current balance type earth leakage breaker coping with high harmonics.  
(This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)

- Electrical wiring must be carried out by qualified personnel.
- Before obtaining access to terminal devices, all supply circuits must be interrupted.

## ⚠ CAUTION

### To the electrician

- Make sure to install a current balance type earth leakage breaker coping with high harmonics.  
(This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)
- Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)
- Do not remove the thermistors or sensors when the power supply and transmission wiring are connected.  
(Operating the unit with the thermistors and sensors removed will break the compressor.)
- Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.
- An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.
- The wiring between the indoor unit and outdoor unit must be for 230V.
- For electric wiring work, refer to also the "WIRING DIAGRAM".
- When doing the electrical wiring, always shut off the power source before working, and do not turn on the branch switch until all work is complete.
- Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.
- Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring.
  - Gas piping.....Ignition or explosion may occur if the gas leaks.
  - Water piping.....Hard vinyl tubes are not effective earths.
  - Lightning conductor or telephone earth wiring.....Electric potential may rise abnormally if struck by a lightning bolt.
- The earth is needed in order to reduce the noise generated by the unit's inverter and influence on other appliances and to release the charged electric charge on the outdoor unit surface by leaked current.
- Do not install a phase advance capacitor for improvement of power factor. Since this unit is mounted with an inverter device, the effect of power factor improvement not only cannot be expected, but also there is a risk of the capacitor getting abnormally overheated due to harmonics.
- Be sure to use earth leakage breaker dedicated for earth leakage protection in combination with the load break switch with fuse or breaker for wiring.
- In case of three-phase. Machine, electric wiring must be connected in normal phase connection.
- For wiring, use the designated power supply wiring and connect firmly, then secure to prevent external force being exerted on the terminal attachment (power supply wiring, transmission wiring, earth wiring).
- Left-over wiring should not be wrapped and stuffed into the outdoor unit.
- To prevent the power wiring from being damaged by the knock hole edges, put it in a wiring piping or use insulated bush, etc. to protect it.
- To prevent the wiring from coming in contact with piping (particularly the high-pressure piping), secure it with the included clamping material as shown page 13.

## 8 ELECTRICAL WIRING WORK (2/3)

- When wiring, form the wiring so that the front plate does not float and make sure the front plate is securely fastened.
- Fix the power supply wiring, the earth wiring and the transmission wiring by clamps as shown in the figure.
- As shown in the following figure, please fix power supply wiring, field wiring and ground wire by clamp material.

**RZCFQ90,100AV16, RZVFQ90,100AV16,RZMFQ90,100AV16**

**RZCFQ90CV16 ,RZCFQ36CV1**

- Carry out insulated processing of attaching an insulated sleeve.

Power supply wiring, wiring between units and ground wire with tying as clamp as shown below.

**⚠ Do not connect power supply to terminal block of transmission wiring. All system may get damaged.**




Fig. 4





Fig. 5

### ■ How to attach the partition plate.

- 1) Insert the protrusion of the partition plate into the notch in the metal sheet.
- 2) Slide the partition plate so that the tab on the metal sheet fits into the slit on the partition plate.
- 3) Secure with 2 screws.




## ELECTRICAL WIRING WORK (3/3)


### Connection of wiring

#### Precautions on wiring

- Use a round crimp-style terminal for connection to the power supply terminal board. In case it cannot be used due to unavoidable reasons, be sure to observe the following instruction.
- Do not connect wires of different gauge to the same power supply terminal. (Looseness in the connection may cause overheating.)



When connecting wires of the same gauge, connect them according to the below figure.



- Never use the stranded wiring which is soldered. (Slack in the electric wiring may cause abnormal heat.)
- Use the required wirings, connect them securely and fix these wirings so that external force may not apply to the terminals.
- Use a proper screw driver for tightening the terminal screws. If an improper screw driver is used, it may damage the screw head and a proper tightening cannot be carried out.
- If a terminal is over tightened, it may be damaged. Refer to the table on the right for tightening torque of terminals.

Tightening torque (N·m)	
M4 (Wire between units terminal board)	1.50±0.30
M4 (Power supply terminal board)	1.50±0.30
M4 (Ground wire between units)	1.69±0.25
M5 (Ground wire between units)	3.55±0.50


#### Precautions on connecting terminal of grounding

- Ground wiring should be taken out from the cut out section of a cup washer. (Otherwise, contact of ground wiring is inadequate and it is ineffective.)



### WIRING OF POWER SUPPLY AND THE UNITS

For details on the wiring of the indoor unit and Transmission wiring refer to the installation manual of the indoor unit.



#### SPECIFICATIONS OF STANDARD WIRING COMPONENTS

Outdoor Unit	Power supply		Wire type of Transmission
	Wire type (*)	Size	
RZFO90, 100AV16 RZMFQ90, 100AV16, RZCFQ36CV1 RZFO125, 140AY16, RZCFQ48CY1 RZVMFQ125, 140AY16 RZCFQ90CV16	H05VV-U5G	Wiring size and length must comply with local codes or [IEC 60335-1 (Table 11)]	H05VV-U4G2.5

(\*) Only in protected piping, use H07RN-F when protected pipes are not used.

(Supply cords shall not be lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC 57))

#### NOTES

- Select and install the power supply wiring in accordance with [IEC 60335-1 (Table 11)] or local laws and regulations. The maximum current of the outdoor and indoor units are shown on each name plate.
- When installing wiring in a location that can easily come in contact with people, be sure to install an earth leakage breaker coping with high harmonics to prevent electric shock.
- Breaker type and capacity shall be selected in accordance with local laws and regulations.

### CAUTION


#### TO PERSONS INCHARGE OF ELECTRICAL WIRING WORK

- Do not operate the unit until the refrigerant charging is completed. (Running it before the piping is ready will break the compressor.)

RZFQ125,140AY16  
RZVFQ125,140AY16  
RZMFQ125,140AY16  
RZCFQ48CY1


**Direction for pulling out the wiring**

- Plug the piping through-hole with putty or insulating material (field supply) so as not to leave any gap and prevent entry of small animals.
- Use the knock hole, on the front and side for the conduit (composite) operation.
- When punching knock hole remove pipe outlet from unit and open knock hole



When wiring, using single core wires for the earth wiring, tie the power supply wiring and the earth wiring by clamp material as shown in the right figure.

**CAUTION** Do not connect power supply to terminal block of transmission wiring. All system may get damaged.



## 9 CHECK ITEMS BEFORE TEST OPERATION

### PRE-RUN CHECKS

	ITEM TO CHECK	CHECK
Power supply wiring Transmission wiring Earth wiring	Is the wiring as mentioned on the wiring diagram? make sure no wiring has been forgotten and that there are no missing phases or reverse phases.	
	Does wiring between units put in and changed in continuation installation?	
	Is the unit properly grounded?	
	Are any of the wiring attachment screws loose?	
	Is the insulation resistance at least $1M\Omega$ ? <ul style="list-style-type: none"> <li>• Use a 500V mega-tester when measuring insulation</li> <li>• <del>•</del> Do not use a mega-tester for circuits which except 220-240V.</li> </ul>	
	Is an earth leakage circuit breaker used a current operated type which is compatible to the higher harmonic wave?	
	Does the earth leakage circuit breaker have appropriate rated current?	
Refrigerant piping	Is the size of the piping appropriate?	
	Is the insulation material for the piping attached securely? Are both the liquid and gas pipes insulated?	
	Are the stop valves for both the liquid side and the gas side open?	
Extra refrigerant	Did you write down the extra refrigerant and the refrigerant piping length?	
Indoor unit	Is the indoor unit fully installed? When the testrun is started, the fan automatically begins turning.	

### ⚠ WARNING

- When a power supply is switched on, when you leave from the outdoor unit, be sure to close the cover plate. (It becomes the cause of an electric shock).

## 10 TEST OPERATION


### ⚠ WARNING

- Never perform a test operation with the discharge piping thermistor (R2T) removed, as this might break the compressor.
- If the technician must leave the outdoor unit for some reason, switch places with another installation technician or close the plate. (It may cause electric shocks.)

### HOW TO TEST OPERATION

After the indoor and outdoor unit installation, be sure to perform the test operation in accordance with the following procedure.

- Open the front plate and check that the liquid and gas sides of the stop valves are open.  
<Be sure to close the front plate before the operation (there is a risk of electric shock)>  
(Note) After doing an air-purge with a vacuum pump, the refrigerant pressure may not rise even if the stop valves are opened. This is because the refrigerant piping path is closed off by the outdoor unit electronic expansion valve, etc. There are no problems if the unit is run.
- Attach the front plate to the outdoor unit and turn the power on at least 6 hours before operating the outdoor unit to protect the compressor.
- Set to COOLING operation with the remote controller.
- Perform the test operation.
- Operate normally.
- Confirm function of the indoor and outdoor units according to the operation manual.



### MALFUNCTION DIAGNOSIS

- At the time of a test run, when the following malfunction code is displayed on remote control, the fault of installation construction can be considered.

Malfunction code	Installation error	Remedial action
[E3] [E5] [U0] [L8] [H6]	A failure of a stop valve to open	Open the stop valves.
[E3] [E5] [L4] [L8]	Closing of an air passage	Remove any obstacle to the airflow path.
[U1]	Missing phase, negative phase	Correct the wiring.
[U2]	Power supply unbalancing	Balance the power/Correct the wiring
[U4] [UF]	Incorrect connection of field wiring	Correct the wiring.
[UA]	Connection of incompatible indoor unit	Connect appropriate indoor unit (refer to the catalogue)
NO INDICATION	Mistake wiring or not connect wiring of power supply, indoor, outdoor, field wiring between indoor unit	To correct wiring or connect correctly

- When malfunction codes other than the above are displayed on remote control, considering that the failure of between an indoor and an outdoor unit may have.  
For the malfunction codes, please refer to the indoor unit's installation manual or outdoor service manual.  
(A malfunction code has what has a display according to the form of the interior of a room and an outdoor unit, and the thing which is not.)
- The followings can be considered causes when the breaker for power supply trips.
  - The capacity of a breaker for power supply is smaller than the required capacity of the leakage circuit breaker.
  - The leakage circuit breaker is not compatible to the higher harmonic wave.
- In case of already checking all equipment that not have any problem, but found air conditioner not cooling.  
Please re-check Motor operate valve coil not tighten or remove for 1<sup>st</sup> checking. If normally please re-confirm problem following service manual to solve problem.

### ⚠ CAUTION

#### To persons incharge of piping work and electric work

- Please check having attached the front board and the piping cover after a test run end when giving production over to customer.

## 11. CAUTION (RZFQ90,100AV16, RZCFQ90CV16)

THIS IS NECESSARY FOR AFTER SERVICE, SO PLEASE REQUEST CUSTOMER TO KEEP THIS PAPER.

### CAUTION (NEW REFRIGERANT (R32 SERIES)



WARNING



ELECTRIC SHOCK CAUTION

#### Caution about electric shock when do service inspection.

1. After intercept power supply, do not open outside panel for 10 minutes.
2. Follow manufacturing label on electric box cover, please take off outdoor fan motor connector to confirm voltage and body static electricity discharge.

#### General caution items when do service inspection

##### Caution to confirm compressor and fan motor running

Do not directly connect power input (1/3 Phase 50Hz) to compressor and fan motor. (If not connect to print board (PCB), compressor and fan motor will be burned out.)

##### Caution when recharge refrigerant

1. To prevent the mixing of impurities, Pressure resistance and contamination mix, please use manifold gauge especially for R32.
2. Make sure to do Nitrogen blow if brazing when flare connection. Apply ether oil or ester oil at inside flare only.
3. Do air tight test at 4.0MPa
4. Do dry vacuum.

##### Caution when use outdoor PCB

Make sure to touch earth terminal and earthed metal before touch pcb, to prevent electric shock.

##### Caution when break down diagnosis from letter code in remote control

Please refer to service guide or outdoor unit installation manual.

### Charging refrigerant

#### Charging the system with refrigerant

(For more information such as calculation method of additional refrigerant charge, additional charge method, refrigerant charge caution refer to the Installation Manual and Technical Guide)



Never charge other than the specified refrigerant. (It may cause fire and bursting.)

Table 1. In case of additional refrigerant charging

Outdoor	Liquid piping size	Pipe length which is not required additional charging	Additional ref. amount				Max. pipe length
			25m or less	30m or less	35m or less	50m or less	
RZFQ90,100AV16	Φ9.5 x t0.8 mm	15mtr	0.25	N/A	0.5	0.75	50mtr
RZVFQ90,100AV16 RZCFQ36CV1 RZCFQ90CV16			1.25	0.375	N/A	N/A	30mtr

#### Total refrigerant charging (Details please see service guide)

1. Please recover the refrigerant until becoming 0.09 Mpa (gauge pressure:- 0.011MPa) or less by the refrigerant recovery machine from stop valve service port (liquid gas side) at the same time.
2. Exchange service parts: modify leak point.
3. Perform airtightness test air-purge. Please refer installation manual of outdoor unit or service guide.
4. Charge refrigerant amount selected by table 1 from liquid stop valve service port. **[Caution]** Do not turn on power during evacuation. The motor may be damaged due to vacuum discharge.

#### Making a record of the added refrigerant charge amount

Be sure to record the piping length and added refrigerant charge amount or refrigerant recharge amount with an oil-based or other indelible marker so the figures will not fade over time. This information is necessary for after service and maintenance.

Liquid piping size	Φ9.5 mm x t0.8 mm
Refrigerant piping length	m
Additional refrigerant charging	kg
Recharge of refrigerant	kg

### How to execute a pumping-down


(for example, when moving or reinstalling an indoor or outdoor unit)

The outdoor unit is equipped with a high pressure switch to protect the compressor. **[Caution]** Never short-circuit the high pressure switch during pump-down operation.

- It is not allowed to let the refrigerant out into the air. The refrigerant should be recovered completely.
- Although pumping-down operation allows most of the refrigerant to be recovered in a short period of time, some refrigerant will remain inside the indoor unit and the refrigerant piping. Using a refrigerant recovery machine, recover remaining refrigerant from the stop valve service port until the pressure falls to 0.09MPa (gauge pressure-0.011MPa) or less.
- Be sure to execute the pumping-down before refrigerant piping and wiring is taken off.

#### For pumping-down operation

1. Please follow the caution about electric shock when service inspection which attached on E-Box cover (Caution : Do not take off the connector S70)
2. To prevent electric shock, please protect power input terminal block by insulation sheet refer to below figure.
3. Turn on the power supply and carry out pumping-down operation according to the following procedure.



**[Caution]** To prevent electric shock when inspection, protect by use insulation sheet on power input terminal block and print board(A2P)


#### For pumping-down operation

**[Caution]** Do not remove the indoor unit until pump down operation finish. (It is dangerous when indoor fan automatically starts the operation.)

Perform pumping-down operation using the following procedure

procedure	Precaution
1. Caution that stop valves both on the liquid and gas sides are open.	
2. Push the pumping-down button (BS1) on the PC board of the outdoor unit for 5 seconds	Compressor and outdoor unit fan will start operation automatically door only automatically start running. pay attention to this.
3. Close the stop valve on the liquid side securely about 4 to 5 minutes after the compressor started operation. After 2 to 3 minutes, close the gas stop valve and push pump down button(BS1) for stop operation.	• Do never leave the outdoor unit unattended with opened front panel when power supply is on. • In case the stop valve on the liquid side is not securely closed during compressor operation, pumping-down operation cannot be executed
4. Turn off the power supply.	When you work alone, carry out after closing the front plate, After turning the power supply off, remove the insulation sheet.

- To force of operation, turn off the main power supply and turn it on again. Make sure that stop valves both on liquid and gas sides are open and be sure operate the unit in cooling operation during test run.




**[Caution]** When installing and relocating, be sure to install the earth leakage breaker to protect from the electric shock disaster and fire due to leakage of electricity. For installing the earth leakage breaker, request to the qualified electrician.

## • Caution when servicing the switch box

1. Be sure to check using a tester that the power supply is turned off at a terminal strip before service inspection.
2. Be aware that temperature of switch boxes can be extremely high.
3. Do not touch the switch box for another 10 minutes after turning off the circuit breaker. Even after 10 minutes, always measure the voltages at the terminals of main circuit capacitor or electrical parts and make sure that those voltages are 50V DC or less.

(Always touch the earth terminal first before pulling out or plugging in connectors in order to discharge static electricity. This to prevent the PCB from being damaged.



4. After confirming the main circuit capacitor voltage drop, pull out the outdoor unit fan connector, make sure not to touch any live parts during this action. (strong adverse winds which let the outdoor unit fan rotate, induce a risk of electrical shock because the fan rotation makes the capacitor store electricity.

## • Caution when performing other servicing

Do never connect power supply cables to compressors (U,V,W) or fan motor directly. (Failure to connect the power supply to the PC board may cause the compressor or fan motor to burn out.)

- Total refrigerant charging (Details please see service manual) in case of RZFQ12s,140 v series CDTurn ON refrigerant recovery mode by remote control

Please refer [field setting] from remote control installation manual.

Setting content	Mode No.	Setting switch No.	Setting position No.
Refrigerant recovery mode setting	16(26)	7	01 03
			OFF ON

- ⑧ After setting CD, power supply will be intercepted after 1 minute passed.
  - It turn on power supply before ⑧⑨ are completed refrigerant recovery mode is turned OFF, the refrigerant cannot be recovered or charged regularly.
  - In case charge power supply unwillingly, please set refrigerant mode as ON by remote control again.
- ⑨ Please recover the refrigerant until becoming 0.09Mpa (gauge pressure: -0.011 Mpa) or less by the refrigerant recovery machine from stop valve service port (liquid . gas side) at the same time.
- ⑩ Exchange service parts modify leak point.
- ⑪ Perform airtightness test . air- purge.
  - Please refer installation manual of outdoor unit or service manual.
- ⑫ Charge refrigerant amount selected by table 1 from liquid stop valve service port.
  - Caution Do not turn on power during evacuation. The motor may be damaged due to vacuum discharge.
  - In other hands, Recovery mode can set from button at outdoor side.

**Table 1. Charge refrigerant amount (After a leak, etc...)**

Outdoor	Liquid piping size	Piping length: R32 complete additional amount (KG)					
		5'10m	15m or less	25m or less	30m or less	35m or less	50m or less
RZFQ 125,140 series	Ø9.5 x 10.8mm	1.35	1.35	1.6	N/A	1.85	2.1
RZFO 125,140 series	Ø9.5 x 10.8mm	2.1	2.1	2.35	2.475	N/A	N/A

## How to execute a pumping-down

(for example, when moving or reinstalling an indoor or outdoor unit)

The outdoor unit is equipped with a high pressure switch to protect the compressor.


**Caution** Never short-circuit the high pressure switch during pump-down operation.

- It is not allowed to let the refrigerant out into the air. The refrigerant should be recovered completely.
- Although pumping-down operation allows most of the refrigerant to be recovered in a short period of time, some refrigerant will remain inside the indoor unit and the refrigerant piping. Using a refrigerant recovery machine, recover remaining refrigerant from the stop valve service port until the pressure falls to 0.09 MPa. (gauge pressure: -0.011 MPa) or less.
- Be sure to execute the pumping-down before refrigerant piping and wiring is taken off.

## Preparation for pumping-down operation

1. Make sure to cut off power supply. Open the front panel and cover the PCB and terminal board with insulation sheet to avoid electric shock by accidental touching of live parts.
2. Close the front panel before leaving the outdoor unit. You cannot leave the unit unattended in case the front panel remains opened.
3. Turn on the power supply and carry out pumping-down operation according to the following procedure.

**Do not take off the insulation sheet when inspection from the opening to prevent electric shock.**



## • For pumping-down operation

- ◆ Do not remove the indoor unit until pump operation finish. (It is dangerous when indoor fan automatically starts the operation.)

Perform pumping-down operation using the following procedure

	Procedure	Precaution
1	Confirm that stop valves both liquid and gas sides are open.	
2	Push the pumping-down button (BS2) on the PC board of the outdoor unit for 5 seconds.	Compressor and outdoor unit fan will start operation automatically. Indoor fan may automatically start running. Pay attention to this
3	close the stop valve on the liquid side securely about 2 minutes after the compressor started operation.  Once the compressor operation stops after 2 to 5 minutes, close the stop valve on the gas side securely.	
4	Turn off the power supply.	When you work alone, carry out after closing the front plate, After turning the power supply off, remove the insulation sheet.

- If after finishing pumping-down operation the outdoor unit does not operate, even when the remote controller switch is turned on, the remote controller and ?segment display may or may not indicate "U4" But it is not a malfunction.
- When in need of operation, turn off the main power supply and turn it on again. make sure that stop valves both on liquid and gas sides are open and be sure to operate the unit in cooling operation during test run.



Liq. stv. valve Gas stv. valve

- ◆ When installing and relocating, be sure to install the earth leakage breaker to protect from the electric shock disaster and fire due to leakage of electricity. For installing the earth leakage breaker, request to the qualified electrician.

**DAIKIN AIRCONDITIONING INDIA PVT. LTD.**

12th Floor, Building No. 9, Tower A,  
DLF Cyber City, DLF Phase - III  
Gurgaon - 122002, Haryana (India)  
Tel : +91-124-4555444  
Fax: +91-124-4555333

# Split System Air Conditioner

## INSTALLATION MANUAL <FOR OUTDOOR UNIT>

READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION.

### NEW REFRIGERANT (R32) SERIES RZCMF50CV16, RZCMF71CV16

Note :  Read the precautions in this manual carefully before operating the unit.

 This appliance is filled with R32.

## CONTENTS

SAFETY PRECAUTIONS.....	38
1.BEFORE INSTALLATION.....	40
2.SELECTING INSTALLATION SITE.....	40
3.INSTALLATION SERVICE SPACE.....	41
4.PRECAUTIONS ON INSTALLATION.....	44
5.REFRIGERANT PIPING WORK.....	44
6.AIRTIGHTNESS TEST AND AIR-PURGE.....	47
7.CHARGING REFRIGERANT.....	48
8. ELECTRICAL WIRING WORK.....	49
9.CHECK ITEMS BEFORE TEST OPERATION AND FIELD SETTINGS.....	52
10.TEST OPERATION.....	53
11.CAUTION.....	54
12.HOW TO RE-USE THE EXISTING PIPING.....	55
13.REFRIGERANT RECOVERY.....	56
14.UNPACKING & PACKING INSTRUCTION OF OUTDOOR UNIT .....	57



### WARNING) THERE IS A RISK OF EXPLOSION OR FIRE

- Do not mix air in the refrigerating cycle during pump down operation.
- Do not use oxygen for air tight test.
- Do not use refrigerant other than the specified one or flammable material ( e.g. propane ) in the refrigerant cycle. They may cause over pressure in the refrigerating cycle and result in explosion, fire or injury. Our company assumes no responsibility for failure or malfunction caused by filling or mixing of anything other than the specified refrigerant.



### CAUTION) ABOUT ISOLATING RESISTANCE OF COMPRESSOR

If refrigerant accumulates in the compressor after completing installation, the insulation resistance can drop, but if it is at least  $1\text{ M}\Omega$ , then the unit will not break down.

- Connect the power supply to the unit and after 6 hours check if the insulation resistance of the compressor rises. (Energize and heat the compressor to vaporize the refrigerant accumulated in the compressor.)
- If the earth leakage breaker actuates, check if the earth leakage breaker is equipped with a device to cope with high harmonics. To prevent wrong actuation of the earth leakage breaker due to the inverter, make sure to adopt an earth leakage breaker equipped with a device to cope with high harmonics.

1. Please make sure to confirm that R32 (new refrigerant) is used in installation work in advance.  
(It may not operate normally, if refrigerant type is different.)
2. The refrigerant R32 requires that strict precautions be observed for keeping the system clean, dry and tightly sealed.
  - Clean and dry  
Strict measures must be taken to keep impurities (Including SUNISO oil and other mineral oils as well as moisture) out of the system.
  - Tightly sealed  
R32 contains no chlorine, does not destroy the ozone layer and so does not reduce the earth's protection against harmful ultraviolet radiation. R32 will contribute only slightly to the greenhouse effect if released into the atmosphere. Therefore, sealing tightness is particularly important in installation.  
Carefully read the chapter **(5) REFRIGERANT PIPING WORK** and strictly observe the correct procedures.
3. The design pressure of this unit : High/Low pressure area are shown in the right table.  
The refrigerant piping is a high pressure area,  
Use the refrigerant piping which supports the design pressure.  
The piping specifications, please refer to chapter **(5) REFRIGERANT PIPING WORK**
4. Be sure to connect the indoor unit, which is dedicated to R32. See the catalog for indoor unit models which can be connected.  
(Normal operation is not possible when connected to other units.)

Outdoor Unit	Design Pressure	
RZCMF71CV16	High	4.17
RZCMF50CV16	Low	2.76

(Units: MPa)

## READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION

- This manual classifies the precautions into **WARNINGS** and **CAUTIONS**.

Be sure to follow all the precautions below. They are all important for ensuring safety.



**WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

- After the installation is completed, test the air conditioner and check if the air conditioner operates properly.

Given the user adequate instructions concerning the use and cleaning of the indoor unit according to the operation manual. In particular, make sure to explain with regard to "SAFETY PRECAUTIONS" and "Not malfunction of the air conditioner".

Ask the user to keep this manual and the operation manual together in a handy place for future reference.

- This air conditioner comes under the term "appliances not accessible to the general public".

### ⚠ WARNING

- Ask your local dealer or qualified personnel to carry out installation work. Improper installation may result in water leakage, electric shocks or a fire.
- Perform installation work in accordance with this installation manual. Improper installation may result in water leakage, electric shocks or a fire.
- Consult your local dealer regarding what to do in case of refrigerant leakage. When the indoor unit is installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen deficiency.
- Be sure to use only the specified parts and accessories for installation work. Failure to use the specified parts may result in the air conditioner fall down, water leakage, electric shocks, a fire, etc.
- Install the air conditioner on a foundation that can withstand its mass. Insufficient strength may result in the air conditioner fall down and causing injury.
- Carry out the specified installation work in consideration of strong winds, typhoons, or earthquakes. Improper installation may result in an accident such as the air conditioner falling.
- Make certain that all electric work is carried out by qualified personnel according to the applicable legislation (note 1) and this installation manual, using a separate circuit. In addition, even if the wiring is short, make sure to use a wiring that has sufficient length and never connect additional wiring to make the length sufficient. Insufficient capacity of the power supply circuit or improper electric construction may lead to electric shocks or a fire. (note 1) Applicable legislation means "All international, national and local directives, laws, regulations and/or codes which are relevant and applicable for a certain product or domain."
- Earth the air conditioner. Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring. Incomplete earthing may cause electric shocks or a fire.
- Be sure to install an earth leakage circuit breaker. Failure to do so may cause electric shocks or a fire.
- The appliance must be stored in a room without continuously operating ignition sources (for example : open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerant may not contain an odor.
- Comply with national gas regulations.
- Be sure to switch off the unit before touching any electrical parts. Touching a live part may result in electric shocks.
- Make sure that all wiring is secure, using the specified wiring and ensuring that external forces do not act on the terminal connections or wiring. Incomplete connection or fixing may cause overheating terminals or fire.
- When wiring between the outdoor and indoor units, and wiring the power supply, from the wiring orderly so that the structural parts such as a cover can be securely fastened. If the cover is not in place, electric shocks or a fire may be caused.
- Do not add wiring. It may result in heat generation. Electric shocks or fire.
- When installing or relocating the air conditioner, be sure to bleed the refrigerant circuit to ensure, it is free of air, and use only the specified refrigerant (R32). The presence of air or other foreign matter in the refrigerant circuit causes abnormal pressure rise, which may result in equipment damage and even injury.
- If refrigerant gas leaks during installation work, ventilate the area immediately. Toxic gas may be produced if refrigerant gas comes into contact with a fire.
- After completing the installation work, check to make sure that there is no leakage of refrigerant gas. Toxic gas may be produced if refrigerant gas leaks into the room and comes into contact with a source of a fire, such as a fan heater, stove or cooker.
- Never directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.
- Do not stand on the outdoor unit or put things on it. The unit may fall down or drop, and cause accidents.
- Do not charge any refrigerant into the refrigeration cycle other than the designated refrigerant. It may cause an explosion or a fire due to leakage or a burst due to abnormally high pressure in the refrigeration cycle.
- Do not extend wiring on the way. It may cause heat generation, electric shocks or fire.
- At the installation work, install the refrigerant piping firmly before operating the compressor. If the compressor is operated without installing firmly and the service valve is in open condition, it sucks the air, etc., and the pressure inside the refrigerant circle becomes abnormally high. It may cause injury and breakage.
- At pump down work, stop the compressor before removing the refrigerant piping. If removing the refrigerant piping when the compressor is operated with its service valve in open condition, it sucks the air, etc., and the pressure inside the refrigerant circle become abnormally high, which may cause injury and breakage.
- The appliance RZCMF50/71CV16 shall be installed operated and stored in a room with floor area larger 1.84 m<sup>2</sup>
- When flared joints are reused, the flare part shall be re-fabricated.



## CAUTION

- Install drain piping according to this installation manual to ensure good drainage, and insulate the piping to prevent condensation. Improper drain piping may cause water leakage, make the furniture get wet.
- Install the indoor and outdoor units, power cord and connecting wires at least 1 meter away from televisions or radio to prevent picture interference and noise. (Depending on the incoming signal strength, a distance of 1 meter may not be sufficient to eliminate noise.)
- Install the indoor unit as far as possible from fluorescent lamps.
- In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- Disposal requirements  
Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.
- Only qualified personnel can handle, fill, purge and dispose of the refrigerant.
- Do not install the air conditioner in places such as following:
  - Where there is mist of oil, oil spray or vapor for example a kitchen.  
Resin parts may deteriorate, and cause them to fall out or water to leak.
  - Where corrosive gas, such as sulfuric acid gas, is produced.  
Corrosion of copper pipings or brazed parts may cause the refrigerant to leak.
  - Where there is machinery which emits electromagnetic waves.  
Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
  - Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables, such as thinner or gasoline, are handled. If the gas should leak and remain around the air conditioner, it may cause ignition.
  - The place that the vibration or the voltage fluctuation give influence. Vehicles, vessels, etc.  
The vibration may cause a damage and the voltage fluctuation may cause an abnormal operation.
  - Where small animals may build a nest, fallen leaves are accumulated, or weeds are overgrown.  
If small animals touch the electrical parts inside, this may cause malfunction, smoke or a fire.


■ Important information regarding the refrigerant used  
This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.  
Refrigerant type: R32  
GWP<sup>(1)</sup> value: 675  
• <sup>(1)</sup>GWP = global warming potential  
The refrigerant quantity is indicated on the unit name plate.

## 1 BEFORE INSTALLATION

### CAUTION



- Read these instructions carefully before installation.  
For installation of the indoor unit,  
refer to the indoor unit installation manual.

RZCMF71CV16  
RZCMF50CV16



### HANDLING

As shown in the figure, bring the unit slowly by grabbing the left and right grips.  
(Take care not to let hands or objects come in contact with rear fins.)



### INSTALLATION CONSTRUCTION ACCESSORIES

Be sure only to use accessories made by DAIKIN  
which are specifically designed for use with the equipment.


### CAUTION

Work in a team of at least two people when carrying the outdoor unit

## 2 SELECTING INSTALLATION SITE (1/2)

(1) Select the installation location that meets the following conditions and get approval of the customer.

- Places where there is no risk of flammable gas leakage.
- Places where the outdoor unit does not bother next-door neighbors.
- Safe places which can withstand the unit's mass and vibration and where the air conditioner can be installed level.
- Places that are well-ventilated and where servicing space can be well ensured.  
The minimum required space is shown in chapter 3 INSTALLATION SERVICE SPACE.
- Where the piping length between the indoor and the outdoor units is ensured within the allowable piping length. Please see chapter 5 REFRIGERANT PIPING WORK.
- Do not allow wind from the same direction to blow frequently toward the outlet or inlet of the outdoor unit. If the wind is likely to blow as mentioned above, make sure to keep a sufficient service space and install a wind protective shield.



Inverter air conditioners may cause noise to occur in electrical appliances. As shown in the right drawing, select an installation site well away from radios, PCs, and stereos.

Especially in the areas where the incoming signal strength is weak, keep the indoor remote controller 3 meter or more from electrical appliances.

Put the power supply and transmission wiring in a metal piping and ground the metal piping.

## 2 SELECTING INSTALLATION SITE (2/2)

### CAUTION

- 1) In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- 2) When installing the unit in a place exposed to strong wind, pay special attention to the following. Strong winds of 5 m/sec or more blowing against the outdoor unit's air outlet causes short circuit (suction of discharge air) and this may have the following consequences:
  - Deterioration of the operational capacity.
  - Disruption of operation due to rise of high pressure.
  - When a strong wind blows continuously on the face of the unit, the fan can start rotating very fast until it breaks. Refer to the figures for installation of this unit in a place where the wind direction can be foreseen.
- 3) Following the installation place, it is expected that the influence of the strong wind is great.
  - The flat area which receives the adverse wind such as typhoon directly since there is no obstacles such as buildings and mountains. (Including coast line, shoreline of lake and mountain region.)
  - The installation place that no obstacles around the outdoor unit to prevent the adverse wind, for example, walls and buildings that are higher than the applicable outdoor unit, etc. Please take measures when installing especially on a rooftop.
  - Since the outdoor unit may fall down, attach the fixture for preventing overturning(option).



- 4) Prepare a water drainage channel around the foundation, to drain waste water from around the unit.
- 5) If the water drainage of the unit is not easy, please build up the unit on a foundation of concrete blocks, etc. (the height of the foundation should be maximum 150 mm).
- 6) If you install the unit on a frame, please install a waterproof plate within 150 mm of the underside of the unit in order to prevent the invasion of water from the lower direction.

## 3 INSTALLATION SERVICE SPACE (1/3)

- The installation servicing spaces shown in these drawings are based on the outdoor unit inlet area temperature of 35°C for COOLING operation.


If the planned inlet area temperature exceeds 35°C(DB), or if the heat load of all outdoor units is increased significantly and exceeds the maximum operating capacity, secure a larger space than that indicated by the inlet dimensions in these drawings.

- For installation, consider both pedestrian and air flow paths and choose a suitable pattern from these drawings to match the space available field. (If the number of units to be installed exceeds the patterns in these drawings, consider there is no short-circuits.)
- Regarding the front space, position the units with consideration to the space required for the refrigerant piping work. (Consult your dealer if the work conditions do not match those in the drawings.)
- Secure appropriate space when using a side piping outlet.

### STAND-ALONE INSTALLATION

#### No Obstacle above


- 1) Obstacle on the suction side only




- To secure service space, more than 250 mm of each products at right side in needed.

(Units: mm)

- 2) Obstacle on both sides and suction side, too




- 3) Obstacle on the discharge side only




#### Obstacle above, too


- 1) Obstacle on the suction side, too



- 2) Obstacle on both sides and suction side, too



- 3) Obstacle on the discharge side only, too




### 3 INSTALLATION SERVICE SPACE (2/3)

When there are obstacles on both suction and discharge sides

(Pattern 1) When the obstacles on the discharge side is higher than the unit


1) No obstacle above (There is no limit for the height of obstructions on the suction side.)



2) Obstacle above, too  
The relations between H, A and L are as follows.


	L	A
$L \leq H$	$L \leq 0.5H$	750 or more
	$0.5H < L \leq H$	1000 or more
$L > H$	Set the stand as: $L \leq H$	

※ - Close the bottom of the stand to prevent the discharged air from being bypassed.  
 - The limitation of facilities connection is until 2 unit only.  
 - In case of more than dimension in ( ), It is no need to establish the stand although  $L > H$



(Pattern 2) When the obstacle on the discharge side is lower than the unit


1) No obstacle above (There is no limit for the height of obstructions on the suction side.)



2) Obstacle above, too  
The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	50 or more
	$0.5H < L \leq H$	100 or more
$L > H$	Set the stand as: $L \leq H$	


※ - Close the bottom of the stand to prevent the discharged air from being bypassed.  
 - The limitation of facilities connection is until 2 unit only.  
 - In case of more than dimension in ( ), It is no need to establish the stand although  $L > H$



#### SERIES INSTALLATION (2 OR MORE)

No obstacle above

1) Obstacle on the suction side and both sides




※ Inside extraction, please provide the space of piping.

• To secure service space, more than 250 mm of each products at right side is needed.


(Units: mm)

2) Obstacle on the discharge side only




Obstacle above, too

1) Obstacle on the discharge side



2) Obstacle on the suction side and both sides




### 3 INSTALLATION SERVICE SPACE (3/3)

When there are obstacles on both suction and discharge sides

(Pattern 1) When the obstacles on the discharge side is higher than the side unit

1) No obstacle above (There is no limit for the height of obstructions on the suction side.)




2) Obstacle above, too

The relations between H, A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	1000 or more
	$0.5H < L \leq H$	1250 or more
$L > H$	Set the stand as: $L \leq H$	

- To secure service space, more than 250 mm of each products at right side is needed.



(Pattern 2) When the obstacle on the discharge side is lower than the unit


1) No obstacle above

(There is no limit for the height of obstructions on the suction side.)

2) Obstacle above, too

The relations between H, A and L are as follows. The relations between H, A and L are as follows.


L	A
$L \leq 0.5H$	150 or more
$0.5H < L \leq H$	200 or more



L	A	
$L \leq H$	$L \leq 0.5H$	150 or more
	$0.5H < L \leq H$	200 or more
$L > H$	Set the stand as: $L \leq H$	

- Close the bottom of the stand to prevent the discharged air from being bypassed.
- The limitation of facilities connection is until 2 unit only.
- In case of more than dimension in ( ), It is no need to establish the stand although  $L > H$

(Units: mm)




#### DOUBLE-DECKER INSTALLATION


- Do not stack more than two unit.
- The drain piping construction size of upper side outdoor unit is needed about 100 mm.
- In side extraction, please provide the space of piping.

(Units: mm)

1) Obstacle on the discharge side




2) Obstacle on the suction side



#### MULTIPLE ROWS OF SERIES INSTALLATION (ON THE ROOFTOP, ETC.)


1) One row of stand-alone installation



2) Rows of series installation (2 or more)

The relations between H,A and L are as follows.

	L	A
$L \leq H$	$L \leq 0.5H$	150 or more
	$0.5H < L \leq H$	200 or more
$L > H$	Can not be installed	




## 4 PRECAUTIONS ON INSTALLATION

- Check the strength and level of the installation ground so that the unit will not cause any operating vibration or noise after installed.
- In accordance with the foundation drawing in Fig. 1, fix the unit securely by means of the foundation bolts. (Prepare 4 sets of M12 foundation bolts, nuts and washers each which are available on the market.)
- It is best to screw in the foundation bolts until their length are 20 mm from the foundation surface.
- Fix the outdoor unit to the foundation bolts using nuts with resin washers. (See the left-hand of Fig. 1 drawing )  
If the coating on the fastening area is stripped off, the nuts rust easily.

### <Drain pipe disposal>

- If drain pipe disposal from the outdoor unit causes trouble, (for example, if the drain water may splash on people) provide the drain piping by using of the drain plug (optional).
- Then, coat the area around the bored holes with rust preventive coating to cover the metal exposure.
- Make sure the drain works properly.



## 5 REFRIGERANT PIPING WORK (1/4)

### CAUTION

#### To plumbing person

- Important information regarding the refrigerant used. This product contains fluorinated greenhouse gases covered by the Kyoto Protocol.  
Do not vent gases into the atmosphere.  
GWP (global warming potential) of R32 refrigerant type = 675.
- Use R32 as additional for charging.
- Do not use flux when brazing refrigerant piping.  
Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux.  
(If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)
- After chapter 7 CHARGING REFRIGERANT is completed, be sure to open the stop valves before performing 9 LOCAL SETUP).  
(Operating the unit with the valve shut will break the compressor.)

#### (Precaution when reuse existed refrigerant pipe)

Please keep below points in order to reuse existed pipe, failure may caused if have a fault.

- Below are pipes shall always make new construction, do not reuse piping.
  - When removed from indoor unit or outdoor unit for a long time.  
(Moisture entry to internal pipe, wastes entry can be occurred.)
  - When copper tube is corroded.
  - When pipe thickness is insufficient (refer to 5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH)
  - Do not reuse flare for refrigerant leak protection, please make flare processing.
  - Do not reuse flare nut, please use flare nut in product accessories.
  - Make sure to do refrigerant leak check in case there is brazing area while perform field piping.
  - If insulation is deteriorate, make sure to exchange to new one.

#### (5-1 INSTALLATION TOOLS) Be sure to use the dedicated tools to ensure sufficient pressure resistance and prevent the entry of any impurities.

Manifold gauge	To ensure sufficient pressure resistance and prevent the entry of any impurities (mineral oils such as Suniso oil and liquids), use the R410A or R32 dedicated item (the screw specifications for R410A or R32 differ).
Vacuum pump	Be extremely careful not to flow the pump oil backward to inside the piping when the pump is stopped. Use a pump which enables vacuuming to -0.1 MPa(-755mmHg) of the gauge pressure.

#### (5-2 SELECTION OF PIPING MATERIAL)

- Use the piping whose inside and outside are clean and with no harmful substances for use such as sulphur, oxide, dust, dust from cutting, grease, or liquid (contamination) is attached.
- For the refrigerant piping, use the following material.

Material: Deoxidised phosphorous seamless copper piping

Temper grade: Use piping with temper grade in function of piping diameter as listed in the table on section

#### (5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH)

Size: Decide based on section (5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH)

Thickness: Comply with applicable legislation. The minimal piping thickness for R32 piping must be in accordance with the table on section

#### (5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH)

- Be sure to perform piping work using measurements within the maximum allowable length and height difference described on section

#### (5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH)

## 5 REFRIGERANT PIPING WORK (2/4)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

### 5-3 CARE OF PIPE

- Prevent contamination or moisture from getting into the piping.
- Pay special attention when running the copper piping through the through-hole or when leading the edge of the piping outside the room.
- Refrigerant piping must be protected from physical damage. Install a plastic cover or equivalent.

PLACE	INSTALLATION PERIOD	PROTECTION METHOD	PLACE	INSTALLATION PERIOD	PROTECTION METHOD
OUTDOOR	More than a month	Pinch the pipe	INDOOR	Unquestioned	Pinch or tape pipe
	Less than a month	Pinch or tape pipe			

### 5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH

- One way maximum allowable piping length means the maximum length of liquid side piping or gas side piping.
- Equivalent length is the pressure loss due to L joints, traps, and so on along the refrigerant piping converted to a straight piping length of the same size and added to the overall value.
- Please see the Engineering Data for calculation of equivalent length.
- Please give the vertical interval between the indoor and outdoor as 20m or less.

#### CAUTION

This unit is chargeless specification. Due to chargeless length and allowable piping length will be different depend on field pipe size.

#### Piping bend radius

(Units : mm)

Piping diameter	Pipe thickness (material)	Bend radius
Ø 6.4mm	0.6 mm (C1220T-O, Type O)	30mm or more
Ø 15.9mm	1.0 mm (C1220T-O, Type O)	50mm or more

#### Refrigerant pipe size and chargeless length

Outdoor unit type	Liquid pipe size (type)	Chargeless length
RZCMF71CV16 RZCMF50CV16	Ø 6.4mm x t 0.6mm (type O)	10m

### WARNING


- When flared joints are reused in indoors, the flared part shall be re-fabricated.

### CAUTION

- Use dedicated piping cutters and flaring tools for R410A or R32.
- When making a flare connection, apply ether or ester oil only to the flare inner surface.
- Use only the flare nuts attached to the unit. If other flare nuts are used, it may cause refrigerant leakage.
- To prevent contamination, dust or moisture from getting into the piping, take measures such as pinching or taping the piping.

### 5-5 CONSTRUCTION OF REFRIGERANT PIPING

- Field pipes can be installed in Back - side connection. <Fig.2>
- Do not allow any substances other than the specified refrigerant such as air to mix into the refrigerant circuit.




<Fig. 2>

## 5 REFRIGERANT PIPING WORK (3/4)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

### PREVENTING FOREIGN OBJECTS FROM ENTERING

- Plug the pipe through-holes with putty or insulating material (field supply) to cover all gaps, as shown in the figure.
- Insects or small animals entering the outdoor unit may cause a short circuit in the electrical box.




### CAUTIONS FOR HANDLING STOP VALVE

**DO NOT OPEN THE STOP VALVE UNTIL (7) CHARGING REFRIGERANT FINISHED.**

- The stop valves for indoor-outdoor connecting piping are closed at shipment from the factory. The names of parts are shown in figure on the right.
- Since the side boards may be deformed if only a torque wrench is used when loosening or tightening flare nuts, always lock the stop valve with a wrenches and then use a torque wrench.


When tightening the flare of the stop valves, make sure to tighten by the rated torque. The rated torque is shown on (CAUTION FOR FLARE CONNECTION) (Following)



**DO NOT APPLY FORCE ON THE VALVE CAP, THIS MAY RESULT IN A REFRIGERANT LEAK.**

- For cooling operation under low ambient temperature or any other operation under low pressure, apply silicon pad or similar to prevent freezing of the gas stop valve flare nut (see figure).

Freezing of the flare nut may cause refrigerant leak.




### How to operate the stop valve

Use hexagonal wrenches 5mm.

**Opening the valve** 1. Place the hex wrench on the valve bar and turn counter-clockwise.  
2. Stop when the valve bar no longer turns. (It is now open.)

**Closing the valve** 1. Place the hex wrench on the valve bar and turn clockwise.  
2. Stop when the valve bar no longer turns. (It is now close.)



### CAUTIONS FOR HANDLING VALVE CAP

- A seal is attached to the point indicated by the arrow. Take care not to damage it.
- Be sure to tighten the valve cap securely after operating the valves.

Valve size (mm)	Tightening torque(N·m)	Valve size (mm)	Tightening torque(N·m)
Liquid side Ø6.4	15.7 ± 1.5 N·m	Gas side Ø15.9	33.0 ± 3

Stop valve (cap attachment)

### CAUTIONS FOR HANDLING SERVICE PORT


- Always use a flexible charge hose with a push-rod and valve to enable recovery of remaining refrigerant in the charge hose.
- After the work, tighten the valve cap in place.
- Tightening torque:  $12.7 \pm 1.2 \text{ N}\cdot\text{m}$



Do not use a charging hose of which pressing stick is slipped out from the center. (It may cause refrigerant leakage due to deformation to the valve stem of the service port)

### PRECAUTIONS FOR CONNECTING PIPING

- Take caution so that the refrigerant piping between the outdoor and indoor may not touch and sound proof cover and the plate as shown figure.
- If installing the outdoor unit higher than the indoor unit, caulk the space around insulation and tubes because condensation on the stop valves can seep through to the indoor unit side.



### PRECAUTIONS REGARDING INSULATION

Enhance the insulation of the refrigerant piping according to the installation conditions. If this is not done, condensation may form on the surface of the insulation. Please refer to the target values shown below.

- When the temperature and humidity conditions are 30°C and RH 75% or more: thickness of the insulation is 15 mm or more.
- When the temperature and humidity conditions are 30°C and RH 80% or more: thickness of the insulation is 20 mm or more.
- Be sure to insulate the liquid and gas sides interunit piping. It may become the cause of refrigerant leakage if it is not insulated. (Be sure to use insulating material which can resistant.)





Caution Insulation of interunit piping must be carried out up to the connection inside the casing. If the piping is exposed to the atmosphere, it may cause sweating or burn due to touching the piping, electric shocks or a fire due to the wiring touching the piping.

## 5 REFRIGERANT PIPING WORK (4/4)

### CAUTION FOR FLARE CONNECTION

- Please be sure to remove a flare nut with a two-dish spanner, and to bind after connection of piping using a spanner and a torque wrench.
- Refer to the following table for a flare part processing size.
- When connecting the flare nut, apply refrigerating machine oil to the flare (inside) and at first screw the nut 3 or 4 turns by hand. Coat here with ether or ester oil.
- Refer to the table for the dimensions for processing flares and for the tightening torques. (Too much tightening will end up in splitting of the flare.)
- After completing the installation, carry out a gas leak inspection of the piping connections with nitrogen and such.

PIPING SIZE (mm)	TIGHTENING TORQUE	A DIMENSIONS FOR PROCESSING FLARES (mm)	FLARE SHAPE
Ø6.4	15.7 ± 1.5 N·m	8.9 ± 0.2	
Ø9.5	36.3 ± 3.6 N·m	13.0 ± 0.2	
Ø12.7	54.9 ± 5.4 N·m	16.4 ± 0.2	
Ø15.9	68.6 ± 6.8 N·m	19.5 ± 0.2	
Ø19.1	108.0 ± 10.8 N·m	23.8 ± 0.2	



- If a torque wrench is not available, be aware that the tightening torque may increase suddenly. Do not tighten nuts any further than to the angle as listed.
- When work is completed, be sure to check that there is no gas leakage.
  - A flare nut is bound tight with a spanner to the position whose torque with a bundle increases suddenly.
  - Only the angle of a right table is further bound tight from the position.

PIPING SIZE (mm)	FURTHER TIGHTENING ANGLE	RECOMMENDED ARM LENGTH OF TOOL
Ø6.4	60 to 90 degrees	About 150 mm
Ø9.5	60 to 90 degrees	About 200 mm
Ø12.7	30 to 60 degrees	About 250 mm
Ø15.9	30 to 60 degrees	About 300 mm
Ø19.1	20 to 35 degrees	About 450 mm

### PRECAUTIONS WHEN BRAZING THE REFRIGERANT PIPINGS

- When brazing the refrigerant piping, carry out brazing work (NOTE 2) after substituting nitrogen for air (flow nitrogen into the piping and substitute nitrogen for air (NOTE 1) (see the drawing below)).


<Do not reuse joint which have been used once already>

NOTES

- The proper pressure for having nitrogen flow through the piping is approximately 0.02MPa, a pressure that makes one feel like breeze and can be obtained through a pressure reducing valve.
- Do not use flux when brazing refrigerant piping. Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux. (If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)



Do not use anti-oxidants when brazing the piping joints.  
(Residue can clog pipes and break equipment.)



## 6 AIRTIGHTNESS TEST AND AIR-PURGE

### AIRTIGHTNESS TEST


- Perform a refrigerant leakage check using nitrogen gas (airtightness test) with the outdoor unit stop valve close, to make sure there are no leakage.
- For the airtightness test, raise the pressure to the design pressure in the high pressure section (4.17 MPa). For the airtightness test, the unit passes the test if the pressure in the high pressure section does not drop for 24 hours after increasing to the design pressure. A correction is required since the pressure decreases approx. 0.01Mpa when the ambient temperature of 1°C decreases.
- If the pressure drop is confirmed, perform the airtightness test again after checking and modifying the leakage points.

### AIR-PURGE

- Evacuate by the vacuum pump for more than 2 hours until the internal pressure decreases below -0.1MPa. After that, leave it with -0.1MPa or less for more than one hour and confirm that the value of vacuum gauges does not increase.
- If the value of vacuum gauge increases, there is moisture inside the refrigerant piping or there are leakage points. Perform evacuation again after checking and improving the leakage points.

#### NOTE

After doing an air-purge with a vacuum pump, the refrigerant pressure may not rise even if the stop valves are opened. This is because the refrigerant piping path is closed off by the outdoor unit electronic expansion valve, etc. There are no problems if the outdoor unit is running.




## 7 CHARGING REFRIGERANT (1/2) < Be sure to use R32 as refrigerant. >

### ADDITIONAL REFRIGERANT CHARGING

This model is chargeless type, so it is not necessary to charge additionally if pipe does not exceed the maximum allowable length without additional charge.

Please refer to the following table about the maximum allowable length without additional charge.

Liquid piping size	Length for which additional charging is not required
ø6.4mm x t 0.6mm	10m



When piping length exceeds its of a top table,

or only when you perform recharging, Please be correctly charged according to the following.

For future servicing, please describe the amount of additional refrigerant charging, or the amount of recharging in the collective label in accessory set or back side of right side plate.

#### • In case of additional refrigerant charging

Please select the amount of additional refrigerant which suited piping length from the following table, and add it from the service port of liquid stop valve.

Outdoor units type	Liquid piping size	Length for which additional charging is not required	Length of piping exceeding the length for which additional charging is not required, R32 additional amount (kg)
			30m or less
RZCMF50 / 71CV16	ø6.4mm x t 0.6mm	10m	20 g per meter(For Piping Length Exceeding 10 m)

#### • Total refrigerant charging (When recharging due to exchange compressor, etc.)

Please charge refrigerant base on pipe length mentioned on the following table.

Outdoor units type	Liquid piping size	Piping length, R32 complete additional amount (kg)		
		5m~10m	20m or less	30m or less
RZCMF50 / 71CV16	ø6.4mm	1.40	1.60	1.80


When recharging refrigerant, follow the procedure below.

G In case of recharge refrigerant (cause of refrigerant leak)  
please follow suggestion below (reference detail from service guide)  
• In case of outdoor PCB (A1P) set refrigerant recovery mode at ON  
please press switch (BS 1 for RZCMF50 / 71CV16) for 5 second.

- ② Shut down the power at least 1 minute after setting process (1) is performed.
  - If the power is turned on before the process (3) - (6) are completed, the refrigerant recovery mode is turned off and the refrigerant cannot be recovered or charged normally. If the power is turned on by necessary, turn on Refrigerant recovery mode again.
- ③ Recover the refrigerant from both the gas stop valve service port simultaneously until the pressure drops below 0.09MPa (gauge pressure: -0.011MPa) by using a refrigerant recovery machine.
- ④ Modify the leakage points.
- ⑤ Perform the airtightness test and air-purge accordance with (6)AIRTIGHTNESS TEST AND AIR-PURGE.
- ⑥ Charge the refrigerant from the service port of the gas side stop valve when recharging refrigerant.

(Note) Do not turn on power during evacuation.

The motor may be damaged due to vacuum discharge.



Be sure to write down the additional amount of refrigerant charged or the entire amount re-charged on the precaution plate on the rear of the front panel, as this information is needed in case of after-sales service.

## 7 CHARGING REFRIGERANT (2/2)

### Precautions when adding R32

#### Charging a cylinder with an attached siphon



Stand the cylinder upright at charging.

(There is a siphon piping inside, so that cylinder need not be upside-down to charge with liquid.)

- To prevent entry of any impurities and ensure sufficient pressure resistance, always use the special tools dedicated for R410A or R32.
- The refrigerant should be charged from the service port of the liquid side stop valve.

#### Charging other cylinders



Stand the cylinder upside-down and charge.

(Turn the cylinder upside-down at charging.)

### WARNING

#### To persons incharge of piping work

- Please be sure to open a stop valve after a refrigerant charging end (if it operates shut, a compressor will break down).
- After complete charging of refrigerant carry out refrigerant leak check and heat insulation work.
- Please do not emit a refrigerant into the atmosphere indiscriminately.

## 8 ELECTRICAL WIRING WORK (1/3)

### WARNING

- Install the earth leakage circuit breaker. (A duty of installation of a earth leakage circuit breaker is imposed for an electric shock and fire accident prevention.  
The inverter is provided in the air conditioner. In order to prevent malfunction of the earth leakage breaker itself, use a breaker resistant to higher harmonics).
- Electrical wiring must be carried out by qualified personnel.
- Before obtaining access to terminal devices, all supply circuits must be interrupted.


### CAUTION

#### To the electrician

- Make sure to install a current balance type earth leakage breaker coping with high harmonics.  
(This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)
- Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)
- Do not remove the thermistors or sensors when the power supply and transmission wiring are connected.  
(Operating the unit with the thermistors and sensors removed will break the compressor.)
- Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.
- An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.
- The wiring between the indoor unit and outdoor unit must be for 220-240V.
- For electric wiring work, refer to also the " WIRING DIAGRAM ".
- When doing the electrical wiring, always shut off the power source before working, and do not turn on the branch switch until all work is complete.
- Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.
- Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring.
  - Gas piping.....Ignition or explosion may occur if the gas leaks.
  - Water piping.....Hard vinyl tubes are not effective earths.
  - Lightning conductor or telephone earth wiring.....Electric potential may rise abnormally if struck by a lightning bolt.
- The earth is needed in order to reduce the noise generated by the unit's inverter and influence on other appliances and to release the charged electric charge on the outdoor unit surface by leaked current.
- Do not install a phase advance capacitor for improvement of power factor. Since this unit is mounted with an inverter device, the effect of power factor improvement not only cannot be expected, but also there is a risk of the capacitor getting abnormally overheated due to harmonics.
- Be sure to use earth leakage breaker dedicated for earth leakage protection in combination with the load break switch with fuse or breaker for wiring.
- In case of three-phase. Machine, electric wiring must be connected in normal phase connection.
- For wiring, use the designated power supply wiring and connect firmly, then secure to prevent external force being exerted on the terminal attachment (power supply wiring, transmission wiring, earth wiring).
- Left-over wiring should not be wrapped and stuffed into the outdoor unit.
- To prevent the power wiring from being damaged by the knock hole edges, put it in a wiring piping or use insulated bush, etc. to protect it.
- To prevent the wiring from coming in contact with piping (particularly the high-pressure piping), secure it with the included clamping material as shown page 32.
- When wiring, form the wiring so that the front plate does not float and make sure the front plate is securely fastened.
- Fix the power supply wiring, the earth wiring and the transmission wiring by clamps as shown in the figure.


## 8 ELECTRICAL WIRING WORK (2/3)

- As shown in the following figure, please fix power supply wiring, field wiring and ground wire by clamp material.



- Carry out insulated processing of attaching an insulated sleeve.  
Power supply wiring, wiring between units and ground tying with clamp as shown below.

**⚠ Do not connect power supply to terminal block of transmission wiring. All system may get damaged.**




RZCMF50/71CV16

### Connection of wiring

### Precautions on wiring

- Use a round crimp-style terminal for connection to the power supply terminal board.  
In case it cannot be used due to unavoidable reasons, be sure to observe the following instruction.
- Do not connect wires of different gauge to the same power supply terminal.  
(Looseness in the connection may cause overheating.)



## 8 ELECTRICAL WIRING WORK (3/3)

When connecting wires of the same gauge, connect them according to the below figure.

Connect wires  
of the same  
gauge to both sides



Do not connect  
wires of different  
gauges



Do not connect  
wires of the same  
gauge to one side



- Never use the stranded wiring which is soldered.  
(Slack in the electric wiring may cause abnormal heat.)
- Use the required wirings, connect them securely and fix these wirings so that external force may not apply to the terminals.
- Use a proper screw driver for tightening the terminal screws.  
If an improper screw driver is used, it may damage the screw head and a proper tightening cannot be carried out.
- If a terminal is over tightened, it may be damaged. Refer to the table shown below for tightening torque of terminals.

Tightening torque (N·m)	
M4 (Wire between units terminal board)	1.50±0.30
M4 (Power supply terminal board)	1.50±0.30
M4 (Ground wire between units)	1.69±0.25
M5 (Ground wire between units)	3.55±0.50


### Precautions on connecting terminal of grounding

- Ground wiring should be taken out from the cut out section of a cup washer.  
(Otherwise, contact of ground wiring is inadequate and it is ineffective.)



### WIRING OF POWER SUPPLY AND THE UNITS

For details on the wiring of the indoor unit and wiring between units refer to the installation manual of the indoor unit.



### ● SPECIFICATIONS OF STANDARD WIRING COMPONENTS

Outdoor Unit	Power supply			Wire type of wiring between the units
	Recommended field fuse	Wire type (*)	Size	
RZCMF71CV16 RZCMF50CV16	20	H05VV-U3G	Wiring size and length must comply with local codes or IEC 60335-1 (Table 11)	H05VV-U4G2.5

(\*) Only in protected piping, use H07RN-F when protected pipes are not used.  
(Supply cords shall not be lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC 57))

### NOTES

- Select and install the power supply wiring in accordance with [IEC 60335-1 (Table 11)] or local laws and regulations. The maximum current of the outdoor and indoor units are shown on each name plate.
- When installing wiring in a location that can easily come in contact with people, be sure to install an earth leakage breaker coping with high harmonics to prevent electric shock.
- Breaker type and capacity shall be selected in accordance with local laws and regulations.

### CAUTION

#### TO PERSONS INCHARGE OF ELECTRICAL WIRING WORK

- Do not operate the unit until the refrigerant charging is completed. (Running it before the piping is ready will break the compressor.)

## 9 CHECK ITEMS BEFORE TEST OPERATION AND FIELD SETTINGS

### PRE-RUN CHECKS

	ITEM TO CHECK	CHECK
Power supply Wiring	Is the wiring as mentioned on the wiring diagram? make sure no wiring has been forgotten and that there are no missing phases or reverse phases.	
	Does wiring between units put in and changed in continuation installation?	
	Is the unit properly grounded?	
	Are any of the wiring attachment screws loose?	
	Is the insulation resistance at least $1M\Omega$ ? <ul style="list-style-type: none"> <li>• Use a 500V mega-tester when measuring insulation</li> <li>• <del>•</del> Do not use a mega-tester to low voltage circuit except 220-240V.</li> </ul>	
	Is an earth leakage circuit breaker used as a current operated type which is compatible to the higher harmonic wave?	
	Does the earth leakage circuit breaker have appropriate rated current?	
Refrigerant piping	Is the size of the piping appropriate?	
	Is the insulation material for the piping attached securely?	
	Are both the liquid and gas pipes insulated?	
Extra refrigerant	Are the stop valves for both the liquid side and the gas side open?	
	Did you write down the extra refrigerant and the refrigerant piping length?	
Indoor unit	Is the indoor unit fully installed? When the test run is started, the fan automatically begins turning.	

### WARNING

- When a power supply is switched on, when you leave from the outdoor unit, be sure to close the cover plate.  
(It becomes the cause of an electric shock.)

In field setting for an outdoor unit, make sure to shut down the power and check that there is no residual voltage before start installing. (It may cause an electric shock.)

## 10 TEST OPERATION


### WARNING

- Never perform a test operation with the discharge piping thermistor(R2T) and suction piping thermistor(R3T) removed, as this might break the compressor.
- If the technician must leave the outdoor unit for some reason, switch places with another installation technician or close the plates. (It may cause electric shocks.)

#### HOW TO TEST OPERATION

After the indoor and outdoor unit installation, be sure to perform the test operation in accordance with the following procedure.

- Open the stop valve cover and check that the liquid and gas sides of the stop valves are open.  
<Be sure to close the front plate before the operation (there is a risk of electric shock)>  
Note: After doing an air-purge with a vacuum pump, the refrigerant pressure may not rise even if the stop valves are opened. This is because the refrigerant piping path is closed off by the outdoor unit electronic expansion valve, etc. There are no problems if the unit is run.
- Attach the stop valve cover to the outdoor unit and turn the power on at least 6 hours before operating the outdoor unit to protect the compressor.
- Set to COOLING operation with the remote controller.
- Perform the test operation
  - When doing trial operation, it may take about 1 minute until the compressor begins to function, but this is not abnormal.
  - When using the system the first time after installation, even if heating operation is selected, cooling operation will take place for about 3 to 5 minutes.  
Thereafter, it will change to heating operation, but this is not abnormal.  
(In this case, the remote controller display will continue to display "heating operation.") This is in order to detect if someone has forgotten to open the stop valve during trial operation.
  - If the outside air temperature is about 24°C or more, even if HEATING operation is set, the system may not operate, but this is not abnormal.
- Operate normally.
- Confirm function of the indoor and outdoor units according to the operation manual.



#### MALFUNCTION DIAGNOSIS

- At the time of a test run, when the following malfunction code is displayed on remote control, the fault of installation construction can be considered.

Malfunction code	Installation error	Remedial action
[E3] [E5] [U0] [L8]	A failure of a stop valve to open	"Open" operation of a stop valve
[E3] [E5] [L4] [L8]	Closing of an air passage	Removing closing thing from air passage
[U1]	Missing phase, negative phase	2 Phase of power supply 3 Phase (L1, L2, L3 Phase) are replaced
[U2]	Power supply unbalancing	Unbalanced dissolution
[U4] [UF]	Incorrect connection of field wiring	Correction of wiring
[UA]	Connection of incompatible indoor unit	Connect appropriate indoor unit (Refer to the catalogue)
NO INDICATION	Mistake wiring or not connect wiring of power supply, indoor, outdoor, field wiring between indoor unit	To correct wiring or connect correctly

- When malfunction codes other than the above are displayed on remote control, considering that the failure of between an indoor and an outdoor unit may have.

For the malfunction codes, please refer to the indoor unit's installation manual or outdoor service manual.  
(A malfunction code has what has a display according to the form of the interior of a room and an outdoor unit, and the thing which is not.)

- The followings can be considered causes when the breaker for power supply trips.
  - The capacity of a breaker for power supply is smaller than the required capacity of the leakage circuit breaker.
  - The leakage circuit breaker is not compatible to the higher harmonic wave.
- In case of already checking all equipment that not have any problem, but found air conditioner not cooling.  
Please re-check Motor operate valve coil not tighten or remove for 1<sup>st</sup> checking. If normally please re-confirm problem following service manual to solve problem.

### CAUTION

#### To persons incharge of piping work and electric work

- Please check having attached the front board and the piping cover after a test run end when giving production over to customer.

## 11 CAUTION (RZCMF50/71CV16)

**THIS IS NECESSARY FOR AFTER SERVICE, SO PLEASE REQUEST CUSTOMER TO KEEP THIS MANUAL.**

### CAUTION (NEW REFRIGERANT (R32 SERIES))



**WARNING**



**ELECTRIC SHOCK CAUTION**

#### Caution about electric shock when do service inspection

1. After intercept power supply, do not open outside panel for 10 minutes.
2. Follow manufacturing label on electric box cover, please take off outdoor fan motor connector to confirm voltage and body static electricity discharge.

#### General caution items when do service inspection

##### Caution to confirm compressor and fan motor running

Do not directly connect power input (3 Phase 50Hz) to compressor and fan motor. (If not connect to print board (PCB), compressor and fan motor will be burned out.)

##### Caution when recharge refrigerant

1. To prevent the mixing of impurities, pressure resistance and contamination mix, please use manifold gauge especially for R32.
2. Make sure to do Nitrogen blow if brazing when flare connection. Apply ether oil or ester oil at inside flare only.
3. Do air tight test at 4.17Mpa.
4. Do dry vacuum, make sure to charge refrigerant in liquid condition from liquid side service port. (Compressor will be broken if charge from gas side service port.)

##### Caution when use outdoor PCB

Make sure to touch earth terminal and earthed metal before touch pcb, to prevent electric shock

##### Caution when break down diagnosis from letter code in remote control

Please refer to service guide or outdoor unit installation manual.

### Charging refrigerant

#### Charging the system with refrigerant

(For more information such as calculation method of additional refrigerant charge, additional charge method, refrigerant charge caution, refer to the installation manual and technical Guide.)



- For refrigerant charge, be sure to charge from the service port of the liquid side stop valve in liquid states. (If you charge from the service port of the gas side stop valve, it may break the compressor.)
- Never charge other than the specified refrigerant. (It may cause fire and bursting.)

**Table 1. Chargeless piping length**

Liquid piping size	Pipe length which is not required additional charging
Ø 6.4 mm x 0.6mm	10m

#### 1. In case of additional refrigerant charging

Please add refrigerant amount according to the following table.

Outdoor	Liquid piping size	Pipe length which is not required additional charging	Pipe length over chargeless R32 additional amount (kg)
RZCMF50/71CV16	Ø 6.4 x 0.6mm	10 m	+15m or less +20m or less

#### 2. Total refrigerant charging (Details please see service guide)

1. Please recover the refrigerant until becoming 0.09MPa (gauge pressure:-0.01MPa) or less by the refrigerant recovery machine from stop valve service port (Liquid-gas side) at the same time.
2. Exchange service parts, modify leak point.
3. Perform airtightness test, air-purge.
4. Charge refrigerant amount selected by table 2 from liquid stop valve service port.

Caution Do not turn on power during evacuation. The motor may be damaged due to vacuum discharge.

**Table 2. Charge refrigerant amount (After a leak, etc..)**

Outdoor	Liquid piping size	Piping length, R32 complete additional amount (kg)		
		5~10m	15m or less	30m or less
RZCMF50/71CV16	Ø 6.4 x 0.6mm	1.40	1.50	1.80

#### • Making a record of the added refrigerant charge amount

Be sure to record the piping length and added refrigerant charge amount or refrigerant recharge amount with an oil-based or other indelible marker so the figures will not fade over time. This information is necessary for after service and maintenance.

Liquid piping size	Ø 6.4 mm x 0.6mm		
Refrigerant piping length	m		
Additional refrigerant charging	kg		
Recharge of refrigerant	kg		

### How to execute a pumping-down

(for example, when moving or reinstalling an indoor or outdoor unit)


The outdoor unit is equipped with a high pressure switch to protect the compressor.

**Caution** Never short circuit the high pressure switch during pump-down operation.

- It is not allowed to let the refrigerant out into air. The refrigerant should be recovered completely.
- Although pumping-down operation allows most of the refrigerant to be recovered in a short period of time, some refrigerant will remain inside the indoor unit and the refrigerant piping. Using a refrigerant recovery machine, recover remaining refrigerant from the stop valve service port until the pressure falls to 0.09MPa (gauge pressure:-0.01MPa) or less
- Be sure to execute the pumping-down before refrigerant piping and wiring is taken off.

#### For pumping-down operation

1. Please follow the [ caution about electric shock when service inspection] which attached on Top panel (Caution: Do not take off the connector X106A)
2. To prevent electric shock, please protect power input terminal block by insulation sheet refer to below figure.
3. Turn on the power supply and carry out pumping-down operation according to the following procedure.



**Caution** To prevent electric shock when inspection, protect by use insulation sheet on power input terminal block and print board (A2P)

#### For pumping-down operation

**Caution** Do not remove the indoor unit until pump down operation finish. (It is dangerous when indoor fan automatically starts the operation.)

Perform pumping-down operation using the following procedure

Procedure	Precaution
1 Confirm that stop valves both on the liquid and gas sides are open	-
2 Push the pumping-down (BS1) on the PC board of the outdoor unit for 5 seconds.	Compressor and outdoor unit fan will start operation automatically. Indoor fan may automatically start running. Pay attention to this.
3 Close the stop valve on the liquid side securely about 2 minutes after the compressor started operation.	<ul style="list-style-type: none"> <li>• Do never leave the outdoor unit unattended with opened front plate when power supply is on.</li> <li>• In case the stop valve on the liquid side is not securely closed during compressor operation, pumping-down operation cannot be executed</li> </ul>
4 Turn off the power supply.	When you work alone, carry out after closing the front plate. After turning the power supply off, remove the insulation sheet.

- If after finishing pumping-down operation the outdoor unit does not operate, even when the remote controller switched on, the remote controller may or may not indicate "U4". But it is not a malfunction.

- To force of operation, turn off the main power supply and turn it on again. Make sure that stop valves both on liquid and gas sides are open and be sure to operate the unit in cooling operation during test run.

Liquid stop valve




Gas stop valve



**Caution** When installing and relocating, be sure to install the earth leakage breaker to protect from the electric shock disaster and fire due to leakage of electricity. For installing the earth leakage breaker, request to the qualified electrician.

## 12 HOW TO RE-USE THE EXISTING PIPING



### PRECAUTIONS ON REFRIGERANT PIPING

- Clean pipe if existing air conditioner is [gas, oil heat pump type].
- Clean pipe if used compressor oil in existing air conditioner is other than [SUNISO, MS, HAB, Barrel freeze, JOMO, Ethereal oil, Ester oil].
- Clean pipe if existing indoor and outdoor unit is disconnected.
- Change new pipe if refrigerant leakage or it should adding refrigerant.
- Change new heat insulation if existing part is peeling off.

## 13 REFRIGERANT RECOVERY


### [Working procedure]

1. Recovery retaining oil in existing pipe Approx. 1 min  
Close gas stop valve (liquid stop valve: open)  
and recovery refrigerant from gas stop valve port.(Fig.1)
2. Recovery retaining oil in existing liquid pipe Approx. 1 min  
Recovery refrigerant from liquid stop valve port. (Fig.2)
3. Recovery refrigerant in outdoor unit Approx. 2-3 min  
Recovery refrigerant from outdoor unit refrigerant recovery port \*1 .(Fig.3)
4. Recovery refrigerant in accordance with Fluorocarbons Recovery and Destructive Law  
If refrigerant recovery port \*2 pressure become lower than gas stop valve port pressure, refrigerant will recover at the simultaneous from the gas stop valve port, open gas stop valve (Fig.3- 1 ) gradually to avoid from pressure rising rapidly. (Fig.3- 2 )

NOTE 1 Can be omit this procedure if there is no refrigerant recovery port  
NOTE 2 Can be omit this procedure if there has no refrigerant recovery port simultaneously if there has no refrigerant recovery port.

Retaining oil recovery amount improved  
approx. 5 times from regular refrigerant  
recovery method

(pipe length, height difference, pipe path etc. is difference by installation condition)



### ABOUT FLARE PROCESSING

- Flare connection area of existed piping will cause processing deterioration, make sure to do newly re-processing.
- Flare processing [Unit: mm]



6.4

- Please use flare nut which attached with product  
(Do not use existed flare nut)
- Flare nut  
[Unit: mm]



Piping outside diameter	B (+0,-0.6)
For R32	
Ø 6.4	17
Ø 15.9	29

## REFRIGERANT PIPE SIZE TABLE

Outdoor Unit	Existing pipe size	6.4/15.9	Height difference	Design pressure (High pressure)
RZCMF71CV16 RZCMF50CV16	Standard pipe length	7.5 m	Max 20m	4.17 MPa
	Max. pipe length	30m		
	Chargeless pipe length	10m		


- Refer to the installation manual for details other than those mentioned above table such as additional refrigerant charge amount.
- Clean the existing piping if it length is exceed 30m.
- Clean the existing pipe if chargeless length is exceed limit of existing pipe pump down refrigerant recovery.

#### ■ Standard pipe (R32)


Pipe size (mm)	Ø 6.4	Ø 15.9
Thickness (mm)	t 0.6	t 1.0

## 14. Unpacking & Packing of the Outdoor Unit

### 14-1 Unpacking




- Cut all the straps (a) from the unit using strap cutter(b) as shown in figure.




- Remove the cardboard box(c) from the unit after opening it and pulling it up as shown in figure.

3




- Remove the bottom skid(d) with EPS by pulling the unit up, then remove the polythene product cover by pulling it up

4




## 14-2 Packing

1



- a) Strap
- b) Starp Cutter
- c) Cardboard box
- d) Bottom Skid
- e) Portable strap fixing machine


2



- Cover the unit with polythene product cover, then pick the unit up and settle it down on the bottom skid(d) as shown in figure.

- Put the cardboard box (c) upon the unit as shown in figure.

3



- Fix the straps (a) on the unit by using portable strap fixing machine as shown in figure.(Use marked reference for placing straps)

**DAIKIN AIRCONDITIONING INDIA PVT. LTD.**

12th Floor, Building No. 9, Tower A,  
DLF Cyber City, DLF Phase - III  
Gurgaon - 122002, Haryana (India)  
Tel : +91-124-4555444  
Fax: +91-124-4555333

**SPLIT SYSTEM****Air Conditioners****MODEL****Ceiling mounted cassette type (Non Sensing flow model)**

**FCVFQ50AV16**  
**FCVFQ71AV16**  
**FCVFQ90AV16**  
**FCVFQ100AV16**  
**FCVFQ125AV16**  
**FCVFQ140AV16**  
**FCFQ90AV16**  
**FCFQ100AV16**  
**FCFQ125AV16**  
**FCFQ140AV16**  
**FCFQ71CV16**  
**FCFQ90CV16**  
**FCMF71CV16**  
**FCMF50CV16**  
**FCFQ36CV1**  
**FCFQ48CV1**

**English**

---

**READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION.  
KEEP THIS MANUAL IN A HANDY PLACE FOR FUTURE REFERENCE.**

---

## CONTENTS

1. SAFETY PRECAUTIONS	61
2. BEFORE INSTALLATION	63
3. SELECTING INSTALLATION SITE	65
4. PREPARATIONS BEFORE INSTALLATION	67
5. INDOOR UNIT INSTALLATION	69
6. REFRIGERANT PIPING WORK	71
7. DRAIN PIPING WORK	73
8. ELECTRIC WIRING WORK	77
9. WIRING EXAMPLE	80
10. INSTALLATION OF THE DECORATION PANEL	80
11. FIELD SETTING	81
12. TEST OPERATION	83
13. HOW TO RE-USE EXISTING PIPING	88
14. REFRIGERANT RECOVERY	89

## 1. SAFETY PRECAUTIONS



Read the precautions in this manual  
carefully before operating the unit.



This appliance is filled with R32.

Please read these "SAFETY PRECAUTIONS" carefully before installing air conditioning equipment and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation.

After completing installation, conduct a trial operation to check for faults and explain to the customer how to operate the air conditioner and take care of it with the aid of the operation manual. Ask the customer to store the installation manual along with the operation manual for future reference.

This air conditioner comes under the term "appliances not accessible to the general public".

Please instruct the customer on how to operate the unit and keep it maintained.

Also, inform customers that they should store this installation manual along with the operation manual for future reference.

Meaning of WARNING and CAUTION notices.

**⚠ WARNING** ..... Failure to follow these instructions properly may result in personal injury or loss of life.

**⚠ CAUTION** ..... Failure to observe these instructions properly may result in property damage or personal injury,  
which may be serious depending on the circumstances.

### ⚠ WARNING

- Ask your dealer or qualified personnel to carry out installation work.  
Do not attempt to install the air conditioner yourself. Improper installation may result in water leakage, electric shocks or fire.
- Install the air conditioner in accordance with the instructions in this installation manual.  
Improper installation may result in water leakage, electric shocks or fire.
- Be sure to use only the specified accessories and parts for installation work.  
Failure to use the specified parts may result in the unit falling, water leakage, electric shocks or fire.
- Install the air conditioner on a foundation strong enough to withstand the weight of the unit.  
A foundation of insufficient strength may result in the equipment falling and causing injury.
- Carry out the specified installation work after taking into account strong winds, typhoons or earthquakes.  
Failure to do so during installation work may result in the unit falling and causing accidents.
- Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations and this installation manual.  
An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire.
- Make sure that all wiring is secured, the specified wires are used, and that there is no strain on the terminal connections or wires.  
Improper connections or securing of wires may result in abnormal heat build-up or fire.
- When wiring the power supply and connecting the wiring between the indoor and outdoor units, position the wires so that the control box lid can be securely fastened.  
Improper positioning of the control box lid may result in electric shocks, fire or overheating terminals.

- If refrigerant gas leaks during installation, ventilate the area immediately.  
Toxic gas may be produced if the refrigerant comes into contact with fire.
- After completing installation, check for refrigerant gas leakage.  
Toxic gas may be produced if the refrigerant gas leaks into the room and comes into contact with a source of fire, such as a fan heater, stove or cooker.
- When installing or relocating the air conditioner, be sure to bleed the refrigerant circuit to ensure, it is free of air, and use only the specified refrigerant (R32).  
The presence of air or other foreign matter in the refrigerant circuit causes abnormal pressure rise, which may result in equipment damage and even injury.
- Be sure to switch off the unit before touching any electrical parts.
- Do not directly touch refrigerant that has leaked from refrigerant pipes or other areas, as there is a danger of frostbite.
- Be sure to earth the air conditioner.  
Do not earth the unit to a utility pipe, lightning conductor or telephone earth lead.  
Imperfect earthing may result in electric shocks or fire.  
A high surge current from lightning or other sources may cause damage to the air conditioner.
- Be sure to install an earth leakage breaker.  
Failure to install an earth leakage breaker may result in electric shocks or fire.
- Consult your local dealer regarding what to do in case of refrigerant leakage. When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen depletion.
- Do not allow children to climb on the outdoor unit and avoid placing objects on the unit.  
Injury may result if the unit becomes loose and falls.
- The appliance must be stored in a room without continuously operating ignition sources (for example : open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerant may not contain an odour.
- Floor area required for installation of the equipment, refer to the installation manual of the outdoor unit.
- Comply with national gas regulations.
- When flared joints are reused indoors, the flare part shall be re-fabricated.

## CAUTION

- While following the instructions in this installation manual, install drain piping to ensure proper drainage and insulate piping to prevent condensation.  
Improper drain piping may result in indoor water leakage and property damage.
- Install the indoor and outdoor units, power cord and connecting wires at least 1 meter away from televisions or radios to prevent picture interference and noise.  
(Depending on the incoming signal strength, a distance of 1 meter may not be sufficient to eliminate noise.)
- Remote controller (wireless kit) transmitting distance can be shorter than expected in rooms with electronic fluorescent lamps (inverter or rapid start types). Install the indoor unit as far away from fluorescent lamps as possible.
- In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals.  
Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- Install in a machine room that is free of moisture. The unit is designed for indoor use.
- Disposal requirements  
Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.
- The refrigerant R32 requires that strict precautions be observed for keeping the system clean, dry and tightly sealed.
  - A. Clean and dry  
Strict measures must be taken to keep impurities (including SUNISO oil and other mineral oils as well as moisture) out of the system.
  - B. Tightly sealed  
R32 contains no chlorine, does not destroy the ozone layer and so does not reduce the earth's protection against harmful ultraviolet radiation. R32 will contribute only slightly to the greenhouse effect if released into the atmosphere.
- Do not install the air conditioner in the following locations:
  1. Where there is a high concentration of mineral oil spray or vapour (e.g. a kitchen).  
Plastic parts will deteriorate, parts may fall off and water leakage could result.
  2. Where corrosive gas, such as sulphurous acid gas, is produced.  
Corroding of copper pipes or soldered parts may result in refrigerant leakage.
  3. Near machinery emitting electromagnetic radiation.  
Electromagnetic radiation may disturb the operation of the control system and result in a malfunction of the unit.
- 4. Where flammable gas may leak, where there is carbon fibre or ignitable dust suspensions in the air, or where volatile flammables such as paint thinner or gasoline are handled.  
Operating the unit in such conditions may result in fire.
- The air conditioner is not intended for use in a potentially explosive atmosphere.
- Only qualified personnel can handle, fill, purge and dispose of the refrigerant.
- Important information regarding the refrigerant used.  
This product contains fluorinated greenhouse gases covered by the Kyoto protocol. Do not vent gases into the atmosphere.  
Refrigerant type: R32  
GWP<sup>(1)</sup> value: 675\*
- The refrigerant quantity is indicated on the unit name plate.  
\*This value is based on F gas regulation (842/2006).

## 2. BEFORE INSTALLATION

**Do not exert pressure on the resin parts when opening the unit or when moving it after opening. Be sure to check the type of R32 refrigerant to be used before doing any work. (Using an incorrect refrigerant will prevent normal operation of the unit.)**

- When opening the unit or moving it after opening, be sure to lift it by holding on to the hanger bracket without exerting any pressure on other parts, especially, drain piping, and other resin parts.
- Leave the unit inside its packaging while moving, until reaching the installation site. Use a sling of soft material, where unpacking is unavoidable or protective plates together with a rope when lifting, to avoid damage or scratches to the unit.
- Refer to the installation manual of the outdoor unit for items not described in this manual.
- Do not dispose of any parts necessary for installation until the installation is complete.
- In order to protect the indoor unit from damage, use packing materials to protect the unit after carrying until the installation starts.
- When selecting installation site, refer to the paper pattern.
- Do not use the unit in locations with high salt content in the air such as beachfront property, locations where the voltage fluctuates such as factories, or in automobiles or marine vessels.
- Do not install accessories on the casing directly. Drilling holes in the casing may damage electrical wires and consequently cause fire.

### 2-1. ACCESSORIES

**Check the following accessories are included with your unit.**

**(Do not dispose of any parts necessary for installation until the installation is completed.)**

Name	(1) Drain hose	(2) Metal clamp	(3) Paper pattern for installation	(4) washer fixing plate	(5)Insulation for fitting
Quantity	1 pc.	1 pc.	1 pc.	4 pcs.	1 each
Shape					 (6) For gas pipe (7) For liquid pipe

Name	Sealing pad			(Other)
	Quantity	1 each	1 pc.	1 pc.
Shape	(8) Large 	(11) Small 	(12) 	• Installation manual • Operation manual

### 2-2. OPTIONAL ACCESSORIES

- The optional decoration panel and remote controller are required for this indoor unit. (Refer to Table 1, 2)
- Check that the decoration panel is prepared.  
(For the installation of the decoration panel, refer to the installation manual attached to the decoration panel.)

**Table 1**

Cassette IDU Accessories		
Name of option	Remark	Model No.
		FCFQ90,100,125,140AV16; FCVFQ50,71,90,100,125,140AV16; FCFQ71/90CV16,FCMF71/90CV16
Standard Panel	Fresh White	BYCQ125EAF6
Sealing material of air discharge outlet (Note 1)	1 Outlet	KDBH551C160
	2 Outlet	KDBH552C160
Panel spacer		KDB55J160F
Insulation kit for high humidity		KDTP55K80B

**NOTE** 

- If you wish to use a optional decoration panel that is not listed in "Table 1" on page 39, select a suitable remote controller after consulting catalogs and technical materials.
- Refer table 2 for remote controller install in an appropriate place.

(For the installation of the remote controller, refer to the installation manual attached to the remote controller.)

**Table 2**

Remote controller				
Wireless type	Cooling only	Remote	BRCA91A152	
		Receiver kit	BRCA7M632F-6	

**NOTE** 

- If you wish to use a remote controller that is not listed in "Table 2" on page 39, select a suitable remote controller after consulting catalogs and technical materials.

**FOR THE FOLLOWING ITEMS, TAKE SPECIAL CARE DURING CONSTRUCTION AND CHECK AFTER INSTALLATION IS FINISHED.**

**1. Items to be checked after completion of work**

Items to be checked	If not properly done, what is likely to occur	Check
Are the indoor unit and outdoor unit fixed firmly?	The unit may drop, vibrate or make noise.	
Is the outdoor unit fully installed?	The unit may malfunction or the components burn out.	
Is the gas leak test finished?	It may result in insufficient cooling.	
Is the unit fully insulated?	Condensate water may drip.	
Does drainage flow smoothly?	Condensate water may drip.	
Does the power supply voltage correspond to that shown on the name plate?	The unit may malfunction or the components burn out.	
Are wiring and piping correct?	The unit may malfunction or the components burn out.	
Is the unit safely grounded?	It may result in electric shock.	
Is wiring size according to specifications?	The unit may malfunction or the components burn out.	
Is something blocking the air outlet or inlet of either the indoor or outdoor units?	It may result in insufficient cooling.	
Are refrigerant piping length and additional refrigerant charge noted down?	The refrigerant charge in the system is not clear.	

## 2. Items to be checked at time of delivery

\* Also review the "1. SAFETY PRECAUTIONS"

Items to be checked	Check
Has the field setting done (as necessary)?	
Did you attach the control box lid, the air filter, and suction grille?	
Does the cold air blow properly during the cooling operation?	
Did you explain about operations while showing the instruction manual to your customer?	
Did you hand the instruction manual over to your customer?	

### Points for explanation about operations

The items with **△ WARNING** and **△ CAUTION** marks in the instruction manual are the items pertaining to possibilities for bodily injury and material damage in addition to the general usage of the product. Accordingly, it is necessary that you make a full explanation about the described contents and also ask your customers to read the instruction manual.

## 2-3. NOTE TO THE INSTALLER

Be sure to instruct customers how to properly operate the unit (especially cleaning filters, operating different functions, and adjusting the temperature) by having them carry out operations themselves while looking at the manual.

## 3. SELECTING INSTALLATION SITE

(Hold the unit by the 4 lifting lugs when opening the box and moving it, and do not exert pressure on to any other part piping (refrigerant, drain, etc.) or plastic parts.

If the temperature or humidity inside the ceiling might rise above 30°C or RH 80%, respectively, use the high-humidity kit (sold separately) or add extra insulation to the main unit body.

Use glass wool or polyethylene foam as insulation and make sure it is at least 10 mm thick and fits inside the ceiling opening.)

**The direction this product blows can be selected. However, a separately sold shut-off material kit is needed in order to make the unit blow in two, three, or four (corner shut-off) directions.**

(1) Select an installation location with the customer's approval which matches the following conditions.

- Where optimum air distribution can be ensured.
- Where nothing blocks air passage.
- Where condensate can be properly drained.
- Where the ceiling is strong enough to bear the indoor unit weight.
- Where the false ceiling is not noticeably on an incline.
- Where sufficient clearance for maintenance and service can be ensured.
- Where there is no risk of flammable gas leakage.
- Where piping between indoor and outdoor units is possible within the allowable limit.

(Refer to the installation manual for the outdoor unit.)

[Space required for installation]




Fig. 1

Model	H (mm)
BYCQ125EAF6	
FCVFQ50.71AV16,FCFQ71CV16,FCMF7 1CV16,FCMF50CV16	261
FCVFQ90.100.125.140AV16,FCFQ90.100.125.140A V16,FCFQ90CV16,FCFQ36.48CV1	303




Fig. 2

**NOTE**

- The “\*” marked space is at least 500 mm wide if the air outlet is closed. In case of also closed corner area (corner area of both left right direction for closing air outlet), it is 200 mm or more.

**CAUTION**

- Any vents, light fixtures, or other appliances which may disturb the airflow might cause the top side to become dirty if located too nearby, so follow Fig. 2 when installing.  
(Note)
  - This restriction applies to the exposed type lighting, but does not apply to the recessed type (which does not protrude below the ceiling line).
  - For how to set the airflow direction (including airflow block) with the horizontal blade, refer to “Individual Airflow Direction” in the operation manual attached to the remote controller.
- Keep indoor unit, outdoor unit, power supply wiring and transmission wiring at least 1 meter away from televisions and radios. This is to prevent image interference and noise in those electrical appliances. (Noise may be generated depending on the conditions under which the electric wave is generated, even if 1 meter is kept.)
- If installing the wireless kit, the distance of the signal sent from the remote controller might be shorter if there are fluorescent lights which are electrically started (such as with inverters, rapid starters, etc.) in the room. The indoor unit should be installed as far away from fluorescent lights as possible.

**(2) Ceiling height**

This product can be installed in ceilings up to 3.5 m high.

If the ceiling height is 2.7 m or more, field settings will have to be made with the remote controller. See “11. FIELD SETTING” for details.

**(3) Air direction**

The air direction shown in Fig. 3 is an example.

Select the appropriate number of directions according to the shape of the room and the location of the unit. (Field settings have to be made using the remote controller and the outlet vents have to be shut off if two, three, or four (corner shut-off) directions are selected. See the PPS for optional Kit (sold separately) installation manual for details.)

**(4) Use suspension bolts for installation. Check if the location for the installation is strong enough to support the weight of the unit, reinforce it if necessary, and install using suspension bolts. (The spacing of the installation is shown on the “paper pattern for installation (3)”).**




Fig. 3

## 4. PREPARATIONS BEFORE INSTALLATION

### (1) Relation of ceiling opening to unit and suspension bolt position.




Fig. 4

Decoration Panel	BYCQ125EAF6
C (mm)	125~130




Fig. 5

■ Installation is possible when ceiling opening dimensions is as follows.

- When installing the unit within the frame for fixing false ceiling.




Fig. 6




Fig. 7

**NOTE**

- Installation is possible with a ceiling dimension of 910 mm (marked with \*). However, to achieve a ceiling-panel overlapping dimension of 20 mm, the spacing between the ceiling and the unit should be 35 mm or less. If the spacing between ceiling and the unit is over 35 mm, attach ceiling material to  part or recover the ceiling.




Fig. 8

**(2) Make the ceiling opening needed for installation where applicable. (For existing ceilings)**

- Refer to the paper pattern for installation (5) for ceiling opening dimensions.
- Create the ceiling opening required for installation. Implement the refrigerant and drain piping and wiring between IDU and ODU refer to "6. REFRIGERANT PIPING WORK", "7. DRAIN PIPING WORK" and "8. ELECTRIC WIRING WORK".
- After making an opening, it may be necessary to reinforce the ceiling beam to keep the ceiling level and to prevent it from vibrating. Consult the builder for details.

**(3) Install the suspension bolts.**

- Use M8 or M10 bolts for hanging the indoor unit. Use a hole-in anchor for existing ceilings, and a sunken insert, sunken anchor or other field supplied parts for new ceilings to reinforce the ceiling to bear the weight of the unit. Adjust clearance (50 – 100 mm) from the ceiling before proceeding further.

**NOTE**

- All the above parts are field supplied.




Fig. 9

## 5. INDOOR UNIT INSTALLATION


Installing optional accessories (except for the decoration panel) before installing the indoor unit is easier.

As for the parts to be used for installation work, be sure to use the provided accessories and specified parts designated by our company.

### 5.1 FOR NEW CEILINGS

#### (1-1) Install the indoor unit temporarily.

- Attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and washer from the upper and lower sides of the hanger bracket. (Refer to Fig.10)  
The washer fixing plate (4) will prevent the washer from falling. (Refer to Fig.11)



[Securing the hanger bracket]

Fig. 10



[Securing the washer]

Fig. 11

#### (1-2) Refer to the paper pattern for installation (3) for ceiling opening dimension.

Consult the builder or carpenter for details.

- The center of the ceiling opening is indicated on the paper pattern for installation.  
The center of the unit is indicated on the triangular mark to the unit bottom and on the paper pattern for installation.
- Fix the paper pattern to the unit with screws .
- Ceiling height is shown on the side of the paper pattern for installation (3). Adjust the height of the unit according to this indication.

Please perform one of the following, as the shape of the paper pattern for installation differs according to the model.




Fig. 12

[Installation of paper pattern for installation]

#### <Ceiling work>

#### (1-3) Adjust the unit to the right position for installation.

(Refer to “4. PREPARATIONS BEFORE INSTALLATION-(1)”).


- Using the installation guide allows you to check the positions from the underside of the unit to the lower ceiling surface.

**(1-4) Check the unit is horizontally level. (Refer to Fig.13)**

- The indoor unit is equipped with a built-in drain pump and float switch. Verify that it is level by using a level or a water-filled vinyl tube.

**—  CAUTION**

- The indoor unit is equipped with a built-in drain pump and float switch. Verify that it is level by using a level or a water-filled vinyl tube.  
(If the unit is tilted against condensate flow, the float switch may malfunction and cause water to drip.)



[Maintaining horizontality]

**Fig. 13**

**(1-5) Remove the washer fixing plate (4) used for preventing the washer for hanger from dropping and tighten the upper side nut.**

**(1-6) Remove the paper pattern for installation (3).**

## 5.2 FOR EXISTING CEILINGS

**(2-1) Install the indoor unit temporarily.**

Perform step (1-1) in (1) For new ceilings.

**(2-2) Adjust the height and position of the unit.**

(Refer to “4. PREPARATIONS BEFORE INSTALLATION-(1)” and (1-3) in (1) For new ceilings.)

**(2-3) Perform steps (1-4), (1-5) in (1) For new ceilings.**

**—  CAUTION**

- **Install the indoor unit leveled.**

If the indoor unit is inclined and the drain piping side gets high, it may cause malfunction of a float switch and results in water leakage.

- **Attach nuts on the upper and lower side of hanger.**

If there is no upper nut and the lower nut is over-tightened, the hanger and the top plate will deform and cause abnormal sound.

- **Do not insert materials other than that specified into the clearance between the hanger and the washer for hanger.**

Unless the washers are properly attached, the hanging bolts may come off from the hanger.

**—  WARNING**

**The indoor unit must be securely installed on a place that can withstand the mass.**

If the strength is insufficient, the indoor unit may fall down and cause injuries.

## 6. REFRIGERANT PIPING WORK

- For the outdoor unit refrigerant piping, refer to the installation manual of the outdoor unit.
- Carry out insulation of both gas and liquid refrigerant piping securely. If not insulated, it may cause water leakage. For gas piping, use insulation material of which heat resistant temperature is not less than 120°C. For use under high humidity, strengthen the insulation material for refrigerant piping. If not strengthened, the surface of insulation material may sweat.
- Before installation work, make sure that the refrigerant is R32. (Unless the refrigerant is R32, the normal operation cannot be expected.)

### - **WARNING**

**When flared joints are reused indoors, the flare part shall be re-fabricated.**


### - **CAUTION**

**This air conditioner is a dedicated model for new refrigerant R32. Make sure to meet the requirements shown below and carry out installation work.**

- Use dedicated piping cutters and flaring tools for R32 and R410A.
- When making a flare connection, coat the flared inner surface only with ether oil or ester oil.
- Use only the flare nuts attached to the air conditioner. If other flare nuts are used, it may cause refrigerant leakage.
- To prevent contamination or moisture from getting into the piping, take measures such as pinching or taping the pipings.


**Do not mix substance other than the specified refrigerant such as air into the refrigeration circuit. If the refrigerant leaks during the work, ventilate the room.**

- The refrigerant is pre-charged in the outdoor unit.
- When connecting the pipings to the air conditioner, make sure to use a spanner and a torque wrench as shown in Fig. 14.
- For the dimension of flared part and the tightening torque, refer to the Table 3.



**Fig. 14**

- When making a flare connection, coat the flared inner surface only with ether oil or ester oil. (Refer to Fig. 15) Then, turn the flare nut 3 to 4 times with your hand and screw in the nut.



**Fig. 15**

**Table 3**

Piping size (mm)	Tightening torque (N·m)	Dimension for processing flare A (mm)	Flare shape
φ 6.4	15.7 ± 1.5	8.9 ± 0.2	
φ 9.5	36.3 ± 3.6	13.0 ± 0.2	
φ 12.7	54.9 ± 5.4	16.4 ± 0.2	
φ 15.9	68.6 ± 6.8	19.5 ± 0.2	

### - **CAUTION**

**Do not have oil adhere to the screw fixing part of resin parts.**

If oil adheres, it may weaken the strength of screwed part.

**Do not tighten flare nuts too tight.**

If a flare nut cracks, the refrigerant may leak.

- If there is no torque wrench, use **Table 4** as a rule of thumb.  
When tightening a flare nut with a spanner harder and harder, there is a point where the tightening torque suddenly increases.  
From that position, tighten the nut additionally the angle shown in **Table 4**.  
After the work is finished, check securely that there is no gas leak.  
If the nut is not tightened as instructed, it may cause slow refrigerant leak and result in malfunction (such as does not cool or heat).

**Table 4**

Piping size (mm)	Tightening angle	Recommended arm length of tool used
φ 6.4	60° - 90°	approx. 150 mm
φ 9.5	60° - 90°	approx. 200 mm
φ 12.7	30° - 60°	approx. 250 mm
φ 15.9	30° - 60°	approx. 300 mm


**CAUTION**

**Insulation of field piping must be carried out up to the connection inside the casing.**


If the piping is exposed to the atmosphere, it may cause sweating, burn due to touching the piping, electric shocks or a fire due to the wiring touching the piping.

- After leak test, referring to **Fig. 16**, insulate both the gas and liquid piping connection with the attached joint insulating for fitting (6) and (7) to prevent the pipings from getting exposed.  
Then, tighten the both ends of insulating material with the clamp.
- Wrap the sealing material (Medium-1, 2) (9) (10) around the joint insulating for fitting (6) and (7) (flare nut section), both the gas and liquid piping.
- Make sure to bring the seam of joint insulating for fitting (6) and (7) to the top.

**Gas Piping Insulation Procedure**



**Liquid Piping Insulation Procedure**



**Fig. 16**

- Before brazing refrigerant piping, have nitrogen flow through the refrigerant piping and substitute air with nitrogen (NOTE 1) (Refer to Fig. 17). Then, carry out brazing (NOTE 2). After all the brazing works are finished, carry out flare connection with the indoor unit. (Refer to Fig. 16)




Fig. 17

**NOTE**

1. The proper pressure for having nitrogen flow through the piping is approximately 0.02 MPa, a pressure that makes one feel like breeze and can be obtained through a pressure reducing valve.
2. Do not use flux when brazing refrigerant piping.  
Use phosphor copper brazing filler metal (BCuP-2: JISZ3264/B-Cu93P-710/795: ISO 3677) that does not require flux.  
(If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)
3. When carrying out leakage test of refrigerant piping and the indoor unit after the installation of indoor unit is finished, confirm the connecting outdoor unit installation manual for test pressure.  
Refer to also the outdoor unit installation manual or technical document for refrigerant piping.
4. In case of refrigerant shortage due to forgetting additional refrigerant charge etc., it will result in malfunction such as does not cool or does not heat.  
Refer to the outdoor unit installation manual or technical document for refrigerant piping.

— **CAUTION** —

**Do not use antioxidant when brazing piping.**

It may result in malfunction of components and clogging of piping due to residue.

## 7. DRAIN PIPING WORK

### (1) Rig drain piping

- As for drain work, perform piping in such a manner that water can be drained properly.
- Employ a pipe with either the same diameter or with the diameter larger (excluding the raising section) than that of the connecting pipe (PVC pipe, nominal diameter 25 mm, outside diameter 32 mm).
- Keep the drain pipe short and sloping downwards at a gradient of at least 1/100 to prevent air pockets from forming.
- If the drain pipe cannot be sufficiently set on a slope, execute the drain raising piping.
- To keep the drain pipe from sagging, space hanging wires every 1 to 1.5 m.




Fig. 18-1




Fig. 18-2

— **CAUTION** —

Water accumulating in the drainage piping can cause the drain to clog.

- Use the attached drain hose (1) and Metal clamp (2).
- Insert the drain hose into the drain socket up to the base, and tighten the metal clamp securely within the portion of a white tape of the hose-inserted tip. Tighten the metal clamp until the screw head is less than 4 mm from the hose.
- Wrap the attached sealing pad (8) over the Metal clamp and drain hose to insulate.
- Make sure that heat insulation work is executed on the following 2 spots to prevent any possible water leakage due to dew condensation.
  - Indoor drain pipe
  - Drain socket




Fig. 19




Fig. 20

#### <PRECAUTIONS FOR DRAIN RAISING PIPING>

- Install the drain raising pipes at a height of less than 675 mm. The drain pump of this unit has a high delivery flow rate. Therefore, the higher the drain raising height is, the lower the sound of draining will be. For this reason, a minimum drain raising height of 300 mm is recommended.
- Install the drain raising pipes at a right angle to the indoor unit and no more than 300 mm from the unit.




Fig. 21

#### NOTE

- To ensure no excessive pressure is applied to the included drain hose (1), do not bend or twist when installing. (This may cause leakage.)
- If converging multiple drain pipes, install according to the procedure shown below.




Fig. 22

- As for the size of central drain pipe, select the size that meet the capacity of indoor units to be connected. (Refer to the technical document)
- At replacement with new indoor unit, use the attached new drain hose (1) and the metal clamp (2). If an old drain hose or a metal clamp is used, it may cause water leakage.

#### **CAUTION**

##### Drain piping connections

- Do not connect the drain piping directly to sewage pipes that smell of ammonia. The ammonia in the sewage might enter the indoor unit through the drain pipes and corrode the heat exchanger.


**(2) After piping work is finished, check if drainage flows smoothly.**

**WHEN ELECTRIC WIRING WORK IS FINISHED**

- Add approximately 1L of water slowly from the air outlet and check drainage flow. (Refer to Fig.23)
- Check drainage flow during COOL running, explained under “12. TEST OPERATION”.
- Refer to the figure on the following after checking the draining of water, and mount the thermal insulation material for drainage (12) and thermal insulate the drain socket.

**—  CAUTION —**

- Do not apply external force to the float switch.  
This may result in a malfunction.



**WHEN ELECTRIC WIRING WORK IS NOT FINISHED**


**—  CAUTION —**

- Electrical wiring work should be done by a certified electrician.
- If someone who does not have the proper qualifications performs the work, perform the following after the test run is complete.

- Remove the control box lid. Connect the single phase power supply (SINGLE PHASE 230V) to connections No.1 and No.2 on the terminal block for wiring the units. Do not connect to No.3 of the terminal block for wiring the units. (The drain pump will not operate.) Connect the earth wire firmly. When carrying out wiring work around the control box, make sure none of the connectors come undone. Be sure to attach the control box lid before turning on the power.
- Put approximately 1L of water into the drain pan through the blow-off mouth on the left-hand side of the drain socket. Make sure not to pour water over the drain pump or any electric parts including those of the drain pump.
- When the power is turned on, the drain pump will operate and you can check the draining of water through the transparent part of the drain socket. (The drain pump will stop automatically in 10 minutes.) After checking the draining of water, mount the thermal insulation material for drainage (12) and thermal insulate the drain socket.
- After confirming drainage (Fig. 23, Fig. 24), turn off the power and remove the power supply.
- Attach the control box lid as before.

**—  CAUTION —**

- Do not apply external force to the float switch.  
This may result in a malfunction.
- Do not touch the electronic ports other than the terminal block.



<Adding water through air discharge outlet>  
[Method of adding water]

Fig. 23





Fig. 24



## 8. ELECTRIC WIRING WORK

- Electric wiring work must be conducted by electrician authorized by power companies. (Only licensed electrician can conduct electric work and earth connections.)
- All wiring must be performed by an authorized electrician.
- A circuit breaker capable of shutting down power supply to the entire system must be installed.
- Be sure to install an earth leakage circuit breaker to the outdoor unit.

(This installation of an earth leakage circuit breaker is mandatory for the prevention of electric shocks and fire disasters.)

- Make sure that 230V is specified wiring between the indoor and outdoor units and between indoor units.
- Do not turn on the power supply (of the indoor unit) until all the installation work is completed.
- Be sure to ground the air conditioner.
- Refer to the installation manual attached to the outdoor unit for the size of power supply electric wire connected to the outdoor unit, the capacity of the circuit breaker and switch, and wiring instructions.
- Do not connect the earth wire to gas pipes, plumbing pipes, lightning rods, or telephone earth wires.
  - Gas pipes: might cause explosions or fire if gas leaks.
  - Plumbing pipes: no earth effect if hard vinyl piping is used.
  - Telephone earth wires or lightning rods: might cause abnormally high electric potential in the earth during lightning storms.
- For electric wiring work, refer to also "WIRING DIAGRAM" attached to the control box lid.
- Do not touch the printed circuit board ASSY during the wiring work. Otherwise, it may cause damage.

### • Specifications for field wire

Refer to the installation manual attached to the outdoor unit regarding the detail of standard accessories for the outdoor unit.

Table 5

	Wire	Size (mm <sup>2</sup> )	Length
Wiring the units	H05VV – U4G (NOTE 1, 2)	2.5	–


### NOTE

1. Shows only in case of protected pipes. Use H07RN-F in case of no protection.
2. Supply cords shall not be lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC 57)
3. Vinyl cord with sheath or cable (Insulated thickness : 1 mm or more)

### Connection of wiring between units and earth wire (Refer to Fig. 26)

#### • Wiring the units and earth wire

Remove the control box lid and connect wires of matching number to the terminal block for wiring the units inside. And connect the earth wire to the earth terminal. In doing this, pull the wires inside through the hole and fix the wires securely with the included clamp.



How to connect the connection pipe

### CAUTION

- Never connect the power supply wiring to the terminal block for wiring the units (4P). If may damage the total system.

- Protect the wire and the wiring through hole area for wirings of the transmission, earth in order to prevent the intrusion of water and small animals into the air conditioner after the system is wired.
- Cut the sealing pad - small (11) into two pieces and wrap each wiring with each piece.
- Seal the clearance around the wirings with putty or thermal insulation material (field supply). (If insects and small animals get into the indoor unit, short circuiting may occur inside the control box.)
- After all the wiring connections are done, fill in any gaps in the through holes with putty or insulation (procured locally) to prevent small animals and insects from entering the unit from outside. (If any do get in, they could cause short circuits in the control box.)

[Processing method of wiring through hole]

#### Wiring through hole

Transmission wire,  
earth wire or remote  
controller wire

Sealing pad - Small (11)

Putty or thermal  
insulation material  
(Filed supply)

Fig. 25




Fig. 26

## **CAUTION**

- Shape the wires and attach the control box lid securely so that wires will not be caught. (Caught wires and risen lid may cause an electric shock or fire.)

### **Precautions to be taken for power supply wiring**

Use a round crimp-style terminal for connection to the power supply terminal block.

In case it cannot be used due to unavoidable reasons, be sure to observe the following instructions.  
(Refer to Fig. 27)

- Do not connect wires of different gauge to the same power supply terminal. (Looseness in the connection may cause overheating.) (Refer to Fig. 28)
- When connecting wires of the same gauge, connect them according to. (Refer to Fig. 28)
- In wiring, make certain that prescribed wires are used, carry out complete connections, and fix the wires so that external forces are not applied to the terminals.





Fig. 27

Connect wires of the same gauge to both side. (GOOD)



Good

Do not connect wires of the same gauge to one side. (WRONG)



Wrong

Do not connect wires of different gauges. (WRONG)



Wrong

Fig. 28

### **Tightening torque for the terminal screws.**

- Use the correct screw driver for tightening the terminal screws. If the blade of screwdriver is too small, the head of the screw might be damaged, and the screw will not be properly tightened.
- If the terminal screws are tightened too hard, screws might be damaged.

Refer to the table below for the tightening torque of the terminal screws.

Tightening torque (N·m)	
Terminal block for remote controller	0.88±0.08
Terminal block for wiring the units	1.47±0.14
Earth terminal	1.47±0.14

- If the strand wire is used, do not solder it. (Abnormal heating may occur if the wirings are not tightened securely.)

## 9. WIRING EXAMPLE

### CAUTION

Be sure to install an earth leakage breaker to the outdoor unit.

Installation of an earth leakage breaker is mandated to avoid electric shocks or fire.

For the wiring of outdoor units, refer to the installation manual attached to the outdoor units.

**Confirm the system type.**

- **Pair type:** 1 indoor unit to 1 outdoor unit. (standard system) (Refer to Fig. 29)

#### Pair type




Fig. 29

Standard wiring accessories

Single-phase supply	Indoor unit		
	Connection wire between indoor unit and outdoor unit		
	Earth wire (copper)	Minimum thickness	Length
	$\geq 2.0 \text{ mm}^2$ φ1.6	2.0 $\text{mm}^2$ φ1.6	$\leq 50 \text{ m}$

\* For wiring length of indoor and outdoor connection wiring will be changed depends on connect model, quantity, power size. For details, please refer engineer guide.

## 10. INSTALLATION OF THE DECORATION PANEL

<If test operation is required before installation of the decoration panel, “11. FIELD SETTING” and “12. TEST OPERATION” can be carried out before “10. INSTALLATION OF THE DECORATION PANEL”.>

- Refer to the installation manual attached to the decoration panel.
- After installing the decoration panel, ensure that there is no space between the unit body and decoration panel.
- When making a test run before installation of the decoration panel, be sure to check the operation of the swing flap after the installation.

## 11. FIELD SETTING

<<Refer to also the installation manual attached to the outdoor unit.>>

### — CAUTION —

Before carrying out field setting, check the items mentioned in the clause 2 “1. Items to be checked after completion of work” on page 39.

- Check if all the installation and piping works for the air conditioner are completed.
- Check if the control box lids of the air conditioner are closed.

### <FIELD SETTING FOR REMOTE CONTROLLER>

Kindly refer W/L Remote Manual for field settings with wireless remote

#### 11-1 SETTING CEILING HEIGHT

- Set the SECOND CODE No. according to the ceiling height as shown in the **Table 6**.

Table 6

		FCVFQ/FCFQ50/71AV16 FCFQ50/71CV16 FCMF50/71CV16	FCVFQ/FCFQ90,100,125, 140AV16,FCFQ90CV16	Mode No. (Note) 1	FIRST CODE No.	SECOND CODE No.
		50-71 type	90.100.125.140 type			
Ceiling height (m)	Standard · All round outlet	≤2.7	≤3.2	13 (23)	0	01
	High ceiling 1	2.7 - 3	3.2-3.6			02
	High ceiling 2	3 - 3.5	3.6-4.2			03

Note:

1. To make or confirm settings for an individual unit, set the internal mode number in parentheses.
2. The figure of the ceiling height is for the all round outlet.

For the settings for four-direction (part of corner closed off), three-direction and two-direction outlets, see the installation manual and technical guide supplied with the separately sold closure material kit.

#### 11-2 SETTING AIR DISCHARGE DIRECTION

- Refer to the installation manual attached to the sealing material of air discharge outlet sold separately and engineering data book, for ceiling height settings for four-direction (part of corner closed off) and three-direction.

(The SECOND CODE No. is factory set to “01” (all round outlet) before shipping.)

#### 11-3 SETTING WHEN AN OPTIONAL ACCESSORY IS ATTACHED

- For setting when attaching an optional accessory, refer to the installation manual attached to the optional accessory.

#### 11-4 WHEN USING WIRELESS REMOTE CONTROLLER

- When using a wireless remote controller, it is necessary to set the wireless remote controller address. Refer to the installation manual attached to the wireless remote controller.

#### 11-5 SETTING FAN SPEED DURING THERMOSTAT OFF

- Set the fan speed according to the using environment after consultation with your customer.
- When the fan speed is changed, explain the set fan speed to your customer.

**Table 7**

Setting	Mode No.	FIRST CODE No.	SECOND CODE No.
Fan operates / stops during thermo OFF (Cooling · heating)	Operates	11 (21)	2
	Stops		01 02
Fan speed during cooling thermostat OFF	(Extra low)	12 (22)	6
	Setting		01 02
Fan speed during heating thermostat OFF	(Extra low)	12 (22)	3
	Setting		01 02

**11-6 SETTING FILTER SIGN**

- A message to inform the air filter cleaning time will be indicated on the remote controller.
- Set the SECOND CODE No. shown in the **Table 8** according to the amount of dust or pollution in the room.
- Though the indoor unit is equipped with the long life filter, it is necessary to periodically clean the filter to avoid clogging of the filter. Please also explain the set time to the customer.
- The periodical filter cleaning time can be shortened depending on the environment.

**Table 8**

Contamination	Hours until indication	Mode No.	FIRST CODE No.	SECOND CODE No.	
Normal	Approx. 2500 hrs	10 (20)	0	01	
More contaminated	Approx. 1250 hrs		02	01 02	
With indication			3	01	
No indication*			02		

\* Use "No indication" setting when cleaning indication is not necessary such as the case of periodical cleaning being carried out.

## 12. TEST OPERATION

### **CAUTION**

When performing field setting or test operation without attaching the decoration panel, do not touch the drain pump. This may cause electric shock.


<Complete all the “1. Items to be checked after the installation work is completed” on page 39. Please also refer to the installation manual attached to outdoor unit.‑

Refer to the section of “FOR THE FOLLOWING ITEMS, TAKE SPECIAL CARE DURING CONSTRUCTION AND CHECK AFTER INSTALLATION IS FINISHED.” .

- After finishing the construction of refrigerant piping, drain piping, and electric wiring, conduct test operation accordingly to protect the unit.
- Check that the outdoor unit has been wired properly.
- Check that the control box lid of the indoor unit is closed and that the outer plate and piping cover of the outdoor unit are closed as well.
- Clean the decoration panel and interior of the indoor unit on completion of refrigerant piping, drain piping, and electric wiring work.
- Refer to the installation manual of the outdoor unit, and perform the test operation of the air conditioner.
- If the decoration panel is mounted at the time of test operation, check the operation of the swing flap of the decoration panel.
- If the interior finishing work has been still on the way on completion of test operation, explain to the customer not to operate the air conditioner for the protection of the indoor unit until the interior finishing work is completed.

If the air conditioner is operated, substances generated from the paint and glue of the interior finishing will contaminate the indoor unit, thus resulting in water splashing or leakage.

- If an error occurs and the air conditioner does not operate, refer to the following troubleshooting information.
- On completion of test operation, press the INSPECTION/TEST OPERATION button to set the air conditioner to “ mode and check that the error code is set to “00” (=normal). If the error code is other than “00”, refer to the following troubleshooting information.
- The air conditioner will return to normal run mode if the INSPECTION/TEST OPERATION button is pressed four times.
- Perform the trial operation of the air conditioner after mounting the decoration panel if the wireless remote controller is used.



### PRECAUTIONS

1. Refer to the diagnoses below if the unit does not operate properly.
2. After completing the test run, press the INSPECTION/TEST OPERATION button once to put the unit in inspection mode, and make sure the malfunction code is “00”. (=normal)  
If the code reads anything other than “00”, refer to the malfunction diagnoses below.

### **NOTE**

- If a malfunction is preventing operation, refer to the malfunction diagnoses.

## 12-1 CAUTIONS FOR SERVICING

**With the power on. Troubles can be monitored on the remote controller.**

- If the air conditioner does not operate normally after installing the air conditioner.  
a malfunction shown in the table below may have happened.

Remote controller display	Malfunction
No display	<ul style="list-style-type: none"><li>• Batteries are not inserted or batteries may be discharged</li><li>• Remote controller faulty</li></ul>

\*After turning on the power, the maximum is 90 seconds, although it will only display "Checking the connection. Please stand by". This is not a problem, and it will be set for 90 seconds.

■ Trouble shooting with the display on the liquid crystal display remote controller.

**1. With the wireless remote controller.**

(Refer also to the operation manual attached to the wireless remote controller)

When the operation stops due to trouble. The display on the indoor unit flashes. In such a case, diagnose the fault contents with the table on the Malfunction code list looking for the Malfunction code which can be found by following procedures.

(1) Press the INSPECTION /TEST OPERATION button, "  " is displayed and " 0 " flashes.

(2) Press the Temp. button and find the unit No. which stopped due to trouble.

Number of beeps 3 short beeps Perform all the following operations

1 short beep Perform (3) and (6)

1 long beep No trouble

(3) Press the OPERATION MODE SELECTOR button and upper figure of the Malfunction code flashes.

(4) Continue pressing the Temp. button until it makes 2 short beeps and find the upper code.

(5) Press the OPERATION MODE SELECTOR button and lower figure of the Malfunction code flashes.

(6) Continue pressing the Temp. button until it makes a long beep and find the lower code.

• A long beep indicates the Malfunction code.

**NOTE **

1. Keep down the ON/OFF button for 5 seconds or longer in the inspection mode and the above trouble history disappears, after the trouble code goes on and off twice, followed by the code "00"(normal).  
The display changes from the inspection mode to the normal mode.

**Caution:**

Check the items in "**2. Items to be checked at time of delivery**" on page 40 after a test operation.

## 12-2 MALFUNCTION CODE LIST

- For places where the Malfunction code is left blank, the “” indication is not displayed. Though the system continues operating, be sure to inspect the system and make repairs as necessary.
- Depending on the type of indoor or outdoor unit the Malfunction code may or may not be displayed.

code	Malfunction/ Remarks
A0	Safety device operates.
A1	Indoor units PC board faulty
A3	Drain water level abnormal
A6	Indoor fan motor overloaded overcurrent or locked
A8	Fan PCB power supply error
AF	Humidifier faulty
AH	Air cleaner faulty
	Only the air cleaner does not function
AJ	Type set improper
	Capacity data is wrongly preset. Or there is nothing programmed in the data IC.
C1	Indoor PCB (Master) - indoor PCB (Slave) Transmission defect
C4	Sensor (R2T) for heat exchanger temperature is fault
C5	Sensor (R3T) for heat exchanger temperature is fault
C6	Fan PCB setting defect
C9	Sensor for suction air temperature is fault
CC	Humidity sensor abnormal
CE	Human detection / floor temperature sensor error
	Sensor for remote controller is fault
CJ	The remote controller thermistor does not function, but the system thermo run is possible
U1	Reverse phase/ Reverse two phase of the L1, L2 and L3
UF	Wrong wiring between indoor and outdoor units or malfunction of PC board mounted on indoor and the outdoor units
U5	transmission Error (indoor unit- remote controller)
U8	Malfunction in transmission between main and sub remote controls ( malfunction in sub remote controller)
UA	Miss setting multi setting setting is wrong for selector switch of multi-system. (See SS2 on main unit's PC board)
UC	Central control address overlapping
UE	Transmission defect (indoor- centralizing)
UJ	Peripheral equipment transmission fault
U0	Refrigerant shortage/Suction pipe temperature abnormal.
U2	Low -voltage detection or over- voltage detection /Includes the defect in 52C
U4	Signal transmission error (between indoor unit and ODU)
UA	Miss setting for multi system Setting is wrong for selector switch of multi -system (see switch SS2 on the main unit's PC board)
E1	Outdoor unit PCB abnormality
E7	Outdoor fan motor lock malfunction /outdoor fan instantaneous over current malfunction.
F3	Discharge pipe temperature control (Outdoor Unit)
H9	Outdoor air thermistor faulty/ equipment operation in response to error will vary according to model
J3	Discharge pipe thermistor faulty (outdoor unit)/ equipment operation in response to error will vary according to model
J6	Heat exchanger thermistor faulty /equipment operation in response to error will vary according to model
L4	Over heated radiation fin /inverter cooling defect

L5	Instantaneous over current / possible earth fault or short in the compressor motor
E6	Compressor lock (Outdoor Unit)
E8	Input over-current detection (Outdoor Unit)
F6	High pressure control in cooling (Outdoor Unit)
00	Normal
E5	OL activation (compressor overload) (Outdoor Unit)
F8	System shutdown due to temperature abnormality in compressor (Outdoor Unit)
H0	Compressor sensor system abnormality (Outdoor Unit)
H6	Position sensor abnormality (Outdoor Unit)
H8	DC voltage/current sensor abnormality (Outdoor Unit)
L3	Reactor thermistor error outdoor
P4	Radiation fin thermistor or related abnormality (Outdoor Unit)
J7	Heat exchanger thermistor faulty (outdoor unit) Equipment operation in response to errors will vary according to model.
J8	Liquid piping temperature sensor system error (outdoor unit)
J9	Intake temperature sensor error (outdoor unit)
L1	Inverter system error (outdoor unit)
L3	Reactor thermister error (outdoor)
L4	Overheated heat-radiating fin (outdoor unit) Inverter cooling defect.
L5	Instantaneous overcurrent (outdoor unit) Possible earth fault or short circuit in the compressor motor.
L8	Electric thermal (outdoor unit) Possible electrical overload in the compressor or cut line in the compressor motor.
L9	Stall prevention (outdoor unit) Compressor possibly locked.
LC	Transmission malfunction between the outdoor control unit's inverters (outdoor unit)
P1	Open-phase (outdoor unit)
P3	P-board temperature sensor malfunction (outdoor unit)
P6	DC output current error (outdoor)
PJ	Type set improper (outdoor unit) Capacity data is wrongly preset. Or there is nothing programmed in the data hold IC.
U0	Suction pipe temperature abnormal

## **CAUTION**

- Refer to “**2. Items to be checked at time of delivery**” on page 40 upon completion of the test run and make sure that all the items are checked.
- If the customer’s interior work has not been finished on completion of the test run, explain the customer not to operate the air conditioner. This is essential until the interior work is finished so as to protect the product. Substances generated from paints and adhesives used for the interior work may contaminate the product if the unit is operated.

## **To test run Contractors**

When delivering the product to the customer after the test run is completed, check that the control box lid, the air filter and the suction grille are mounted. In addition, explain to the customer regarding the state (ON/OFF) of the power supply breaker.

## How to confirm of running condition by LED AND 7 SEGMENT DISPLAY

When power supply turns "ON", LED of printed board (A1P) of outdoor side can confirm details as following.

 : LED light ON    : LED light OFF    : LED flash


HAP	
Micon	
Normal	
Monitor	

	: Normal
	: Abnormal, power supply is abnormal (Insufficient voltage, breaker does not ON) or printed board (A1P) of outdoor has failure.
	: Abnormal, power supply is abnormal.
	: Abnormal (Fast flashing)

Result	7segment display
Normality finish	Light off
Abnormality finish	Abnormal code

### 7 segment : For display error code detail

When test operation, 7 segment display will flashing same as right view, this symbol is not abnormal (for normal or abnormal will display same right now)



### Measure for abnormal finished

Confirm malfunction code from remote controller and 7 segment display, then correct the abnormal finished (for how to correct abnormality and correction method, see the installation/opertion/service manual). After correcting abnormal finished push the confirm button (BS3) and reset the malfunction code, then carry out the check again and confirm the abnormality is properly corrected (need to not show error code in remote controller and 7 segment display.)



This unit, while operation and stop, stand by power is decreasing, LED of outdoor PCB will be turn OFF. Power is still being supplied to terminal block while stand by power is deceasing, be make sure to turn OFF power supply when service.

### Precautions regarding trouble diagnosis using the malfunction code on the remote controller and 7 segment display.

Please refer to the installation manual attached to indoor unit.

### Making a record of the added refrigerant charge amount


Be sure to record the piping length and added refrigerant charge amount or refrigerant recharge amount with an oil-based or other indelible marker so to the figures will not fade over time.

This information is necessary for after service and maintenance.

Liquid piping size	Ø 9.5mm x t0.8mm
Refrigerant piping size	m

Additional refrigerant charging	kg
Recharge of refrigerant	kg

## 14. HOW TO RE-USE THE EXISTING PIPING



(Note)

- ① Clean the pipe if refrigerant leakage and unit has not service port on gas-liquid stop valve.
- ② If indoor unit equipped with EV valve, open that valve before recovery refrigerant.
- ③ Maximum pipe length as per specified on next page.

### PRECAUTIONS ON REFRIGERANT PIPING

- Clean pipe if existing air conditioner is [gas, oil heat pump type].
- Clean pipe if used compressor oil in existing air conditioner is other than [SUNISO, MS, HAB, Barrel freeze, JOMO, Ester oil].
- Clean pipe if existing indoor and outdoor unit is disconnected.
- Change new pipe if refrigerant leakage or it should adding refrigerant.
- Change new heat insulation if existing part is peeling off.

## 15. REFRIGERANT RECOVERY

### [Working procedure]

#### 1. Recovery retaining oil in existing gas pipe Approx. 1 min

Close gas stop valve (liquid stop valve : open)

and recovery refrigerant from gas stop valve port.(Fig.1)

#### 2. Recovery retaining oil in existing liquid pipe Approx.1 min

Recovery refrigerant from liquid stop valve port.(Fig.2)

#### 3. Recovery refrigerant in outdoor unit Approx 2-3 min

Recovery refrigerant from outdoor unit refrigerant recovery port \*1. (Fig.3)

NOTE M\*1 Can be omit this procedure if there has no refrigerant recovery port.


#### 4. Recovery refrigerant in accordance with Fluorocarbons Recovery and Destruction Law

If refrigerant recovery port \*2 pressure became lower than gas stop valve port pressure, refrigerant will recover at the simultaneous from the gas stop valve port, open gas stop valve (Fig.3- ①) gradually to avoid from pressure rising rapidly. (Fig.3- ②)

NOTE MM\*2 Recovery refrigerant from liquid valve port and stop valve port simultaneous if there has no refrigerant recovery port.

Retaining oil recovery amount improved approx. 5 times from regular refrigerant recovery method


(pipe length, height difference, pipe path etc. is difference by installation condition)



### ABOUT FLARE PROCESSING

● Flare connection area of existed piping will cause processing deterioration, make sure to do newly re-processing.

■ Flare processing [Unit : mm]



Piping outside diameter	A (+0, -0.4)
Ø 6.35	9
Ø 9.5	13
Ø 12.7	16.2
Ø 15.9	19.7

● Please use flare nut which attached with product  
(Do not use existed flare nut)

■ Flare nut [Unit : mm]



Piping outside diameter	A (+0, -0.4)
Ø 6.35	17
Ø 9.5	22
Ø 12.7	26
Ø 15.9	29

### REFRIGERANT PIPE SIZE TABLE

Outdoor	Pipe Size (mm)	Pipe length		Height Difference	Design Pressure (High Pressure)
RZVFQ50	6.35/12.7	Standard pipe length	7.5m		
RZVFQ71, RZCFQ71CV16, RZCMF71CV16, RZCMF50CV16	6.35/15.9	Max pipe length	20m	Max. 20m	4.17MPa
		Chargeless length	10m		
RZVFQ50, 100, 125, 140	9.52/15.9	Standard pipe length	7.5m		
RZCFQ50CV16		Max pipe length	30m	Max. 30m	4.17MPa
		Chargeless length	15m		
RZVFQ90, 100, 125, 140	9.52/15.9	Standard pipe length	7.5m		
		Max pipe length	50m	Max. 50m	4.17MPa
		Chargeless length	15m		
RZVFQ125, 140 RZCFQ48CY1	9.52/15.9	Standard pipe length	7.5m		
		Max pipe length	30m	Max. 30m	4.17MPa
		Chargeless length	15m		

■ Refer to the installation manual for details other than those mentioned above table such as additional refrigerant charge amount.

■ Standard pipe (R32)

Pipe size (mm)	Ø6.35	Ø9.5	Ø12.7	Ø15.9
Thickness (mm)	t 0.8	t 0.8	t 1.0	t 1.0

**DAIKIN AIRCONDITIONING INDIA PVT. LTD.**

12th Floor, Building No. 9, Tower A,  
DLF Cyber City, DLF Phase - III  
Gurgaon - 122002, Haryana (India)  
Tel : +91-124-4555444  
Fax: +91-124-4555333

**SPLIT SYSTEM****Air Conditioners****MODEL****Ceiling mounted cassette type (Non Sensing flow model)**

FCVFQ50AV16  
FCVFQ71AV16  
FCVFQ90AV16  
FCVFQ100AV16  
FCVFQ125AV16  
FCVFQ140AV16  
FCFQ90AV16  
FCFQ100AV16  
FCFQ125AV16  
FCFQ140AV16  
FCFQ71CV16  
FCFQ90CV16  
FCMF71CV16  
FCMF50CV16  
FCFQ36CV1  
FCFQ48CV1

**English**

Thank you for purchasing this Daikin air conditioner.

Carefully read this operation manual before using the air conditioner. It will tell you how to use the unit properly and help you if any trouble occurs. This manual explains about the indoor unit only. Use it along with the operation manual for the outdoor unit. After reading the manual, file it away for future reference.

## ■ DISPOSAL REQUIREMENTS



### Disposal requirements

Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Air conditioners must be treated at a specialized treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

Batteries must be removed from the remote controller and disposed of separately in accordance with relevant local and national legislation.

## CONTENTS

1. SAFETY PRECAUTIONS .....	94
2. WHAT TO DO BEFORE OPERATION .....	96
3. OPERATION RANGE .....	97
4. INSTALLATION SITE .....	97
5. OPERATION PROCEDURE .....	97
6. OPERATION CHARACTERISTICS .....	97
7. OPTIMUM OPERATION .....	98
8. MAINTENANCE (FOR SERVICE PERSONNEL).....	99
9. NOT MALFUNCTION OF THE AIR CONDITIONER.....	101
10. TROUBLE SHOOTING .....	102

### 1. SAFETY PRECAUTIONS



Read the precautions in this manual carefully before operating the unit.



This appliance is filled with R32.

To gain full advantage of the air conditioner's functions and to avoid malfunction due to mishandling, we recommend that you read this instruction manual carefully before use. This air conditioner is classified under "appliances not accessible to the general public".

- **Read the precautions thoroughly to avoid misuse of the equipment.**
- **The precautions described herein are classified as WARNING and CAUTION. They both contain important information regarding safety. Be sure to observe all precautions without fail.**
- **There are two kinds of safety precaution and tips listed in the following.**

**⚠ WARNING** .....Failure to follow these instructions properly may result in personal injury or loss of life.

**⚠ CAUTION** .....Failure to observe these instructions properly may result in property damage or personal injury, which may be serious depending on the circumstances.

- **After reading, keep this manual in a convenient place so that you can refer to it whenever necessary. If the equipment is transferred to a new user, be sure also to hand over the manual.**

#### — **⚠ WARNING** —

- **The appliance must be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).**
- **Do not pierce or burn.**
- **Be aware that refrigerants may not contain an odour.**
- **Floor area required for installation of the equipment, refer to the installation manual of the outdoor unit.**
- **Be aware that prolonged, direct exposure to cool air from the air conditioner, or to air that is too cool can be harmful to your physical condition and health.**
- **When the air conditioner is malfunctioning (giving off a burning odour, etc.) turn off power to the unit and contact your local dealer.**  
Continued operation under such circumstances may result in a failure, electric shocks or fire hazards.

- **Consult your local dealer about installation work.**

Doing the work yourself may result in water leakage, electric shocks or fire hazards.

- **Consult your local dealer regarding modification, repair and maintenance of the air conditioner.**

Improper workmanship may result in water leakage, electric shocks or fire hazards.

- **Do not place objects, including rods, your fingers, etc., in the air inlet or outlet.**

Injury may result due to contact with the air conditioner's high speed fan blades.

- **Beware of fire in case of refrigerant leakage.**

If the air conditioner is not operating correctly, i.e. not generating cool air, refrigerant leakage could be the cause.

Consult your dealer for assistance.

The refrigerant within the air conditioner is safe and normally does not leak.

However, in the event of a leakage, contact with a naked burner, heater or cooker may result in generation of noxious gas.

Do not longer use the air conditioner until a qualified service person confirms that the leakage has been repaired.

- **Consult your local dealer regarding what to do in case of refrigerant leakage.**

When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen depletion.

- **Contact professional personnel about attachment of accessories and be sure to use only accessories specified by the manufacturer.**

If a defect results from your own workmanship, it may result in water leaks, electric shock or fire.

- **Consult your local dealer regarding relocation and reinstallation of the air conditioner.**

Improper installation work may result in leakage, electric shocks or fire hazards.

- **Be sure to use fuses with the correct ampere reading.**  
Do not use improper fuses, copper or other wires as a substitute, as this may result in electric shock, fire, injury or damage to the unit.

- **Be sure to earth the unit.**

Do not earth the unit to a utility pipe, lightning conductor or telephone earth lead. Imperfect earthing may result in electric shocks or fire. A high surge current from lightning or other sources may cause damage to the air conditioner.

- **Be sure to install an earth leakage breaker.**

Failure to install an earth leakage breaker may result in electric shocks or fire.

- **Consult the dealer if the air conditioner submerges owing to a natural disaster, such as a flood or typhoon.**

Do not operate the air conditioner in that case, or otherwise a malfunction, electric shock, or fire may result.

- **Do not start or stop operating the air conditioner with the power supply breaker turned ON or OFF.**

Otherwise, fire or water leakage may result.

Furthermore, the fan will rotate abruptly if power failure compensation is enabled, which may result in injury.

- **Do not use the product in the atmosphere contaminated with oil vapor, such as cooking oil or machine oil vapor.**  
Oil vapor may cause crack damage, electric shocks, or fire.

- **Do not use the product in places with excessive oily smoke, such as cooking rooms, or in places with flammable gas, corrosive gas, or metal dust.**

Using the product in such places may cause fire or product failure.

- **Do not place water containers (flower vases, etc.) on the unit, as this may result in electric shocks or fire.**
- **Do not operate with the control panel lid open.**  
If water gets inside the panel, it may result in equipment failure or electric shock.
- **Do not use flammable materials (e.g., hairspray or insecticide) near the product.**
- **Do not place burners or heaters in places exposed to the air flow from the unit as this may impair combustion of the burner or heater.**
- **Do not wipe the controller panel with benzene or other organic solvent.**  
This will cause discoloration and/or peeling. If the panel needs cleaning, use a damp cloth with some water-diluted neutral detergent. Wipe with a dry cloth afterwards.
- **Be sure to use a dedicated power supply for the air conditioner.**  
The use of any other power supply may cause heat generation, fire, or product failures
- **Consult your dealer regarding cleaning the inside of the air conditioner.**  
Improper cleaning may cause breakage of plastic parts, water leakage and other damage as well as electric shocks.

### — CAUTION


- **Do not use the air conditioner for purposes other than those for which it is intended.**  
Do not use the air conditioner for cooling precision instruments, food, plants, animals or works of art as this may adversely affect the performance, quality and/or longevity of the object concerned.
- **Do not remove the outdoor unit's fan guard.**  
The guard protects against the unit's high speed fan, which may cause injury.
- **Do not place objects that are susceptible to moisture directly beneath the indoor or outdoor units.**  
Under certain conditions, condensation on the main unit or refrigerant pipes, air filter dirt or drain blockage may cause dripping, resulting in fouling or failure of the object concerned.
- **To avoid oxygen depletion, ensure that the room is adequately ventilated if equipment such as a burner is used together with the air conditioner.**
- **After prolonged use, check the unit stand and its mounts for damage.**  
If left in a damaged condition, the unit may fall and cause injury.
- **Do not place flammable sprays or operate spray containers near the unit as this may result in fire.**
- **Before cleaning, be sure to stop unit operation, turn the breaker off or remove the power cord.**  
Otherwise, an electric shock and injury may result.
- **To avoid electric shocks, do not operate with wet hands.**
- **Do not place appliances that produce naked flames in places exposed to the air flow from the unit as this may impair combustion of the burner.**
- **Do not place heaters directly below the unit, as resulting heat can cause deformation.**
- **Do not allow a child to mount on the outdoor unit or avoid placing any object on it.**  
Falling or tumbling may result in injury.
- **Do not sit or place objects on the outdoor unit.**  
Falling yourself or falling objects could cause injury.

- **Do not block air inlets or outlets.**  
Impaired air flow may result in insufficient performance or trouble.
- **Be sure that children, plants or animals are not exposed directly to airflow from the unit, as adverse effects may ensue.**
- **Do not wash the air conditioner with water, as this may result in electric shocks or fire.**
- **Arrange the drain hose to ensure smooth drainage.**  
Imperfect drainage may cause wetting of the building, furniture etc
- **Ensure that the remote controller is not exposed to direct sunlight.**  
This will cause discoloration of the LCD display with resulting loss of readability.
- **Never operate remote controller buttons with hard, pointed objects.**  
This may result in remote controller damage.
- **Do not operate the air conditioner when using a room fumigation type insecticide.**  
Fumigation chemicals deposited in the unit could endanger the health of those who are hypersensitive to touch chemicals.
- **Do not place flammable sprays near the unit as this can cause explosions.**
- **Do not install the air conditioner at any place where there is a danger of flammable gas leakage.**  
In the event of a gas leakage, build-up of gas near the air conditioner may result in fire hazards.
- **Do not put flammable containers, such as spray cans, within 1 m from the blow-off mouth.**  
The containers may explode because the warm air output of the indoor or outdoor unit will affect them.
- **Arrange the drain to ensure complete drainage.**  
If proper drainage from the outdoor drain pipe does not occur during air conditioner operation, there could be a blockage due to dirt and debris build-up in the pipe. This may result in a water leakage from the indoor unit. Under these circumstances, stop air conditioner operation and consult your dealer for assistance.
- **The appliance is not intended for use by unattended young children or infirm persons.**  
Impairment of bodily functions and harm to health may result.
- **Children should be supervised to ensure that they do not play with the unit or its remote controller.**  
Accidental operation by a child may result in impairment of bodily functions and harm health.
- **Do not let children play on or around the outdoor unit.**  
If they touch the unit carelessly, injury may be caused.
- **To avoid injury, do not touch the air inlet or aluminium fins of the unit.**
- **Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.**  
Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.
- **Turn off the main power switch when the air conditioner is not to be used for prolonged periods.**  
When the main power switch is left on, some electrical power (watts) is still consumed even if the air conditioner is not operating. Therefore, switch off the main power switch to save energy. When resuming operation, to ensure smooth running, turn on the main power switch 6 hours before operating the air conditioner again.

- **Never touch the internal parts of the controller.**  
Do not remove the front panel. Touching certain internal parts will cause electric shocks and damage to the unit. Please consult your dealer about checking and adjustment of internal parts.
- **Do not leave the remote controller wherever there is a risk of wetting.**  
If water gets into the remote controller there is a risk of electrical leakage and damage to electronic components.
- **Watch your steps at the time of air filter cleaning or inspection.**  
High-place work is required, to which utmost attention must be paid.  
If the scaffold is unstable, you may fall or topple down, thus causing injury.
- **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
- **Children should be supervised to ensure that they do not play with the appliance.**
- **Take care of scaffolding and exercise caution when working high above ground level.**

## 2. WHAT TO DO BEFORE OPERATION

This operation manual is for the following system with standard control. Before initiating operation, contact your dealer for the operation that corresponds to your system.




### NOTE ➡

- If the unit you purchased is controlled by a wireless remote controller, also refer to the wireless remote controller's operation manual.

If your installation has a customized control system, ask your dealer for the operation that corresponds to your system.

- Heat pump type  
This system provides COOLING, HEATING, AUTOMATIC, PROGRAM DRY, and FAN OPERATION modes.
- Cooling only type  
This system provides COOLING, PROGRAM DRY, and FAN OPERATION modes.

## Names and functions of parts



a	Air outlet
b	Suction grille
c	Air filter (Inside suction grille)
d	Drain discharge device (built-in) Discharges indoor moisture removed during the cooling operation.
e	Drain pipe
f	Brand name logo
g	Horizontal blade (At air outlet)
h	Refrigerant piping Transmission wiring
i	Earth wiring (Note) (Note) It is a wiring to let electricity flow from the indoor unit to the earth for prevention of electric shocks or a fire in case of emergency.
j	Remote control (Operation part)
k	IR Kit

## 3. OPERATION RANGE

If the temperature or the humidity is beyond the following conditions, safety devices may work and the air conditioner may not operate, or sometimes, water may drop from the indoor unit.

### COOLING

For FCMF50/71CV16

OUTDOOR UNIT	INDOOR			OUTDOOR TEMPERA-TURE
	TEMPERA-TURE	HUMIDITY		
RZCMF50/71CV16	D B	21 to 35	80% or below	D B
	W B	14 to 24		

DB: Dry bulb temperature (°C)

WB: Wet bulb temperature (°C)

The setting temperature range of the remote controller is 18°C to 32°C.

If the temperature or the humidity is beyond the following conditions, safety devices may work and the air conditioner may not operate, or sometimes, water may drop from the indoor unit.

**COOLING**

For **FCVFQ 50,71,90,100,125,140AV16,FCFQ71,90CV16**  
**FCFQ 90,100,125,140AV16**

OUTDOOR UNIT	INDOOR		OUTDOOR TEMPERA- TURE
	TEMPERA- TURE	HUMIDITY	
RZVFQ50,71,90, 100AV16 RZFQ90,100AV16 RZVFQ125,140AY16 RZFQ125,140AY16	D B 19 to 35	80% or below	D B 19 to 50
RZMFQ90,100AV16 RZCFQ36CV1 RZCFQ48CY1	W B 14 to 24		

DB: Dry bulb temperature (°C)

WB: Wet bulb temperature (°C)

The setting temperature range of the remote controller is 18°C to 32°C.

#### 4. INSTALLATION SITE

##### Regarding places for installation

- Is the air conditioner installed at a well-ventilated place where there are no obstacles around?
- Do not use the air conditioner in the following places.
  - a. Filled with much mineral oil such as cutting oil
  - b. Where there is much salt such as a beach area
  - c. Where sulfured gas exists such as a hot-spring resort
  - d. Where there are considerable voltage fluctuations such as a factory or plant
  - e. Vehicles and vessels
  - f. Where there is much spray of oil and vapor such as a cookery, etc.
  - g. Where there are machines generating electromagnetic waves
  - h. Filled with acid and/or alkaline steam or vapor
- Is a snow protection measure taken?  
 For details, consult your dealer about snow protection hoods, etc.

##### Regarding wiring

- All wiring must be performed by an authorized electrician.  
 To do wiring, ask your dealer. Never do it by yourself.
- Make sure that a separate power supply circuit is provided for this air conditioner and that all electrical work is carried out by qualified personnel according to local laws and regulations.

##### Pay attention to running noises, too

- Are the following places selected?
  - a. A place that can sufficiently withstand the weight of the air conditioner with less running noises and vibrations.
  - b. A place where the hot wind discharged from the air outlet of the outdoor unit and the running noises do not cause a nuisance to neighbours.
- Are you sure that there are no obstacles near the air outlet of the outdoor unit?  
 Such obstacles may result in declined performance and increased running noises.
- If abnormal noises occur in use, stop the operation of the air conditioner, consult your dealer.

##### System relocation

- Consult your Daikin dealer about remodelling and relocation.

##### Regarding drainage of drain pipe

- Is the drain pipe executed to perform complete drainage?

If proper drainage is not carried out from the outdoor drain pipes during air-conditioning operation, chances are that dust and dirt are clogged in the pipe. This may result in a water leakage from the indoor unit. Under such circumstances, stop the operation of the air conditioner, and then consult your dealer or our service station.

#### 5. OPERATION PROCEDURE

- Operation procedure  
 Read the operation manual attached to the remote controller.
- Operation procedure varies with heat pump type and cooling only type. Contact your local dealer to confirm your system type.
- To protect the unit, turn on the main power supply switch 6 hours before operation.
- Do not shut off the power supply during seasonal use of the air conditioner.  
 This is required in order to activate the air conditioner smoothly.
- If the main power supply switch is turned off during operation, operation will restart automatically after the power turns back on again.

#### 6. OPERATION CHARACTERISTICS

##### ■ CHARACTERISTICS OF THE COOLING OPERATION (COOLING OPERATION AND AUTOMATIC COOLING OPERATION)

- When operating continuously at downward airflow direction, air blows in the automatically set direction for a period of time to prevent condensation on the horizontal blade.
- If the COOLING OPERATION is used when the indoor temperature is low, frost forms on the heat exchanger of the indoor unit. This can decrease the cooling capacity.
- When the outdoor temperature is high, it takes some time until the indoor temperature reaches the set temperature.


##### ■ CHARACTERISTICS OF THE PROGRAM DRY OPERATION

- This operation lowers the humidity without lowering the indoor temperature. The indoor temperature, when the operation button is pressed, will be the set temperature. At this time, the fan speed and temperature are set automatically, so the remote controller does not display the fan speed and set temperature.  
 To efficiently lower the indoor temperature and humidity, first use the COOLING OPERATION to lower the indoor temperature, and then use the PROGRAM DRY OPERATION. When the indoor temperature is lowered, airflow from the air conditioner may stop.
- When operating continuously at downward airflow direction, air blows in the automatically set direction for a period of time to prevent condensation on the horizontal blade.
- If the PROGRAM DRY OPERATION is used when the indoor temperature is low, frost forms on the heat exchanger of the indoor unit.



## AIRFLOW DIRECTION ADJUST

Airflow direction adjustment can be done by remote controller.  
For details about airflow direction adjustment, refer to operation manual attached to remote controller.



Up and down adjustment

The airflow direction can be adjusted in either of the following.

- Swing  
The horizontal blade continuously varies.
- Fixed airflow direction  
The horizontal blade can be fixed by the user.



## MOVEMENT OF THE HORIZONTAL BLADE

For the following conditions, micro computer controls the airflow direction so it may be different from the display.

Operation mode	<ul style="list-style-type: none"> <li>• COOLING</li> <li>• AUTOMATIC COOLING</li> <li>• PROGRAM DRY</li> <li>• FAN MODE</li> </ul>
Up and down direction	<ul style="list-style-type: none"> <li>• When operating continuously at horizontal airflow direction (Air blows in the automatically set direction for a period of time to prevent condensation on the horizontal blades.)</li> </ul>

## Recommended airflow direction position



We recommend using the fan in the position shown above when fixing the fan direction.

## 7. OPTIMUM OPERATION

Observe the following precautions to ensure the system operates.

- Adjust the room temperature properly for a comfortable environment. Avoid excessive cooling.
- Prevent direct sunlight from entering a room during cooling operation by using curtains or blinds.
- Keep doors and windows closed. If the doors and windows remain open, room air will flow out and cause to decrease the effect of cooling.
- Never place objects near the air inlet and the air outlet of the unit. It may cause deterioration in the effect or stop in the operation.
- Install TV, radios, and stereos 1 m or more away from the indoor unit and remote controller.  
Images may become fuzzy and noise may be generated.
- Turn off the main power supply switch when it is not used for long period of time. When the main power supply switch is turned on, some watts of electricity is being used even if the system is not operating. (\*1)  
Turn off the main power supply switch for saving energy. When reoperating, turn on the main power supply switch 6 hours before operation for smooth running  
(Refer to "8. MAINTENANCE" on page 77). (\*2)
- \*1 The consumed power while the outdoor unit is not in operation depends on the model.
- \*2 The setting before the power circuit breaker is cut off is stored. (The timer setting is cleared.)
- When the display shows "TIME TO CLEAN AIR FILTER" ask a qualified service person to clean the filter  
(Refer to "8. MAINTENANCE" on page 77).
- Fully use the function of air flow direction adjust. Cold air gathers on the floor.  
Set the air direction to horizontal during the COOLING . Do not let the air blow directly to a person.
- It takes time for the room temperature to reach the set temperature.  
We recommend starting the operation in advance using timer operation.

## 8. MAINTENANCE (FOR SERVICE PERSONNEL)

ONLY A QUALIFIED SERVICE PERSON IS  
ALLOWED TO PERFORM MAINTENANCE

### — WARNING —

- Do not use flammable gas (such as hair sprays and insecticides) near the air conditioner.
- Do not wipe the air conditioner with benzene or thinner.  
It may cause cracks, electric shocks or a fire.
- Never put your fingers or rods in the air inlet, air outlet or air blade.  
The fan is rotating at high speed, so you would get injured.

### — CAUTION —

- Do not wash the air conditioner with water. It may cause electric shocks or a fire due to leakage.
- Make sure to turn off the air conditioner when taking care of the air conditioner and disconnect the power supply breaker.  
Unless the power supply is disconnected, it may cause electric shocks and injuries.
- When working at a high place, give caution to your footing.  
If the scaffold is unstable, it may cause injuries due to fall and stumbling.

### NOTE

- Do not remove the air filter unless for cleaning.  
It may cause failure.
- Do not attach substance (such as paper towels) other than the specified air filter to the air inlet.  
The performance may drop and cause freeze-up/water leakage.

### HOW TO CLEAN THE AIR FILTER

When the remote controller indicates "Time to clean filter", clean the air filter.

- It indicates after running for a certain time.

### NOTE

- You may change the time of indication "Time to clean filter".

**If the indoor unit is used in a space where the air is more contaminated, ask your local dealer for solution.**


Contamination	Time until indication is displayed
Normal	2500 hours (equivalent to 1 year)
More contaminated	1250 hours (equivalent to 6 months)

- If it becomes difficult to remove contamination from the air filter, replace the air filter.  
(Air filter for replacement is an optional accessory)

### 1. Open the suction grille.

Pull it downward slowly while pressing the buttons provided on two spots.  
(Do the same procedure for closing.)


Fig. 1




### 2. Remove the air filter.

Perform the operation in the order (1) and (2).


Fig. 2



(1) Pull the ends of the air filter down and remove the holes of the air filter from the grille protrusions. (Both left and right sides.)



(2) Lift the air filter and remove the holes of the air filter from the protrusions on the upper side of the grille. (Both left and right sides.)



### 3. Clean the air filter.

Use vacuum cleaner A) or wash the air filter with water B).

A) Using a vacuum cleaner



### B) Washing with water

When the air filter is very dirty, use soft brush and neutral detergent.



Remove water and dry in the shade.

#### NOTE


- Do not wash the air filter with water of 50°C or higher. It may cause discoloration and deformation.
- When drying the filter, do not heat it with fire. It may cause burning.
- Do not use such as gasoline, benzene, thinner, polishing powder and liquid insecticide sold in the market. It may cause discoloration and deformation.

4. Fix the air filter.  
Refer to item No. 2.

5. Shut the suction grille.  
Slowly push up the suction grille, and then securely hook it onto the decoration panel while pushing the two knobs.

#### NOTE

- The strings may be caught when the suction grille is closed. Before closing the suction grille, ensure that the strings are not getting out from the side of the suction grille.



6. Turn off the indication "Time to clean filter" displayed on the remote controller after turning on the power.  
• For details, refer to the operation manual attached to the remote controller. (The indication can be turned off whether in operation or at stop.)

## HOW TO CLEAN AIR OUTLET, OUTSIDE PANEL, AND REMOTE CONTROLLER

- Wipe them with a dry soft cloth.
- When the stain cannot be wiped off, dip the cloth in the neutral detergent diluted with water and twist the cloth. After wiping off stain with this cloth, wipe them with dry cloth.

#### NOTE


- Do not use such as gasoline, benzene, thinner, polishing powder and liquid insecticide sold in the market. It may cause discoloration and deformation.
- Do not wash the filter with warm water of 50°C or higher. It may cause discoloration and deformation.

## HOW TO CLEAN THE SUCTION GRILLE

### 1. Open the suction grille.


Push it downward slowly while pressing the buttons provided on two spots. (Follow the same procedure for closing.)

Fig. 3



### 2. Remove the strings of the suction grille.


Remove the two strings from the holding parts on the panel main body to which the strings are attached.



### 3. Detach the suction grille.

Open the suction grille 45 degrees and lift it upward.

Fig. 4



### 4. Detach the air filter.

Refer to "HOW TO CLEAN THE AIR FILTER".  
(Refer to Fig. 2)

### 5. Clean the suction grille.

Wash with a soft bristle brush and neutral detergent or water, and dry thoroughly.

#### • When very grimy

Directly apply the type of detergent used for cleaning ventilation fans or ovens, wait 10 minutes, and then rinse with water.



#### NOTE

- Do not wash the suction grille with water of 50°C or higher. It may cause discoloration and deformation.
- When drying the suction grille, do not heat it with fire. It may cause burning.
- Do not use such as gasoline, benzene, thinner, polishing powder and liquid insecticide sold in the market. It may cause discoloration and deformation.

6. **Reattach the air filter.**  
Refer to "HOW TO CLEAN THE AIR FILTER".  
(Refer to Fig. 2)
7. **Reattach the suction grille.**  
Refer to fig. No. 3.
8. **Fit the string of the suction grille.**  
Fit in the reverse order of the procedure 2.
9. **Close the suction grille.**  
Refer to fig. No. 1.

## ■ CLEANING BEFORE AND AFTER SEASONAL USE

### WHAT TO DO WHEN START UP AFTER A LONG STOP

#### Confirm the following.

- Check that the air inlet and outlet of indoor and outdoor unit are not blocked.  
Remove any obstacle.  
Obstacles may cause a reduction in the fan speed, which may decrease functionality, cause an increase in operation noise, or a malfunction of the equipment.

#### Clean the air filter and outside panel

- After cleaning the air filter, make sure to attach it.  
(Refer to "8. MAINTENANCE" on page 6.)
- For information on how to install, remove, or clean an optional sold air filter, refer to the user's manual attached to the air filter.
- After cleaning, perform FILTER SIGN RESET after turning on the power.

#### Turn on the power circuit breaker at least 6 hours before operation.

- This is required in order to activate the air conditioner smoothly, and to protect air conditioner.
- The display on the remote controller will be shown when the power circuit breaker is turned on.

### WHAT TO DO TO STOP THE AIR CONDITIONER FOR A LONG PERIOD

#### Turn on FAN OPERATION for a half day on the fine day and dry the indoor unit.

- This can prevent the causes of mould.

#### Turn off the power circuit breaker.

- During the power circuit breaker is turned on, some watts of electricity is being used even if the air conditioner is not operating.  
Turn off the power circuit breaker for saving energy.
- The display on the remote controller will vanish when the power circuit breaker is turned off.

#### Clean the air filter and outside panel

- Be sure to replace the air filter to its original place after cleaning. (Refer to "8. MAINTENANCE" on page 77.)  
For information on how to install, remove, or clean an optional sold air filter, refer to the user's manual attached to the air filter.

#### NOTE

The inside of the air conditioner may become contaminated after several seasons of use, potentially causing performance degradation and water leakage.  
Ask your local dealer for details on cleaning the inside of the indoor unit. This operation requires a qualified service person.

## 9. NOT MALFUNCTION OF THE AIR CONDITIONER

### 1. THE AIR CONDITIONER DOES NOT OPERATE

- The air conditioner does not restart immediately after the ON/OFF button is pressed.
- The air conditioner does not restart immediately when TEMPERATURE SETTING button is returned to the former position after pushing the button.  
If the OPERATION lamp lights, the air conditioner is in normal condition.  
It does not restart immediately because a safety device operates to prevent overload of the air conditioner.  
After approx. 3 minutes, the air conditioner will turn on again automatically.

#### • The outdoor unit stops.

This is because the indoor temperature has reached the set temperature.  
The indoor unit is in the FAN OPERATION.

#### COOLING OPERATION (AUTOMATIC COOLING OPERATION):

Lower the set temperature.

The operation starts after a while when the air conditioner is in normal condition.

### 2. THE OPERATION SOMETIMES STOPS

- The remote controller displays "U4" and "U5", and the operation stops. However, it will restart in a few minutes.

This is because communication between the indoor and outdoor units or indoor units and remote controllers is shut off and stops the operation due to noise caused by devices other than the air conditioner.  
When the electrical noise decreases, the air conditioner automatically restarts.

### 3. THE FAN SPEED IS DIFFERENT FROM THE SETTING

- Pressing the fan speed control button does not change the fan speed.  
During the COOLING OPERATION, the low fan speed or a gentle wind is used to prevent the discharge of melt water.

### 4. THE AIRFLOW DIRECTION IS DIFFERENT FROM THE SETTING

- The horizontal blades do not swing when the remote controller displays the swing operation.

#### <COOL AND PROGRAM DRY OPERATIONS>

When the operation in a downward airflow direction is set, the airflow direction differs from the display for a period of time to prevent condensation on the horizontal blades.

## 5. HORIZONTAL BLADES DO NOT CLOSE

- The horizontal blades do not close even when operation stops.

This is because the horizontal blades close once airflow from the air conditioner stops. After a while, the horizontal blades close.

## 6. WHITE MIST COMES OUT OF THE AIR CONDITIONER

- When humidity is high during the COOLING OPERATION (In oily or dusty places)

If the inside of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the inside of the indoor unit. Ask your local dealer for details on cleaning the indoor unit.

This cleaning requires a qualified service person. Check the usage environment.

## 7. NOISE OF AIR CONDITIONERS

- A ringing sound after the indoor unit starts.

This sound is generated when the motors for driving the horizontal blades are working. It will quiet down after about a minute.

- A low continuous flow "Shuh" sound which is heard when the air conditioner is in the COOLING

This is the sound of refrigerant gas flowing through both indoor and outdoor units.

- A "Shuh" sound which is heard at the start or immediately after the stop of operation

This is the noise of refrigerant caused by flow stop and flow change.

- A "Pishi-pishi" squeaking sound is heard when the air conditioner is in operation or after the stop of operation.

Expansion and contraction of resin parts caused by temperature change makes this noise.

## 8. DUST FROM THE INDOOR UNITS

- Dust may blow out from the unit after starting operation from long resting time.

Dust absorbed by the unit blows out.

## 9. THE INDOOR UNITS GIVE OFF ODORS

- During operation

The unit absorbs the smell of rooms, furniture, cigarettes, etc., and then emits them. If odor is a concern, you can set to zero fan speed when the indoor temperature reaches the set temperature. For details, contact your local dealer.

## 10. THE AIR CONDITIONER DOES NOT COOL EFFECTIVELY

- The air conditioner is operating in the PROGRAM DRY OPERATION.

This is because program dry mode operates so that the indoor temperature decreases as little as possible. Lower the indoor temperature using the COOLING OPERATION, and then use the PROGRAM DRY OPERATION.

(Refer to "CHARACTERISTICS OF THE PROGRAM DRY OPERATION" on page 75.)

- Read through characteristics of the COOLING OPERATION and characteristics of the PROGRAM DRY OPERATION on page 75.

Read the operation manual that attached to the outdoor unit.

## 10. TROUBLE SHOOTING

### Please check before requesting a service.


- 1. If the air conditioner does not operate at all.

- Check if fuse has blown.  
Turn off the power supply.  
Contact your local dealer.

- Check if the power circuit breaker is blown.

- If the tab of power circuit breaker is in the OFF position, turn the power on with the power circuit breaker switch. If the tab of power circuit breaker is in the trip position do not turn the power on with the power circuit breaker switch.

Contact your local dealer.



Power circuit breaker  
(Earth leakage breaker)

- Check if there is a power failure.

- Wait until power is restored. If power failure occurs during operation, the air conditioner automatically restarts immediately after the power supply recovers.

- 2. If the air conditioner stops after operating the air conditioner.

- Check if the air inlet or outlet of outdoor or indoor unit is blocked by obstacles.

- Remove the obstacle and make it well-ventilated. The horizontal blades at the air outlet are closed while the indoor stops.

- Check if the air filter is clogged. Ask a qualified service person to clean the air filters.

- A decrease in the airflow volume of the air conditioner will result and the performance of the air conditioner will be degraded and power consumption will increase if the air filter is clogged with dust or dirt.

- In addition, this may cause dew condensation at the air outlet.

(Refer to "8. MAINTENANCE" on page 77.)

- 3. The air conditioner operates but it does not sufficiently cool.

- Check if the air inlet or outlet of outdoor or indoor unit is blocked by obstacles. Remove the obstacle and make it well-ventilated.

- The horizontal blades at the air outlet are closed while the unit stops.

- Obstacles decrease the fan speed, and cause performance decrease and breakage when discharged air is suctioned.

- They cause a waste of electricity, increase operating noise, or that may stop the devices.

- Check if the air filter is clogged. Ask a qualified service person to clean the air filters.

- A decrease in the airflow volume of the air conditioner will result and the performance of the air conditioner will be degraded and power consumption will increase if the air filter is clogged with dust or dirt.

- In addition, this may cause dew condensation at the air outlet.

(Refer to "8. MAINTENANCE" on page 77.)

- Check if the set temperature is not proper.

- Set to an appropriate temperature, fan speed, and discharge direction.

- Check if the FAN SPEED button is set to LOW SPEED. Set to an appropriate temperature, fan speed, and discharge direction.

- Check if the airflow direction is not proper.

- Set to an appropriate temperature, fan speed, and discharge direction.

- Check if the doors or the windows are open.  
Shut doors or windows to prevent wind from coming in.
- Check if the ventilation fan is in operation.
- Check if direct sunlight enters the room use curtains or blinds.
- When there are too many inhabitants in the room.
- Check if the heat source of the room is excessive.

**4. Operation was performed or stopped although the ON/OFF button was not pressed.**

- Are you sure that the ON/OFF timer operation is not used?  
Turn off the ON/OFF timer.  
Please refer to operation manual attached to the remote controller.
- Are you sure that any remote control device is not connected?  
If the problem is not solved after checking the above points, please do not try to repair it yourself.  
In such cases, always ask your local dealer. At this time, please tell the symptom and model name (written on the model name plate).

**If one of the following malfunction occurs, take the measures shown below and contact your local dealer.**  
The air conditioner must be repaired by a qualified service person.

—  **WARNING** —

**When the air conditioner is malfunctioning (giving off a burning odor, etc.) turn off power to the air conditioner and contact your local dealer.**

Continued operation under such circumstances may result in a failure, electric shocks or a fire. Contact your local dealer.

- If a safety device such as a fuse, a power circuit breaker or an earth leakage breaker frequently actuates;  
**Measure:** Do not turn on the main power switch.
- If the ON/OFF switch does not properly work;  
**Measure:** Turn off the main power switch.
- If water leaks from the indoor unit.  
**Measure:** Stop the operation.
- If a malfunction occurs, either one of the following messages will appear on the Basic screen on the wired remote controller during operation.

For more information, refer to the operation manual attached to the remote controller.


**Measure:** Notify your local dealer and inform malfunction code of the display.

**Read the operation manual attached to the outdoor unit.**



## WIRING DIAGRAM

APPLICABLE MODEL: RZCFQ71CV16



**[CAUTIONS] < CONCERNING HANDLING OF HIGH VOLTAGE PARTS >**


AFTER THE SAFETY BREAKER IS TURNED OFF,  
BECAUSE OF THE DANGER OF HIGH VOLTAGE.

# WIRING DIAGRAM


APPLICABLE MODEL: RZCFQ90CV16

1~220-240

Applicable For CV1 Series Only



## WIRING DIAGRAM



**NOTE :** 1. REFER TO THE NAMEPLATE FOR THE POWER REQUIREMENTS.

A1P	A2P, A3P	PRINTED CIRC
C110		CAPACITOR
E		EARTH
F1U	F2U, F3U	FUSE
F1S		SURGE ABSORB
J	MR30	JUMPER
K4R	K10R, K20R	MAGNETIC REL
L		LINE
M1C		COMPRESSOR M
M1F		FAN MOTOR
N		NEUTRAL

111

**[CAUTIONS] < CONCERNING HANDLING OF HIGH VOLTAGE PARTS >**

AFTER THE SAFETY BREAKER IS TURNED OFF  
BECAUSE OF THE DANGER OF HIGH VOLTAGE.

AB

## PROTECT THE ENVIRONMENT FROM E-WASTE ( GUIDELINES)

Meaning of E-waste under E-Waste (Management) Rules,2022 (E-waste Rules)  
 -Waste electrical and electronic equipment, whole or in part of reject from their manufacturing and repair process, which are intended to be discarded.  
 Our product is RoHS compliant.



**Don't dump Electrical and Electronic Products in Garbage Bins**

### DO'S & DONT'S

DO'S	
Run and maintain the air conditioner as per the instructions given in the operation / instruction manual	✓
Ensure that an authorised person repairs your air conditioner	✓
Call our local authorised dealer or our toll free number to dispose your air conditioner	✓
Contact an authorised dealer in case of installation or de-installation	✓
Consult our local authorised dealer or our toll free number on the life span of the air conditioner	✓

DONT'S	
Do not try to repair your air conditioner on your own	✗
Do not sell or dispose your air conditioner or parts to an unauthorised Kabbadi wala / Scrap Dealer / Ragpickers	✗
Do not dismantle your air conditioner on your own	✗
Do not get your air conditioner or any parts repaired by an unauthorised person	✗
Do not dispose off the E-waste in landfills	✗
Do not use the air conditioner as furniture after its use	✗

Customer Contact Center : 011-4031 9300/1860-180-3900  
 For further information visit us at [www.daikinindia.com](http://www.daikinindia.com)

**DAIKIN AIRCONDITIONING INDIA PVT. LTD.**

12th Floor, Building No. 9, Tower A,  
DLF Cyber City, DLF Phase - III  
Gurgaon - 122002, Haryana (India)  
Tel : +91-124-4555444  
Fax: +91-124-4555333