

# INSTALLATION MANUAL OPERATIONAL MANUAL

# **Air Conditioner**

# MODELS (Ceiling-mounted Duct type)

INDOOR	OUTDOOR
FDMA100AV16	RZA100AV16
FDMA125AV16	RZA125AV16
FDMA140AV16	RZA140AV16

Page No. Installation Manual.....01-41 Operation Manual......42-55 E-Waste (Guidelines)......56 Split Type Air Conditioner

English

CAREFULLY READ THESE INSTRUCTIONS BEFORE INSTALLATION. KEEP THIS MANUAL IN A HANDY PLACE FOR FUTURE REFERENCE.

# **DAIKIN** Split System Air Conditioner INSTALLATION MANUAL <FOR INDOOR UNIT> READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION.

NEW REFRIGERANT (R32) SERIES FDMA100AV16, FDMA125AV16, FDMA140AV16

Page No. INSTALLATION MANUAL OF INDOOR 1-20 INSTALLATION MANUAL OF OUTDOOR 21-41

## CONTENTS

1.	SAFETY PRECAUTIONS	1
2.	BEFORE INSTALLATION	2
3.	SELECTION OF INSTALLATION LOCATION	4
4.	PREPARATION BEFORE INSTALLATION	5
5.	INSTALLATION OF INDOOR UNIT	6
	REFRIGERANT PIPING WORK	
	DRAIN PIPING WORK	
	DUCT WORK	
9.	ELECTRIC WIRING WORK	11
10.	FIELD SETTING	14
11.	TEST OPERATION	16
12.	UNPACKING & PACKING INSTRUCTION OF INDOOR UNIT	19

## Important information regarding the refrigerant used

This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.

Refrigerant type: R32


GWP<sup>(1)</sup> value: 675\*

<sup>(1)</sup>GWP = global warming potential

The refrigerant quantity is indicated on the unit name plate.

\*This value is based on F gas regulation (824/2006).

## **1. SAFETY PRECAUTIONS**



Please read these "SAFETY CONSIDERATIONS" carefully before installing air conditioning unit and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation. Please instruct the customer on how to operate the unit and keep it maintained.

Also, inform customers that they should store this installation manual along with the operation manual for future reference.

# This air conditioner comes under the term "appliances not accessible to the general public".

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

• This manual classifies the precautions into WARNINGS and CAUTIONS.

Be sure to follow all the precautions below: They are all important for ensuring safety.

	Indicates a potentially
	hazardous situation which,
	if not avoided, could result in
•	death or serious injury.
	Indicates a potentially
	hazardous situation which,
	if not avoided, may result in
	minor or moderate injury.
	It may also be used to alert
	against unsafe practices.

 After the installation is completed, test the air conditioner and check if the air conditioner operates properly. Give the user adequate instructions concerning the use and cleaning of the indoor unit according to the Operation Manual. Ask the user to keep this manual in a handy place for future reference.

## 

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance must be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odor.
- Floor area required for installation of the equipment, refer to the installation manual of the outdoor unit.
- Comply with national gas regulations.
- Ask your local dealer or qualified personnel to carry out installation work.

Improper installation may result in water leakage, electric shocks or a fire.

Perform installation work in accordance with this installation manual.

Improper installation may result in water leakage, electric shocks or a fire.

• Consult your local dealer regarding what to do in case of refrigerant leakage.

When the air conditioner is installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage.

Otherwise, this may lead to an accident due to oxygen deficiency.

• Be sure to use only the specified parts and accessories for installation work.

Failure to use the specified parts may result in the air conditioner falling down, water leakage, electric shocks, a fire, etc.

• Install the air conditioner on a foundation that can withstand its mass.

Insufficient strength may result in the air conditioner falling down and causing injury.

In addition, it may lead to vibration of indoor units and cause unpleasant chattering noise.

- Carry out the specified installation work in consideration of strong winds, typhoons, or earthquakes.
   Improper installation may result in an accident such as air conditioner falling.
- Make certain that all electrical work is carried out by qualified personnel according to the applicable legislation (Note 1) and this installation manual, using a separate circuit. In addition, even if the wiring is short, make sure to use a wiring that has sufficient length and never connect additional wiring to make the length sufficient.

Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire. (Note 1) applicable legislation means "All international,

and/or codes which are relevant and applicable for a certain product or domain".

- Earth the air conditioner. Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring. Incomplete earthing may cause electric shocks or a fire.
- Be sure to install an earth leakage breaker.
   Failure to do so may cause electric shocks and a fire.
- Disconnect the power supply before touching the electric components.
- If you touch the live part, you may get electric shocks.
- Make sure that all wiring is secure, using the specified wirings and ensuring that external forces do not act on the terminal connections or wirings. Incomplete connection or fixing may cause an overheat or a

fire.

- When wiring between the indoor and outdoor units and wiring the power supply, form the wirings orderly so that the control box lid can be securely fastened.
   If the control box lid is not in place, overheating of the terminals, electric shocks or a fire may be caused.
- If refrigerant gas leaks during installation work, ventilate the area immediately.

Toxic gas may be produced if refrigerant gas comes into contact with a fire.

- After completing the installation work, check to make sure that there is no leakage of refrigerant gas.
   Toxic gas may be produced if refrigerant gas leaks into the room and comes into contact with a source of a fire, such as a fan heater, stove or cooker.
- Never directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.
- When installing or relocating the air conditioner, be sure to bleed the refrigerant circuit to ensure it is free of air and use only the specified refrigerant (R32). The presence of air or other foreign matter in the refrigerant circuit causes abnormal pressure rise, which may result in equipment damage and even injury.
- Do not allow children to climb on the outdoor unit and avoid placing objects on the unit.
- Injury may result if the unit becomes loose and falls. • When flared joints are reused, the flare part shall be
- re-fabricated.

# 

• Install drain piping according to this installation manual to ensure good drainage, and insulate the piping to prevent condensation.

Improper drain piping may cause water leakage, make the furniture get wet.

• Install the air conditioner, power supply wiring, remote controller wiring and transmission wiring at least 1 meter away from televisions or radios to prevent image interference or noise.

(Depending on the radio waves, a distance of 1 meter may not be sufficient to eliminate the noise.)

- Install the indoor unit as far as possible from fluorescent lamps.
- Do not install the air conditioner in places such as the following:
  - 1. Where there is mist of oil, oil spray or vapor for example a kitchen.
    - Resin parts may deteriorate, and fall out or water may leak.
  - 2. Where corrosive gas, such as sulfurous acid gas, is produced.

Corrosion of copper pipings or brazed parts may cause the refrigerant to leak.

3. Where there is machinery which emits electromagnetic waves.

Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.

- 4. Where flammable gases may leak, where carbon fibre or ignitable dust is suspended in the air or where volatile flammables, such as thinner or gasoline are handled. If the gas should leak and remain around the air conditioner, it may cause ignition.
- The air conditioner is not intended for use in a potentially explosive atmosphere.
- Pay careful attention when transporting the product. Carry the product by the handle sections indicated on the packaging material.

Do not hold the PP band since the PP band can become loose and may result in danger.

- Do not touch the heat exchanger fins. Inadvertently touching the fins can cause injury.
- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals.

Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.

- Install in a machine room that is free of moisture. The unit is designed for indoor use.
- The refrigerant R32 requires that strict precautions be observed for keeping the system clean, dry and tightly sealed.
  - Clean and dry

Strict measures must be taken to keep impurities (including SUNISO oil and other mineral oils as well as moisture) out of the system.

 Tightly sealed R32 contains no chlorine, does not destroy the ozone layer and so does not reduce the earth's protection against harmful ultraviolet radiation.

R32 will contribute only slightly to the greenhouse effect if released into the atmosphere.

- Only qualified personnel can handle, fill, purge and dispose of the refrigerant.
- Disposal requirements
  - Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.

## 2. BEFORE INSTALLATION

When unpacking the indoor unit or moving the unit after unpacked, hold the hangers (4 places) and do not apply force to other parts (particularly refrigerant piping, drain piping).


- Make sure to check in advance that the refrigerant to be used for installation work is R32. (The air conditioner will not properly operate if a wrong refrigerant is used.)
- For installation of the outdoor unit, refer to the installation manual of the outdoor unit.
- Do not throw away the accessories until the installation work is completed.
- After the indoor unit is carried into the room, try to avoid the indoor unit from getting damaged, take measures to protect the indoor unit with packing materials.

- (1) Determine the route to carry the unit into the room.
- (2) Do not unpack the unit until it is carried to the installation location.
   Where unpacking is unavoidable, use a sling of soft material or protective plates together with a rope when lifting, to avoid damage or scratches to the indoor unit.
- Have the customer actually operate the air conditioner while looking at the operation manual. Instruct the customer how to operate the air conditioner (particularly cleaning of the air filters, operation procedures and temperature adjustment).
- Do not use the air conditioner in a salty atmosphere such as coastal areas, vehicles, vessels or where voltage fluctuation is frequent such as factories.
- Take off static electricity from the body when carrying out wiring and the control box lid is removed. The electric parts may get damaged.

## 2-1 ACCESSORIES

# Check if the following accessories are attached to the indoor unit.

Table 1



## 2-2 OPTIONAL ACCESSORIES

- A remote controller is required for the indoor unit. (No remote controllers are required for multi slave units in simultaneous multi operation.)
- Install the remote controller to the place where the customer has given consent.
   Refer to the catalog for the applicable model.
   (Refer to the installation manual attached to the remote)

controller for how to install.) CARRY OUT THE WORK GIVING CAUTION TO THE FOLLOWING ITEMS AND AFTER THE

WORK IS COMPLETED CHECK THESE AGAIN.

# 1. Items to be checked after the installation work is completed

completed		
Items to be checked	In case of defective	Check column
Are the indoor and outdoor units rigidly fixed?	Drop · vibration · noise	
Are the installation works of the outdoor and indoor units completed?	Does not operate - burnout	
Have you carried out a leakage test with the test pressure specified in the outdoor unit installation manual?	Does not cool / Does not heat	
Is the insulation of refrigerant piping and drain piping completely carried out?	Water leakage	
Does the drain flow out smoothly?	Water leakage	
Is the power supply voltage identical to that stated in the manufacturer's label on the air conditioner?	Does not operate - burnout	
Are you sure that there is no wrong wiring or piping or no loose wiring?	Does not operate · burnout	
Is earthing completed?	Danger in case of leakage	
Are the sizes of electric wiring according to the specification?	Does not operate · burnout	
Are any of air outlets or inlets of the indoor and outdoor units blocked with obstacles?(It may lead to capacity drop due to fan speed drop or malfunction of equipment.)	Does not cool / Does not heat	
Is the external static pressure set correctly?	Does not cool / Does not heat	
Have you recorded the refrigerant piping length and the refrigerant charge amount added?	Refrigerant charge amount is not clear	

Make sure to recheck the items of "SAFETY PRECAUTIONS".

#### 2. Items to be checked at delivery

2. Items to be checked at delivery				
Items to be checked	In case of defective	Check column		
Are the indoor and outdoor units rigidly fixed?	Drop · vibration · noise			
Are the installation works of the outdoor and indoor units completed?	Does not operate · burnout			
Have you carried out a leakage test with the test pressure specified in the outdoor unit installation manual?	Does not cool / Does not heat			
Is the insulation of refrigerant piping and drain piping completely carried out?	Water leakage			
Does the drain flow out smoothly?	Water leakage			
Is the power supply voltage identical to that stated in the manufacturer's label on the air conditioner?	Does not operate · burnout			
Are you sure that there is no wrong wiring or piping or no loose wiring?	Does not operate · burnout			
Is earthing completed?	Danger in case of leakage			
Are the sizes of electric wiring according to the specification?	Does not operate - burnout			
Are any of air outlets or inlets of the indoor and outdoor units blocked with obstacles?(It may lead to capacity drop due to fan speed drop or malfunction of equipment.)	Does not cool / Does not heat			
Is the external static pressure set correctly?	Does not cool / Does not heat			
Have you recorded the refrigerant piping length and the refrigerant charge amount added?	Refrigerant charge amount is not clear			
Points of the operation ex				

In addition to the general usage, since the items in the operation manual with the  $\$   $\land$  WARNING and

▲ CAUTION marks are likely to result in human bodily injuries and property damages, it is necessary not only to explain these items to the customer but also to have the customer read them.


Furthermore, it is necessary to have the customer read through the troubleshooting items while explaining the above items.

## 3. SELECTION OF INSTALLATION LOCATION

Hold the hangers at 4 locations to move the indoor unit when unpacking or after unpacked and do not apply force to the piping (refrigerant and drain) and air outlet flange. If the temperature and humidity in the ceiling is likely to exceed 30°C, RH80%, use the additional insulation stick to the indoor unit.

Use the insulation such as glass wool or polyethylene that has thickness of 10 mm or more. However, keep the insulated outside dimension smaller than the ceiling opening so that the unit may go through the opening at installation.

- (1) Select the installation location that meets the following conditions and get approval of the customer.
  - Where the cool and warm air spreads evenly in the room.
  - Where there are no obstacles in the air passage.
  - Where drainage can be ensured.
  - Where the ceiling's lower surface is not remarkably inclined.
  - Where there is sufficient strength to withstand the mass of the indoor unit. (If the strength is insufficient, the indoor unit may vibrate and get in contact with the ceiling and generate unpleasant chattering noise.)
  - Where a space sufficient for installation and service can be ensured.
  - Where the piping length between the indoor and the outdoor units is ensured within the allowable length. (Refer to the installation manual of the outdoor unit.)
  - Where there is no risk of flammable gas leak.



- The H1 dimension indicates the height of the product.
- Determine the H2 dimension by maintaining a downward slope of at least 1/100 as specified in
   "7. DRAIN PIPING WORK".



[Required installation place]

The dimensions indicate the minimum required space of installation.

Fig.1

#### <Failure example>

If there is an obstacle in the airflow path or proper installation space is not provided, the indoor unit will cause air volume reduction and take in air blown out of the indoor unit, thus resulting in performance degradation or turning the thermostat OFF frequently.

# 

• Install the indoor and outdoor units, power supply wiring, remote controller wiring and transmission wiring at least 1 meter away from televisions or radios to prevent image interference or noise.

(Depending on the radio waves, a distance of 1 meter may not be sufficient to eliminate the noise.)

- Install the indoor units as far as possible from fluorescent lamps.
- (2) Use hanging bolts for installation. Investigate if the installation place can withstand the mass of the indoor unit and if necessary, hang the indoor unit with bolts after it is reinforced by beams etc.

## 4. PREPARATION BEFORE INSTALLATION

- (1) Check the relation of location between the ceiling opening and the indoor unit hanging bolts.
  - Provide one of the following service spaces for the maintenance and inspection of the control box and drain pump or for other services.
  - 1. Inspection hatch 1 and 2 ( $450 \times 450$ ) for the el. compo. box and a minimum space of 300 mm at the bottom of the product. (Refer Fig. 2-2)
  - Inspection hatch 1 (450 × 450) on the control box side and inspection hatch 2 on the bottom of the product.(Fig. 2-3, arrow A-1)
  - Inspection hatch 3 on the bottom of the product and on the bottom side of the control box, see direction view A-2 (Refer Fig. 2-3)






Fig. 2-1







Model	В	С	D
100,125,140	1400	1438	1700

(All dimensions are in mm)

- (2) Mount canvas ducts to the air outlet and inlet so that the vibration of the indoor unit will not be transmitted to the ducts or ceiling. Furthermore, attach sound absorbing material (thermal insulation material) to the duct inner walls and anti-vibration rubber to the hanging bolts (refer to 8. DUCT WORK).
- (3) The indoor unit is set to standard external static pressure.
  - If external static pressure is higher or lower than the standard set value, the remote controller may be used to make on-site setting change in the external static pressure. Refer to **10. FIELD SETTING.**


## (4) Open installation holes

- (in the case of installation onto the existing ceiling).
- Open the installation holes on the ceiling of the installation location, and work on the refrigerant piping, drain piping, remote controller wiring and wiring between the indoor and outdoor units to the piping connection port and wiring connection port of the indoor unit (refer to each piping and wiring procedure items).
- Ceiling framework reinforcement may be required in order to keep the ceiling horizontal and prevent ceiling vibration after opening the ceiling holes. For details, consult your building and upholstery work contractors.

#### (5) Install the hanging bolts.

Use M10 bolts for hanging the indoor unit. Use hole-in anchors for the existing bolts and embedded inserts or foundation bolts for new bolts, and fix the indoor unit firmly to the building so that it may withstand the mass of the unit.

In addition, adjust clearance (50 -100mm) from the ceiling in advance.



Note) Components shown in the figure above are all local procurement.

Fig. 3

## 


- Secure a sufficient maintenance space for the drain pan and electrical components before installing the indoor unit.
- Secure a sufficientmaintenance space for the filter chamber, and peripheral components before installing the indoor unit.

## 5. INSTALLATION OF INDOOR UNIT


Depending on the optional parts, it may be easier to attach them before installing the indoor unit. Refer to also the installation manual attached to the optional parts. For installation, use the attached installation parts and specified parts.

- (1) Install the indoor unit temporarily.
  - Connect the hanging brackets to the hanging bolts. Be sure to the use and tighten the nut and washer(procured in the field) for each hanging bracket from both upper and lower sides of the hanging bracket. (Refer to the Fig. 4) At that time, the fall of the washer for the hanging bracket can be prevented if the washing fixing plate (8) is used.

## [Fixing hanging brackets]




## [Fixing method of washers]





- Keep the air outlet covered with a protective sheet to prevent weld spatter and other foreign materials from entering the indoor unit and damaging the resin drain pan. (If holes or cracks are generated in the resin drain pan, water can leak.)
- (2) Adjust so that the unit is properly positioned.
- (3) Check the level of the unit. (Refer to Fig. 5)
- (4) Remove the washer fixing plate used for preventing the washer for hanger from dropping and tighten the upper side nut.





# 

• Install the indoor unit leveled.

If the indoor unit is inclined and the drain piping side gets high, it may cause malfunction of float switch and result in water leakage.

- Attach nuts on the upper and lower side of hanger. If there is no upper nut and the lower nut is over-tightened, the hanger and the top plate will deform and cause abnormal sound.
- Do not insert materials other than that specified into the clearance between the hanger and the washer for hanger.

Unless the washers are properly attached, the hanging bolts may come off from the hanger.

## 

The indoor unit must be securely installed on a place that can withstand the mass.

If the strength is insufficient, the indoor unit may fall down and cause injuries.

## 6. REFRIGERANT PIPING WORK

- For the outdoor unit refrigerant piping, refer to the installation manual of the outdoor unit.
- Carry out insulation of both gas and liquid refrigerant piping securely. If not insulated, it may cause water leakage. For gas piping, use insulation material of which heat resistant temperature is not less than 120°C.
   For use under high humidity, strengthen the insulation

material for refrigerant piping. If not strengthened, the surface of insulation material may sweat.

• Before installation work, make sure that the refrigerant is R32. (Unless the refrigerant is R32, the normal operation cannot be expected.)

## 

When flared joints are reused in indoors, the flare part shall be re-fabricated.

#### 

This air conditioner is a dedicated model for new refrigerant R32. Make sure to meet the requirements shown below and carry out installation work.


- Use dedicated piping cutters and flaring tools for R32.
- When making a flare connection, coat the flared inner surface only with ether oil or ester oil.
- Use only the flare nuts attached to the air conditioner. If other flare nuts are used, it may cause refrigerant leakage.
- To prevent contamination or moisture from getting into the piping, take measures such as pinching or taping the pipings.

Do not mix substance other than the specified refrigerant such as air into the refrigeration circuit.

If the refrigerant leaks during the work, ventilate the room.

- The refrigerant is pre-charged in the outdoor unit.
- When connecting the pipings to the air conditioner, make sure to use a spanner and a torque wrench as shown in Fig. 6.
- For the dimension of flared part and the tightening torque, refer to the Table 2.
- When making a flare connection, coat the flare inner surface only with ether oil or ester oil. (Refer to Fig. 7)

Then, turn the flare nut 3 to 4 times with your hand and screw in the nut.








Fig. 7

Table 2

Piping size (mm)	Tightening torque (N·m)	Dimension for processing flare A (mm)	Flare shape
φ 9.5	36.3 ± 3.6	13.0 ± 0.2	B0.4-0.8
φ 15.9	68.6±6.8	19.5 ± 0.2	

## 

# Do not have oil adhere to the screw fixing part of resin parts.

If oil adheres, it may weaken the strength of screwed part. **Do not tighten flare nuts too tight.** 

If a flare nut cracks, the refrigerant may leak.

• If there is no torque wrench, use Table 3 as a rule of thumb.

When tightening a flare nut with a spanner harder and harder, there is a point where the tightening torque suddenly increases.

From that position, tighten the nut additionally at the angle shown in Table 3.

After the work is finished check securely that there is no gas leak.

If the nut is not tightened as instructed, it may cause slow refrigerant leak and result in malfunction (such as does not cool or heat).


#### Table 3

Piping size (mm)	Tightening angle	Recommended arm length of tool used
φ9.5	60° - 90°	approx. 200 mm
φ 15.9	30° - 60°	approx. 300 mm

# 

# Insulation of field piping must be carried out up to the connection inside the casing.


If the piping is exposed to the atmosphere, it may cause sweating, burn due to touching the piping, electric shocks or a fire due to the wiring touching the piping. On completion of installation work, check that there is no gas leakage. Refer to the illustrations on the right hand side and be sure to perform heat insulation work on the piping joints after gas leakage. (Refer Fig.8)



- Use the insulation for fitting (3) and (4) provided to the liquid piping and gas piping, respectively and conduct heat insulation work. (Tighten both edges of the insulation for fitting(3) and (4) for each joint with clamp(7)).
- Make sure that the joint of the insulation for fitting(4) and (5) for the joint on the liquid piping and gas piping side faces upwards.
- Wrap the middle sealing material(6) around the insulation for fitting (3) and (4) for the joint (flare nut part).

• Before brazing refrigerant piping, have nitrogen flow through the refrigerant piping and substitute air with nitrogen (NOTE 1) (**Refer to Fig. 9**). Then, carry out brazing (NOTE 2).

After all the brazing works are finished carry out flare connection with the indoor unit. (Refer to Fig. 8)



## NOTE

- 1. The proper pressure for having nitrogen flow through the piping is approximately 0.02 MPa, a pressure that makes one feel like slight breeze and can be obtained through a pressure reducing valve.
- 2. Do not use flux when brazing refrigerant piping. Use phosphor copper brazing filler metal (BCuP-2: JIS Z 3264/B-Cu93P-710/795: ISO 3677) that does not require flux.

(If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the refrigerant circuit will be affected badly.)

3. When carrying out leakage test of refrigerant piping and the indoor unit after the installation of indoor unit is finished, confirm the connecting outdoor unit installation manual for test pressure.

Refer to also the outdoor unit installation manual or technical document for refrigerant piping.

4. In case of refrigerant shortage due to forgetting additional refrigerant charge etc., it will result in malfunction such as does not cool.

Refer to the outdoor unit installation manual or technical document for refrigerant piping.


## 

## Do not use antioxidant when brazing piping.

It may result in malfunction of components and clogging of piping due to residue.


## 7. DRAIN PIPING WORK

- (1) Carry out drain piping.
  - Carry out drain piping so that drainage is ensured.
  - Select the piping diameter equal to or larger than (except for riser) that of the connection piping (polyvinyl chloride piping, nominal diameter 25 mm, outside diameter 32 mm).
  - Install the drain piping as short as possible with downward inclination of 1/100 or more and such that air may not stagnate. (**Refer to Fig. 10**)



## 

- To avoid the attached drain hose (2) getting excessive force, do not bend nor twist it. It may cause water leakage.
- As for drain piping connection, do not connect the drain hose directly to a sewage that gives off ammonia odor. (The ammonia in the sewage may go through the drain piping and corrode the heat exchanger of the indoor unit.)
- In case of centralized drain piping, carry out piping work according to the procedure shown in the following Fig. 14.



- (Refer to the technical document)Positioning the upward drain piping at an angle may cause float switch malfunction and lead to water leakage.
- While replacing with new indoor unit, use the attached new drain hose (2) and the metal clamp (1).
   If an old drain hose or a metal clamp is used, it may cause water leakage.
- (2) After piping is finished, check if the drain flows smoothly.

#### [When the electric wiring work is finished]

 Gradually pour 1 litre of water from the inspection port at the bottom of the drain socket on the left side of the drain socket into the drain pan giving caution to avoid splashing water on the electric components such as drain pump and confirm drainage by operating the indoor unit under cooling mode according to 10. FIELD SETTING. (Refer to Fig. 15)




Fig. 15

## [When the electric wiring work is not finished]

• The electric wiring works (including earthing) must be carried out by a qualified electrician.

- If a qualified person is not present, after the electric wiring work is finished, check the drainage according to the method specified in [When the electric wiring work is finished].
  - 1. Open the control box lid and connect the single phase 220-240V power supply to the terminal (L, N) on the terminal block (X2M).

Connect the earth wiring to the earth terminal.

- 2. Make sure the control box lid is closed before turning on the power supply.
  - Throughout the whole process, carry out the work giving caution to the wiring around the control box so that the connectors may not come off.
- **3.** Gradually pour 1 litre of water from the air outlet on the left side of the drain socket into the drain pan giving caution to avoid splashing water on the electric components such as drain pump. (**Refer to Fig. 15**)
- 4. When the power supply is turned on, the drain pump will operate. Drainage can be checked at the transparent part of the drain socket.

(The drain pump will automatically stop after 10 minutes.)

The drainage of water can be confirmed with water level change in the drain pan through the access window.

- Do not connect the drain piping directly to the sewage that gives off ammonia odor.
   The ammonia in the sewage may go through the drain piping and corrode the heat exchanger of the indoor unit.
- Do not apply external force to the float switch. (It may result in malfunction)
- Do not touch the drain pump. Touching the drain pump may cause electric shocks.
  Do not apply external force to the float switch.
- External force may cause a float switch malfunction.
- 5. Turn off the power supply after checking drainage, and remove the power supply wiring.
- 6. Attach the control box lid as before.
- On the completion of the drainage check, refer to the following illustration, and use the provided large sealing pad (5) and insulate the metal clamp (1) and drain hose (2)




Fig. 16

## 8. DUCT WORK

# Pay utmost attention to the following items and conduct the ductwork.


- Check that the duct is not in excess of the setting range of external static pressure for the unit. (Refer to the technical datasheet for the setting range.)
- Attach a canvas duct each to the air outlet and air inlet so that the vibration of the equipment will not be transmitted to the duct or ceiling.

Use a sound-absorbing material (insulation material) for the lining of the duct and apply vibration insulation rubber to the hanging bolts.

- At the time of duct welding, perform the curing of the duct so that the sputter will not come in contact with the drain pan for the filter.
- If the metal duct passes through a metal lath, wire lath, or plate of a wooden structure, separate the duct and wall electrically.
- Be sure to heat insulate the duct for the prevention of dew condensation. (Material: Glass wool or styrene foam; Thickness: 25 mm)
- Explain the operation and washing methods of the locally procured components (i.e., the air filter, air inlet grille, and air outlet grille) to the customer.
- Locate the air outlet grille on the indoor side for the prevention of drafts in a position where indirect contact with people.
- The air conditioner incorporates a function to adjust the fan to rated speed automatically. (10. FIELD SETTING) Therefore, do not use booster fans midway in the duct.

## Connection method of ducts on air inlet and outlet sides.

- Connect the field supply duct in alignment with the inner side of the flange.
- Connect the flange and unit with the flange connection screw.
- Wrap aluminum tape around the flange and duct joint in order to prevent air leakage.





# 

Connect the flange and unit with the flange connection screw field supply regardless of whether the duct is connected to the air inlet side.

## 9. ELECTRIC WIRING WORK

## 9-1 GENERAL INSTRUCTIONS

• Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate dedicated circuit.

Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.

- Make sure to install an earth leakage breaker.
   Failure to do so may cause electric shocks and a fire.
- Do not turn on the power supply (branch switch, branch overcurrent circuit breaker) until all the works are finished
- Multiple number of indoor units are connected to one outdoor unit. Name each indoor unit as A-unit, B-unit ..... and the like. When these indoor units are wired to the outdoor unit, always wire the indoor unit to the terminal indicated with the same symbol on the terminal block. If the wiring and the piping are connected to the different indoor units and operated, it will result in malfunction.
- Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.
- Do not connect the earth wiring to gas or water pipings, lightning conductor or telephone earth wiring.
  - Gas piping ......Ignition or explosion may occur if the gas leaks.
  - Water piping ......Hard vinyl tubes are not effective earths.
  - Lightning conductor or telephone earth wiring ...... Electric potential may rise abnormally if struck by a lightning bolt.
- For electric wiring work, refer to also the "WIRING DIAGRAM" attached to the control box lid.
- Carry out wiring between the outdoor units, indoor units and the remote controllers according to the wiring diagram.
- Carry out installation and wiring of the remote controller according to the "installation manual" attached to the remote controller.
- Do not touch the Printed Circuit Board assembly. It may cause malfunction.

## 9-2 SPECIFICATION FOR FIELD SUPPLY FUSES AND WIRING

Table 4

	Р	ower supply	Remote controller wiring Transmission wiring		
Model	Field fuses ───	Wiring	Size	Wiring	Size
FDMA100AV16 FDMA125AV16 FDMA140AV16	15A	H05VV-U3G NOTE 1)	Wiring size and length must comply with local codes or IEC60335-1 (Table 11).	Vinyl cord with sheath or cable (2 core) NOTE 2)	0.75- 1.25 mm²

The lengths of remote controller wiring are as follows:

Remote controller wiring (indoor unit - remote controller)....Max. 500 m


## NOTE

- 1. Shows only in case of protected piping. Use H07RN-F in case of no protection. (Supply cords shall not be lighter than polychloroprene sheathed flexible cord (code designation 60245 IEC 57)).
- 2. Vinyl cord with sheath or cable (Insulated thickness : 1 mm or more)

## 9-3 WIRING CONNECTION METHOD

## - $\land$ CAUTION FOR WIRING

• For connection to the terminal block, use ring type crimp style terminals with insulation sleeve or insulate the wirings properly.





- Connect the terminal as shown in Fig. 19.
- Do not carry out soldering finish when stranded wirings are used. (Otherwise, the loosening of wiring may result in abnormal heat radiation.)




Fig. 19

(Abnormal heating may occur if the wirings are not tightened securely.)

- Use the required wirings, connect them securely and fix these wirings securely so that external force may not apply to the terminals.
- Use a proper screw driver for tightening the terminal screws. If an improper screw driver is used, it may damage the screw head and a proper tightening cannot be carried out.
- If a terminal is over tightened, it may be damaged. Refer to the table shown below for tightening torque of terminals.


Та	b	e	5
1 a			J

	Tightening torque (N·m)
Terminal block for remote controller and transmission wirings	0.88 ± 0.08
Terminal for power supply	1.47 ± 0.14
Earth terminal	1.47 ± 0.14


• Do not carry out soldering finish when stranded wirings are used.


# 

• When wiring, form the wirings orderly so that the control box lid can be securely fastened. If the control box lid is not in place, the wirings may come out or be sandwiched by the box and the lid and cause electric shocks or a fire.



(2) Connect the wiring into the control box through the wiring intake beside the control box.





Wiring between the indoor and outdoor units (high vlotage) Earth wiring(high voltage) Power supply wiring (high voltage)

(low voltage)

 Wer supply wiring (high voltage)

 Terminal block (X3M)


 File

 File




- (4) Mount the control box lid and wrap the wire sealing material (small) (9) so that the wiring through hole will be covered by the sealing material.
  - Seal the clearance around the wirings with putty or insulating material (field supply).
     (If insects and small animals get into the indoor unit,

short-circuiting may occur inside the control box.)



# (5) Mount the provided wire fixing bracket(10) with the wire fixing screw(11).Fix each wire with the provided clamp(7).



## WIRING EXAMPLE

## 

Be sure to install an earth leakage breaker to the outdoor unit. This is to avoid electric shocks or a fire.

For the wiring of outdoor units, refer to the installation manual attached to the outdoor units. Confirm the system type.

Pair type:


1 remote controller controls 1 indoor unit (standard system). (Refer to Fig. 25)

- Simultaneous operation system: 1 remote controller controls 2 indoor units (2 indoor units operates equally). (Refer to Fig. 26)
- Group control:

1 remote controller controls up to 16 indoor units (All indoor units operate according to the remote controller). (Refer to Fig. 27)

• 2 remote controllers control:

2 remote controllers control 1 indoor unit. (Refer to Fig. 30)



## NOTE

- 1. Terminal numbers of outdoor and indoor units must be matched.
- 2-1. Connect the remote controller only to the master unit.
- **2-2.** The remote controller needs to be wired only to the master unit; it does not need to be connected to the slave units through transition wiring. (Do not connect transition wiring to the slave units.)
- **2-3.** The indoor temperature sensor is effective only for indoor units to which the remote controller is connected.
- 2-4. The length of wiring between the indoor unit and the outdoor unit varies depending on the connected model, the number of connected units, and the maximum piping length.

For details, refer to the technical documents.





Fig. 27

## NOTE

• Terminal numbers of outdoor and indoor units must be matched.

## When implementing group control

- When using as a pair unit or as a master unit for simultaneous operation system, you may carry out simultaneous start/stop (group) control up to 16 units with the remote controller. (Refer to Fig. 28)
- In this case, all the indoor units in the group will operate in accordance with the group control remote controller.
- Select a remote controller which matches as many of the functions (airflow direction, etc.) in the group as possible.



## Wiring Method

- (1) Remove the control box lid.
- (2) Connect crossover wiring between the terminals (P1, P2) inside the control box for the remote controller. (There is no polarity.) (Refer to Fig. 28)






Fig. 30

Two remote controllers control (Controlling 1 indoor unit by 2 remote controllers)


 When using 2 remote controllers, one must be set to "MAIN" and the other to "SUB".

## MAIN/SUB CHANGEOVER

• Refer to the manual attached to the remote controller.

#### **Wiring Method**

- (1) Remove the control box lid.
- (2) Add wiring between the remote controller 2 (Sub) and the terminal (P1, P2) of the terminal block (X3M) for the remote controller in the control box. (There is no polarity.)



\* For simultaneous operation system, be sure to connect the remote controller to the master unit.



## NOTE

• Terminal numbers of outdoor and indoor units must be matched.

## **10.FIELD SETTING**

## 

Before carrying out field setting, check the items mentioned in **1. Items to be checked after the installation work is completed** on page 3.

- Check if all the installation and piping works for the air conditioner are completed.
- Check that the outside panel and piping cover of the indoor and outdoor units are closed.

#### < FIELD SETTING >

After turning on the power supply, carry out field setting from the remote controller according to the installation state.

 Carry out setting at 3 places, "Mode No.", "FIRST CODE No." and "SECOND CODE No.".

The settings shown by \_\_\_\_\_ in the following tables indicate those when shipped from the factory.

- (Note) Though setting of "Mode No." is carried out as a group, if you intend to carry out individual setting by each indoor unit or confirmation after setting, carry out setting with the Mode No. shown in the parenthesis ().
- Ask your customer to keep the manual attached to the remote controller together with the operation manual.
- Do not carry out settings other than those shown in the table.
- Settings are performed by selecting "Mode No.", "FIRST CODE No.", and "SECOND CODE No.".

## 10-1 Settings for external static pressure

• Make settings in either method (a) or method (b).

# (a) Make settings with Air volume automatic adjustment function.

"Air volume automatic adjustment" function: The air volume is adjusted to the rated air volume automatically.

## 

- Be sure to check that the external static pressure is within the specification range before making settings. The external static pressure will not be automatically adjusted and air volume insufficiency or water leakage may result if the external static pressure is outside the range. (Refer to the technical document for the setting range of external static pressure.)
- If the air conditioner is in simultaneous multi operation, the air volume automatic adjustment function cannot be set collectively for the slaves. Therefore, make main and slave unit settings according to **Simultaneous multi operation individual settings**.
- (1) Check that the electrical wiring and duct work have been completed.

(If the closing damper is set midway, be sure to check that the damper is opened. Furthermore, check that the air passage on the suction side is provided with an air filter (field supply)).

(2) If air conditioner has more than one air outlet and air inlet, be sure to make adjustments so that the air volume ratio of each air outlet and the corresponding air inlet will conform to the designed air volume ratio.

In that case, set the operating mode to "Fan". (In the case of changing the air volume, press the fan speed button on the remote controller and change the current selection to "High", "Medium", or "Low".) (3) Make settings to adjust the air volume automatically. After setting the operating mode to "Fan", set the air conditioner to field setting mode with the operation of the air conditioner stopped. Select Mode No. [21] (11 in the case of batch settings), select FIRST CODE No. "7", and set the SECOND CODE No. to "03".

Return to the "Basic screen", and press the ON/OFF button. The indoor unit will go into fan operation for air volume automatic adjustments (at which time, do not adjust the opening of the air outlet or inlet). The air volume adjustments will automatically terminate approximately 1 to 15 minutes after the indoor unit comes into operation, and the indoor unit will come to a stop.

#### Table 6

	FIRST	Setting	SEC	OND CODE	No.
Mode No.	CODE No.	content	01	02	03
11 (21)	7	Air volume adjust- ment	OFF	Air volume adjust- ment completion	Air volume adjust- ment start

(4) After the air conditioner comes to a stop, be sure to check with Mode No. [21] per indoor unit that the above SECOND CODE No. is "02". If the operation of the air conditioner does not stop automatically or the SECOND CODE No. is not set to "02", repeat the setting procedure from (3). If the remote controller displays an error, refer to 11-1 HOW TO DIAGNOSE FOR PROBLEMS and check the error.

#### 

- If airflow pathway changes, such as duct and air outlet changes, are made after air volume adjustments, be sure to make "Air volume automatic adjustment" again.
- If airflow pathway changes, such as duct and air outlet changes, are made after **11.TEST OPERATION** or air conditioner relocation, contact your dealer.

(b) Select external static pressure with the remote controller. Check with Mode No. [21] per indoor unit that the SECOND CODE No. for the above "Air volume adjustment" is set to "01" (OFF). (The SECOND CODE No. is factory set to "01" (OFF).) Change the SECOND CODE No. by referring to the table below according to the external static pressure of the duct to be connected.

Table 7 [For FDMA100AV16/FDMA125AV16/FDMA140AV16]

External static pressure	Mode No.	FIRST CODE No.	SECOND CODE No.
50Pa			05
60Pa		1	06
70Pa			07
80Pa	13 (23)		08
90Pa			09
100Pa		6	10
110Pa		······	11
120Pa			12
130Pa			13
140Pa			14
150Pa			15

In the above table is rated static/factory settings.

#### 10-2 SETTING WHEN AN OPTIONAL ACCESSORY IS ATTACHED

• For setting when attaching an optional accessory, refer to the installation manual attached to the optional accessory.

#### 10-3 SETTING FAN SPEED DURING THERMOSTAT OFF

- Set the fan speed according to the using environment after consultation with your customer.
- When the fan speed is changed, explain the set fan speed to your customer.

#### Table 8

Setting		Mode No.	FIRST CODE No.	SECOND CODE No.
State of fan in operation with	Normal	11 (21) 2	01	
thermostat OFF (cooling and heating)	Stop		2	02
Fan speed during cooling	LL (Extra low)	12 (22)	6	01
thermostat OFF	Setting			02
Fan speed during heating	LL (Extra low)	12 (22)	3	01
thermostat OFF	Setting			02

#### **10-4 SETTING FILTER SIGN**

- A message to inform the air filter cleaning time will be indicated on the remote controller.
- Set the SECOND CODE No. shown in the Table 9 according to the amount of dust or pollution in the room.
- The periodical filter cleaning time can be shortened depending on the environment.

#### Table 9

Contamination	Hours until indication	Mode No.	FIRST CODE No.	SECOND CODE No.
Normal	Approx. 2500 hrs	0		01
More contaminated	Approx. 1250 hrs	10 (20)	0	02
With indication		]	3	01
No indi	cation*		3	02

\* Use "No indication" setting when cleaning indication is not necessary such as the case of periodical cleaning being carried out.

## 10-5 Remote control settings (forced stop or start-stop control)

 Change the SECOND CODE No. by referring to the table below in the case of remote control.

#### Table 10

Setting content	Mode No. (Note)	FIRST CODE No.	SECOND CODE No.
Forced stop	10 (00)	4	01
Start-stop control	12 (22)	I	02

## 10-6 SETTING NUMBER OF THE CONNECTED INDOOR UNITS AS SIMULTANEOUS OPERATION SYSTEM

- When using in simultaneous operation system mode, change the SECOND CODE No. as shown in Table 11.
- When using in simultaneous operation system mode, refer to "SIMULTANEOUS OPERATION SYSTEM INDIVIDUAL SETTING" section to set master and slave units separately.

Table 11

Setting Mode No.		FIRST CODE No.	SECOND CODE No.
Pair system (1-unit)	-	COBLIN	01
Simultaneous operation system (2-unit)			02
Simultaneous operation system (3-unit)	11 (21)	0	03
Double twin multi (4-unit)			04

## 10-7 SIMULTANEOUS OPERATION SYSTEM INDIVIDUAL SETTING

It is easier if the optional remote controller is used when setting the slave unit.


## < Procedure >

- Perform the following procedure when setting the master and slave unit separately.
- \_\_\_\_\_ in the tables indicates factory settings.
- (Note) The "Mode No." is set on a group basis. To individually set a Mode No. for each indoor unit or confirm the settings, set the Mode No. in the parenthesis.
- (1) Change the SECOND CODE No. to "02", individual setting, so that the slave unit can be individually set.

#### Table 12

Setting	Setting Mode No.		SECOND CODE No.
Unified setting	11 (01)	4	01
Individual setting	11 (21)	1 *	02

- (2) Perform field setting (Refer to 10-1 to 10-6) for the master unit.
- (3) Turn off the main power supply switch after (2) is finished.
- (4) Detach remote controller from the master unit and connect it to the slave unit.
- (5) Turn on the main power supply switch again, and as in (1), change the SECOND CODE No. to "02", individual setting for the slave unit.
- (6) Perform field setting (Refer to 10-1 to 10-6) for the slave unit.
- (7) Turn off the main power supply switch after (6) is finished.
- (8) If there is more than one slave unit, repeat steps (4) to (7).
- (9) Detach the remote controller from the slave unit after the setting, and reattach to the master unit. This is the end of the setting procedure.
  - \* You do not need to rewire the remote controller from the master unit if the optional remote controller for slave unit is used. (However, remove the wiring attached to the remote controller terminal block of the master unit.) After the slave unit setting, remove the remote controller wiring, and rewire the remote controller to the master unit. (The indoor unit does not operate properly when two or more remote controllers are attached to the unit in the simultaneous operation system mode.)





## NOTE 🗐

• Terminal numbers of outdoor and indoor units must be matched.

## **11. TEST OPERATION**

Complete all the 1. Items to be checked after the installation work is completed on page 3. Please also refer to the installation manual attached to outdoor unit.

(1) The settings of BRC1H model remote controller should be performed while referring to the manual attached to the remote controller.

## 11-1 HOW TO DIAGNOSE FOR PROBLEMS

With the power on, troubles can be monitored on the remote controller.

The fault diagnosis for BRC1H model remote controller should be performed while referring to the indoor operation manual page11.

## **11-2 MALFUNCTION CODE**

- For places where the malfunction code is left blank, the " 10 " indication is not displayed. Though the system continues operating, be sure to inspect the system and make repairs as necessary.
- Depending on the type of indoor or outdoor unit, the malfunction code may or may not be displayed.

Malfunc- tion code	Descriptions and measures	Remarks
A1	Indoor Printed Circuit Board failure	
A3	Drain level abnormal	
A6	Indoor fan motor overload, over current, lock	
	Indoor Printed Circuit Board connection failure	
A8	Indoor unit power supply voltage abnormal	
AF	Humidifier system malfunction	
	Air cleaner faulty	
AH	Only the air cleaner does not function.	
AJ	Capacity setting failure	Capacity setting adapter or capacity data error, or disconnection of the capac- ity setting adapter, failure to connect the adapter, or the capacity is not set to the data-retention IC.
C1	Transmission error between indoor Printed Circuit Board (Master) and indoor Printed Circuit Board (Slave)	
C4	Indoor heat exchanger liquid pipe temperature sensor malfunction	Abnormal stop is applied depending on the model or condition.
C5	Indoor heat exchanger condenser / evaporator temperature sensor mal- function	Abnormal stop is applied depending on the model or condition.
C9	Suction air thermistor malfunction	Abnormal stop is applied depending on the model or condition.
CJ	Remote controller air thermistor malfunction	Remote controller thermo does not function, but body thermo operation is enabled.
E0	Action of safety device (Outdoor unit)	
E1	Outdoor Printed Circuit Board failure (Outdoor unit)	
E3	High pressure malfunction (Outdoor unit)	
E4	Low pressure malfunction (Outdoor unit)	
E5	Compressor motor lock malfunction (Outdoor unit)	
E6	Compressor motor lock by over current (Outdoor unit)	
E7	Outdoor fan motor lock malfunction (Outdoor unit) Outdoor fan instant over- current malfunction (Outdoor unit)	
E8	Input overcurrent (outdoor unit)	

E9	Electric expansion valve malfunction (Outdoor unit)	
EA	Cooling/heating switch malfunction (Outdoor unit)	
F3	Discharge piping temperature malfunction (Outdoor unit)	
F6	High pressure control (in cooling) (Outdoor unit)	
H0	Sensor fault for inverter (Outdoor unit)	
НЗ	High pressure switch failure (Outdoor unit)	
H4	Low pressure switch failure (Outdoor unit)	
H7	Outdoor fan motor position signal malfunction (Outdoor unit)	
H8	CT abnormality (Outdoor unit)	
H9	Outdoor air thermistor system malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
J1	Pressure sensor system malfunction (batch) (Outdoor unit)	
J2	Current sensor system malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
JЗ	Discharge piping thermistor system malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
J5	Suction piping thermistor system malfunction (Outdoor unit)	
J6	Outdoor heat exchanger distributor liquid piping thermistor malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
J7	Outdoor heat exchanger condenser / evaporator thermistor malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
J8	Liquid piping thermistor system malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
J9	Gas piping thermistor malfunction (cooling) (Outdoor unit)	
JA	Discharge piping pressure sensor system malfunction (Outdoor unit)	
JC	Suction piping pressure sensor system malfunction (Outdoor unit)	
L1	Inverter system malfunction (Outdoor unit)	
L3	Reactor thermistor malfunction (Outdoor unit)	
L4	Overheated heat-radiating fin (Outdoor unit)	Inverter cooling failure.
L5	Instantaneous overcurrent (Outdoor unit)	The compressor engines and turbines may be experiencing a ground fault or short circuit.
L8	Electric thermal (Outdoor unit)	The compressor engines and turbines may be over- loaded and disconnected.

		· 1
L9	Stall prevention (Outdoor unit)	The compressor may be locked.
LC	Transmission malfunction between inverter and outdoor control unit (Outdoor unit)	
P1	Open-phase (Outdoor unit)	
P3	DCL sensor system malfunction (Outdoor unit)	
P4	Heat-radiating fin thermistor malfunction (Outdoor unit)	Abnormal stop is applied depending on the model or condition.
P6	DC output current sensor system malfunction (Outdoor unit)	
PJ	Capacity setting failure (Outdoor unit)	Capacity setting adapter or capacity data error, or disconnection of the capacity setting adapter, failure to connect the adapter, or the capacity is not set to the data-retention IC.
UO	Suction piping temperature abnormal (Outdoor unit)	The refrigerant may be insufficient. Abnormal stop is applied depending on the model or condition.
U1	Reverse phase (Outdoor unit)	Reverse two phase of L1, L2 and L3 leads.
U2	Power voltage malfunction (Outdoor unit)	The inverter open-phase or main circuit condenser may be malfunctioning. Abnormal stop is applied depending on the model or condition.
U4 UF	Transmission error (between indoor and outdoor units)	Wiring error between indoor and outdoor unit. Or Indoor and outdoor Printed Circuit Board failure.
U5	Transmission error (between indoor and outdoor units)	Transmission between indoor unit and remote controller is not performed properly.
U7	Transmission error of the inverter module	
U8	Transmission error between main and sub remote controllers (sub remote controller malfunction)	
UA	Field setting error	System setting error of the simultaneous on/off multi- split type.
UE	Transmission error (between indoor unit and centralized remote controller)	
UC	Remote controller address setting error	
UJ	Accessory equipment transmission error	Abnormal stop is applied depending on the model or condition.

# 

After test operation is completed, check the items mentioned in the clause **2. Items to be checked at delivery** on page 4.

If the interior finish work is not completed when the test operation is finished, for protection of the air conditioner, ask the customer not operate the air conditioner until the interior finish work is completed.


If the air conditioner is operated, the inside of the indoor units may be polluted by substances generated from the coating and adhesives used for the interior finish work and cause water splash and leakage.

## -<u></u> To the operator carrying out test operation –

After test operation is completed, before delivering the air conditioner to the customer, confirm that the control box lid is closed.

In addition, explain the power supply status (power supply ON/  $\ensuremath{\mathsf{OFF}}\xspace$ ) to the customer.

# 12. Unpacking & Packing of the Indoor 12-1 Unit Unpacking




 Cut all the straps (a) from the unit using strap cutter(b) as shown in figure.

- a) Strap
- b) Starp Cutter
- c) Top corrugated cardboard sheet with EPS


2

•

d) Bottom corrugated cardboard sheet with EPS




Remove top corrugated cardboard sheet(c) & EPS from the unit by pulling it up as shown in figure.




 Remove the bottom corrugated cardboard sheet(d) & EPS from the unit by pulling the unit up as shown in figure, then remove the polythene product cover.

## 12-2 Packing




 Cover the unit with polythene product cover, then pick the unit up and settle it down on the bottom corrugated cardboard sheet with EPS(d) and cover the unit with polythene product cover as shown in figure

- a) Strap
- b) Starp Cutter
- c) Top corrugated cardboard sheet with EPS
- d) Bottom corrugated cardboard sheet with EPS
- e) Strap fixer



Put the cardboard box and EPS (c) upon the unit as shown in figure.



• Fix the straps (a) on the unit as shown in figure.(Use marked reference for placing straps)

Reference for placing strap (4 places)

•

<b>DAIKIN</b> Split System Air Con	ditione	r
INSTALLATION MANUAL <for ou<="" td=""><td></td><td></td></for>		
READ THESE INSTRUCTIONS CAREFULLY BEF		
NEW REFRIGERANT (R32) SE	ERIES	
RZA100AV16,RZA125AV16,RZ		
Note : III Read the precautions in this manual carefully before operating the unit.		
CONTENTS		
* SAFETY PRECAUTIONS		21
1. BEFORE INSTALLATION		
2. SELECTING INSTALLATION SITE		
4. PRECAUTIONS ON INSTALLATION		
5. REFRIGERANT PIPING WORK		
6. AIRTIGHTNESS TEST AND AIR-PURGE		
8. ELECTRICAL WIRING WORK 9. CHECK ITEMS BEFORE TEST OPERATION AND FIELD SETTINGS		
10. TEST OPERATION		
12. HOW TO RE-USE THE EXISTING PIPING		
1.3 REERIGERANT RECOVERY		
Do not use oxygen for air tight test. Do not use refrigerant other than the specified one or flammable material (e.g. pro They may cause over pressure in the refrigerating cycle and result in explosion, fire	opane ) in the refrigerate or injury.	ant cycle.
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li> <li>WARNING THERE IS A RISK OF EXPLOSION OR FIRE</li> <li>Do not mix air in the refrigerating cycle during pump down operation.</li> <li>Do not use oxygen for air tight test.</li> <li>Do not use refrigerant other than the specified one or flammable material (e.g. proposed)</li> </ul>	opane ) in the refrigerate or injury.	ant cycle.
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li> <li>WARNING THERE IS A RISK OF EXPLOSION OR FIRE</li> <li>Do not mix air in the refrigerating cycle during pump down operation.</li> <li>Do not use oxygen for air tight test.</li> <li>Do not use refrigerant other than the specified one or flammable material ( e.g. pro They may cause over pressure in the refrigerating cycle and result in explosion, fire Our company assumes no responsibility for failure or malfunction caused by filling of</li> </ul>	opane ) in the refrigerate or injury. or mixing of anything	ant cycle.
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li> <li>WARNING THERE IS A RISK OF EXPLOSION OR FIRE</li> <li>Do not mix air in the refrigerating cycle during pump down operation.</li> <li>Do not use oxygen for air tight test.</li> <li>Do not use refrigerant other than the specified one or flammable material ( e.g. proprintely may cause over pressure in the refrigerating cycle and result in explosion, fire Our company assumes no responsibility for failure or malfunction caused by filling of the specified refrigerant.</li> <li>ABOUT ISOLATING RESISTANCE OF COMF</li> <li>If refrigerant accumulates in the compressor after completing installation, the insulation at least 1 MΩ, then the unit will not break down.</li> <li>Connect the power supply to the unit and after 6 hours check if the insulation resis (Energize and heat the compressor to vaporize the refrigerant accumulated in the other formers.</li> </ul>	ppane ) in the refrigerate e or injury. or mixing of anything PRESSOR on resistance can drop stance of the compress compressor.) red with a device to compress	ant cycle. other than op, but if it ssor rises. ope with high
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li> <li>WARNING THERE IS A RISK OF EXPLOSION OR FIRE</li> <li>Do not mix air in the refrigerating cycle during pump down operation.</li> <li>Do not use oxygen for air tight test.</li> <li>Do not use refrigerant other than the specified one or flammable material (e.g. program y cause over pressure in the refrigerating cycle and result in explosion, fire our company assumes no responsibility for failure or malfunction caused by filling the specified refrigerant.</li> <li>CAUTION ABOUT ISOLATING RESISTANCE OF COMF</li> <li>If refrigerant accumulates in the compressor after completing installation, the insulation at least 1 MΩ, then the unit will not break down.</li> <li>Connect the power supply to the unit and after 6 hours check if the insulation resist (Energize and heat the compressor to vaporize the refrigerant accumulated in the off the earth leakage breaker is equipped harmonics. To prevent wrong actuation of the earth leakage breaker due to the inv an earth leakage breaker equipped with a device to cope with high harmonics.</li> <li>Please make sure to confirm that R32 (new refrigerant) is used in installation work (It may not operate normally, if refrigerant type is different.)</li> </ul>	ppane ) in the refrigerate or injury. or mixing of anything <b>PRESSOR</b> on resistance can drow stance of the compress compressor.) red with a device to con- verter, make sure to a compressor.)	ant cycle. other than op, but if it ssor rises. ope with high adopt
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li></ul>	ppane ) in the refrigerate e or injury. or mixing of anything <b>PRESSOR</b> on resistance can drop stance of the compress compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- sort.	ant cycle. other than op, but if it ssor rises. ope with high adopt tightly sealed. vell as moisture otection against o the atmosphe
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li></ul>	ppane ) in the refrigerate e or injury. or mixing of anything <b>PRESSOR</b> on resistance can drop stance of the compress compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- sort.	ant cycle. other than op, but if it ssor rises. ope with high adopt tightly sealed. vell as moisture otection against o the atmosphe
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li></ul>	ppane ) in the refrigerate e or injury. or mixing of anything PRESSOR on resistance can drop stance of the compress compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to con- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a compressor.) red with a device to com- verter, make sure to a com- sort of the com- sort	ant cycle. other than op, but if it ssor rises. ope with high adopt tightly sealed. vell as moisture otection against o the atmosphe res.
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li> <li>WARNING) THERE IS A RISK OF EXPLOSION OR FIRE</li> <li>Do not mix air in the refrigerating cycle during pump down operation.</li> <li>Do not use oxygen for air tight test.</li> <li>Do not use refrigerant other than the specified one or flammable material (e.g. proprinted programmed and the specified one or mathematical (e.g. proprinted programmed and the specified one or mathematical (e.g. proprinted programmed and the specified refrigerant of the refrigerating cycle and result in explosion, fire Our company assumes no responsibility for failure or malfunction caused by filling of the specified refrigerant.</li> <li>CAUTION) ABOUT ISOLATING RESISTANCE OF COMF</li> <li>f refrigerant accumulates in the compressor after completing installation, the insulation at least 1 MΩ, then the unit will not break down.</li> <li>Connect the power supply to the unit and after 6 hours check if the insulation resist (Energize and heat the compressor to vaporize the refrigerant accumulated in the compressor to vaporize the refrigerant accumulated in the out wrong actuation of the earth leakage breaker is equipped harmonics. To prevent wrong actuation of the earth leakage breaker is equipped harmonics. To prevent wrong actuation of the earth leakage breaker due to the inv an earth leakage breaker equipped with a device to cope with high harmonics.</li> <li>1. Please make sure to confirm that R32 (new refrigerant) is used in installation work (It may not operate normally, if refrigerant type is different.)</li> <li>2. The refrigerant R32 requires that strict precautions be observed for keeping the sy clean and dry Strict measures must be taken to keep impurities (Including SUNISO oil and ot out of the system.</li> <li>Tightly sealed</li> <li>R32 contains no chlorine, does not destroy the ozone layer and so does not re harmful ultraviolet radiation. R32 will contribute only slightly to the greenhouse Therefore, sealing tightness is particularly important in instal</li></ul>	PRESSOR on resistance can dro stance of the compress compressor.) ed with a device to co verter, make sure to a c in advance. ystem clean, dry and t ther mineral oils as w educe the earth's pro- e effect if released into the correct procedur ble.	ant cycle. other than op, but if it ssor rises. ope with high adopt tightly sealed. vell as moisture otection against o the atmosphe res.
<ul> <li>14. UNPACKING &amp; PACKING INSTRUCTION OF OUTDOOR UNIT</li></ul>	PRESSOR on resistance can dro stance of the compress compressor.) red with a device to co verter, make sure to a compressor.)	ant cycle. other than op, but if it ssor rises. ope with high adopt tightly sealed. vell as moisture otection against o the atmosphe res.

	REA	D THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION
		ifies the precautions into WARNINGS and CAUTIONS. Il the precautions below. They are all important for ensuring safety.
	WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
		Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
Give In p Ask	e the user adeo articular, make the user to ke	In is completed, test the air conditioner and check if the air conditioner operates properly. In the provided instructions concerning the use and cleaning of the indoor unit according to the operation manual. It is sure to explain with regard to "SAFETY PRECAUTIONS" and "Not malfunction of the air conditioner". It is manual and the operation manual together in a handy place for future reference. It is under the term "appliances not accessible to the general public".
		M WARNING
Imp Per Imp Con Whi doe Be Fail Inst In	roper installation form installation roper installation roper installation roper installation roper installation roper installation sult your local en the indoor up s not exceed the sure to use on ure to use the all the air conduction of the speet roper installation roper installation the speet roper is not add wiring. En wiring betwe the such as a con- triger and gap line the switch the speet of a speet of a so the speet of a so the speet of a so the speet of a so the roper is not and dwiring. En installing of the pressure of a speet of a so the room plet of a so the speet of a so the spect of a so the spect of a so the speet of a so the spect of a so the s	Ider or qualified personnel to carry out installation work. on may result in water leakage, electric shocks or a fire. n work in accordance with this installation structure is the proper measures so that the amount of any leaked refrigerant dealer regarding what to do in case of refrigerant leakage. In its installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant ne concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen deficiency. y the specified parts and accessories for installation work. specified parts may result in the air conditioner fall down, water leakage, electric shocks, a fire, etc. titioner on a foundation that can withstand its mass. In may result in the air conditioner fall down and causing injury. The distallation work in consideration of strong winds, typhoons, or earthquakes. on may result in an accident such as the air conditioner fall down. all electric work is carried out by qualified personnel according to the applicable legislation stallation manual, using a separate circuit. In addition, even if the wiring is short, make sure to use a wiring length and never connect additional wiring to make the length sufficient. Insufficient capacity of the power proper electric construction may lead to electric shocks or a fire. e legislation means "All international, national and local directives, laws, regulations and/or codes which are cable for a certain product or domain." itoner. e earth wiring to gas or water piping, lightning conductor or telephone earth wiring. gran cause electric shocks or a fire. st be stored in a room without continuosly operating ignition sources in flames, an operating gas appliance or an operating lectric heater). ur. gerant may not contain an odor. nal gas regulations. of the unit before touching any electrical parts. tr may result in heat generation. Electric shocks or fire. ein the ouldoor and indoor units, and wiring the power supply, from the wiring orderly so th
and • The	the pressure i appliance sha	nside the refrigerant circle become abnormally high, which may cause injury and property damage. Il be installed operated and stored in a room with floor area larger than 3.68 m <sup>2</sup> . are reused, the flare part shall be re-fabricated.


Install drain piping according to this installation manual to ensure good drainage, and insulate the piping to prevent condensation. Improper drain piping may cause water leakage, make the furniture get wet. Install the indoor and outdoor units, power cord and connecting wires at least 1 meter away from televisions or radio to prevent picture interference and noise (Depending on the incoming signal strength, a distance of 1 meter may not be sufficient to eliminate noise.) Install the indoor unit as far as possible from fluorescent lamps. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean. Disposal requirements Dismanting of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation. Only qualified personnel can handle, fill, purge and dispose of the refrigerant. Do not install the air conditioner in places such as following: Where there is mist of oil, oil spray or vapor for example a kitchen. Resin parts may deteriorate, and cause them to fall out or water to leak. 1. Important information regarding the refrigerant used This product contains fluorinated greenhouse gases 2. Where corrosive gas, such as sulfurous acid gas, is produced. covered by the Kyoto Protocol. Do not vent gases Corrosion of copper pipings or brazed parts may cause the refrigerant to leak. 3. Where there is machinery which emits electromagnetic waves. into the atmosphere Refrigerant type: R32 Electromagnetic waves may disturb the control system, and cause malfunction of the equipment. GWP<sup>(1)</sup> value: 675 <sup>(1)</sup>GWP = global warming potential The refrigerant quantity is indicated on the unit Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables, such as thinner or gasoline, are handled. If the gas should leak and remain around the air conditioner, it may cause ignition. name plate. The place that the vibration or the voltage fluctuation give influence. Vehicles, vessels, etc. The vibration may cause a damage and the voltage fluctuation may cause an abnormal operation. 6. Where small animals may build a nest, fallen leaves are accumulated, or weeds are overgrown If small animals touch the electrical parts inside, this may cause malfunction, smoke or a fire. <DO NOT THROW AWAY ACCESSORIES **BEFORE INSTALLATION** THAT ARE REQUIRED FOR INSTALLATION.> Carefully read these instructions before installation. · For installation of the indoor unit, refer to the indoor unit installation manual. When lifting up the unit, do not put < Transporting Unit > fingers into the inlet hole on the side of As shown in the Fig.2, bring the unit slowly.(Take care the casing, otherwise the casing may be not to let hands or things come in contact with rear fins.) deformed. Inlet hole Outlet side grille Outdoor unit (FRONT) (BACK) Handle Fig. 2 Fig. 1 < Installation Parts > < CAUTION > Always use accessory parts or those of designated · Work in a team of at least two people when carrying the outdoor unit specification as parts required for installation. SELECTING INSTALLATION LOCATION (1/2) (1) Select the installation location that meets the following conditions and get approval of the customer. Places where is no risk of flammable gas leakage. Places where the outdoor unit does not bother next-door neighbors. Safe places where can withstand the unit's mass and vibration and where the air conditioner can be installed level. Places where are well-ventilated and where servicing space can be well ensured. The minimum required space is shown in chapter 3 INSTALLATION SERVICE SPACE Earth leakage Only Duct type Where the piping length between the indoor and the outdoor units is ensured within the Connection breaker allowable piping length. (Please see chapter 5 REFRIGERANT PIPING WORK) Do not allow wind from the same direction to blow frequently toward the outlet or inlet of the outdoor unit. If the wind is likely to blow as mentioned above, make sure to keep Indoor Unit a sufficient service space and install a wind protective shield. Inverter air conditioners may cause noise to occur in electrical Indoor appliances. As shown in the right drawing, select an installation 1.5m or more remote Outdoo site well away from radios, PCs, and stereos. 1m or more controller Unit CAUTION Especially in the areas where the incoming signal strength is 1m or more weak, keep the indoor remote controller 3 meter or more from C electrical appliances. Put the power supply and transmission wiring in a metal piping and ground the metal piping. 1.5m or more 1.5m or more

A


CAUTION

#### SELECTING INSTALLATION LOCATION (2/2) (2) When installing the outdoor unit's in a place exposed to strong wind, pay special attention to the following. 5 m/sec or more strong wind blown against the outdoor unit's outlet side causes the oudoor unit to deteriorate in air volume and suck in the air blown out of its outlet side (short circuit), and the following effects may result. - Performance is degraded. - Operation stop due to increase in pressure. If a very high fan strength is used continuously from the front of the oudoor unit outlet side, the fan might turn in reverse at high speed, and become damaged. (3) Following the installation place, it is expected that the influence of the strong wind is great. The flat area which receives the adverse wind such as typhoon directly since there is no obstacles such as buildings and mountains. (Including coast line, shoreline of lake and mountain region.) The installation place that no obstacles around the outdoor unit to prevent the adverse wind. for example, walls and buildings that are higher than the applicable outdoor unit, etc. Please take measures when installing especially on a rooftop. Since the outdoor unit may fall down, attach the fixture for preventing overturning(option). Set the outlet side Turn the outlet side toward the building's at right angle to the direction of the STRONG STRONG wall. fence or wind WIND vindbreak screen WIND Ensure there is enough space for installing the Air outlet outdoor uni INSTALLATION SERVICE SPACE (1/3) 3 • The installation servicing spaces shown in these drawings are based on the outdoor unit inlet area temperature of $35^\circ$ C for COOLING operation. If the planned inlet area temperature exceeds $35^{\circ}$ C(DB), or if the heat load of all outdoor units is increased significantly and exceeds the maximum operating capacity, secure a larger space than that indicated by the inlet dimensions in these drawings. For installation, consider both pedestrian and air flow paths and choose a suitable pattern from these drawings to match the space available field. (If the number of units to be installed exceeds the patterns in these drawings, consider there are no short-circuits.) Regarding the front space, position the units with consideration to the space required for the refrigerant piping work. (Consult your dealer if the work conditions do not match those in the drawings.) Secure appropriate space when using a side piping outlet. **3-1 INSTALLATION OF SINGLE UNIT** (Units: mm) When nothing is obstructing the top (2) In case obstacles exist in front of the inlet (3) In case obstacles exist only (1) In case obstacles exist only in front side and on both sides of the outdoor unit. in front of the outlet side. of the inlet side. 100 or more 100 or more 100 or more 100 or more When something is obstructing the top In case obstacles exist only (2) In case obstacles exist in front of the inlet (3) (1) In case obstacles exist in front in front of the outlet side. side and on both sides of the outdoor unit. of the inlet side 1000 or more 1000 or more 150 or more 100 or more 150 or more 150 or mo

# 3 INSTALLATION SERVICING SPACES (2/3)



# 3 INSTALLATION SERVICING SPACES (3/3)



# PRECAUTIONS ON INSTALLATION

#### <Drain work>

- Potentially problematic locations for the outdoor unit drainage. In locations where, for example, drain may fall on passersby may cause passersby to slip over, install in enclosure (field supply) to prevent people approaching the outdoor unit.
- Then, coat the area around the bored holes with rust preventive coating to cover the metal exposure.
- Make sure the drain works properly.
- <Installation method of the outdoor unit> · Check the strength and level of the installation ground so that the outdoor unit will not cause any operating vibration or noise after installed.
- · In accordance with the foundation drawing in Fig. 3, fix the unit securely by means of the foundation bolts. (Prepare four sets of M12 foundation bolts, nuts and washers each which are available on the market.)
- · It is best to screw in the foundation bolts until their length are 20 mm from the foundation surface
- · Fix the outdoor unit to the foundation bolts using nuts with resin washers. (See the right-hand drawing )
- If the coating on the fastening area is stripped off, the nuts rust easily. <Installation method of fixure for preventing overturning>
- If steps need to be taken to prevent the unit from tipping over. Use the fixure for preventing overturning (option).

## REFRIGERANT PIPING WORK (1/5)



**Outlet Side** 

Û

620

160

201

25

154

₩

179

Diagram of lower surface

Resin

Fixure for preventing verturning (option) (wiring system)

washers

161

66

ശ

20

36

Fig. 3

Drawing of the foundation

σ

295

(Units: mm)

345~355

350

Bottom frame

Drain hole

Knock hole

160

#### To plumbing persons

- Important information regarding the refrigerant used. This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.
- GWP (global warming potential) of R32 refrigerant type = 675 Use R32 as additional for charging.
- Do not use flux when brazing refrigerant piping. Use phosphor copper brazing filler metal (BCuP-2:JIS Z 3264/B-Cu93P-710/795:ISO 3677) that does not require flux. (If chlorinated flux is used, the piping will be corroded and, in addition if fluorine is contained, the refrigerant oil will be deteriorated and the
- refrigerant circuit will be affected badly.) After chapter **O** CHARGING REFRIGERANT) is completed, be sure to open the stop valves before performing **O** FIELD SETTINGS ). (Operating the unit with the valve shut will break the compressor.)

#### 《Precaution when reuse existed refrigerant pipe 》

- Please keep below points in order to reuse existed pipe, failure may caused if have a fault.
- Below are pipes shall always make new construction, do not reuse piping.
  - When removed from indoor unit or outdoor unit for a long time.
  - (Moisture entry to internal pipe, wastes entry can be occured.)
  - When copper tube is corroded.
  - When pipe thickness is insufficient (refer to (5-4 REFRIGERANT PIPE SIZE AND ALLOWABLE PIPE LENGTH)
  - Do not reuse flare for refrigerant leak protection, please make flare processing.
  - Do not reuse flare nut, please use flare nut in product accessories.
  - Make sure to do refrigerant leak check in case there is brazing area while perform field piping.
  - If insulation is deteriorate, make sure to exchange to new one.

#### Be sure to use the dedicated tools to ensure sufficient pressure resistance and prevent the entry of any impurities 5-1 INSTALLATION TOOLS

To ensure sufficient pressure resistance and prevent the entry of any impurities (mineral oils such as Suniso oil and liquids), Manifold gauge Charging hose use the R410A or R32 dedicated item (the screw specifications for R410A or R32 differ). Be extremely careful not to flow the pump oil backward to inside the piping when the pump is stopped. Vacuum pump Use a pump which enables vacuuming to -0.1 MPa(-755mmHg) of the gauge pressure.

## **5-2 SELECTION OF PIPING MATERIAL**

- Use the piping whose inside and outside are clean and with no harmful substances for use such as sulphur, oxide, dust, dust from cutting, grease, or liquid (contamination) is attached.
- For the refrigerant piping, use the following material.
- Material: Deoxidised phosphorous seamless copper piping
- Temper grade: Use piping with temper grade in function of piping diameter as listed in the table on section
  - 5-4 REFRIGERANT PIPING SIZE AND ALLOWABLE PIPING LENGTH

## Size: Decide based on section (5-4 REFRIGERANT PIPING SIZE AND ALLOWABLE PIPING LENGTH )

- Thickness: Comply with applicable legislation. The minimal piping thickness for R32 piping must be in accordance with the table on section <u>(5-4 REFRIGERANT PIPING SIZE AND ALLOWABLE PIPING LENGTH)</u>
- · For the handling of the stop valves, see "precautions when the handling piping stop valves" on section
- 5-4 5EFRIGERANT PIPING WORK
- Be sure to perform piping work using measurements within the maximum allowable length and height difference described on section (5-4 REFRIGERANT PIPING SIZE AND ALLOWABLE PIPING LENGTH

## 5 REFRIGERANT PIPING WORK (2/5)

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>

(Units : mm)

## (5-3 PIPING PROTECTION )

- Prevent contamination or moisture from getting into the piping.
- Pay special attention when running the copper piping through the through-hole or when leading the edge of the piping outside the room.
- Refrigerant piping must be protected from physical damage. Install a plastic cover or equivalent.

Location	ocation WORK PERIOD PROTECTION METHOD		Location	WORK PERIOD	PROTECTION METHOD	
Outdoor	One month or more	Pinching	Indoor	NI/A	Pinching or taping	
	Less than one month	Pinching or taping	Indoor	N/A		

## (5-4 REFERIGERANT PIPING SIZA AND ALLOWABLE PIPING LENGTH

#### CAUTION

This unit is chargeless specification. Due to chargeless length and allowable piping length will be different depend on field pipe size.

#### Piping bend radius

Piping diameter	Pipe thickness (material)	Bend radius
Ø 9.5mm	0.8 mm (C1220T-O, Type O)	30mm or more
Ø 15.9mm	1.0 mm (C1220T-O, Type O)	50mm or more

#### Refrigerant pipe size and chargeless length

Outdoor unit type	Liquid pipe size (type)	Chargeless length
RZA100AV16 RZA125AV16 RZA140AV16	Ø 9.5mm x t 0.8 mm (type O)	30m

• One way maximum allowable piping length means the maximum length of liquid side piping or gas side piping.

• Equivalent length is the pressure loss due to L joints, traps, and so on along the refrigerant piping converted to a straight piping length of the same size and added to the overall value.

- Please see the Engineering Data for calculation of equivalent length.
- Please give the vertical interval between the indoor and outdoor as 20m or less.

Pair Connection Refrigerant piping size and one way maximum allowable piping length.

Outdoor unit t	ype Liquid pipe size (type)	Maximum allowable piping length (It is equivalent length in the inside)	Gas pipe size (type)	Maximum allowable piping length (It is equivalent length in the inside)
RZA100AV16 RZA125AV16 RZA140AV16	Ø 9.5mm x t 0.8mm (type O)	50m (70m)	Ø 15.9mm x t 1.0mm (type O)	50m (70m)


## \Lambda WARNING

• When flared joints are reused, the flared part shall be re-fabricated.

# 


- Use dedicated piping cutters and flaring tools for R410A or R32.
- When making a flare connection, apply ether or ester oil only to the flare inner surface.
- Use only the flare nuts attached to the unit. If other flare nuts are used, it may cause refrigerant leakage.
- To prevent contamination, dust or moisture from getting into the piping, take measures such as pinching or taping the pipings.

<Please refer to installation manual of indoor unit about indoor unit's refrigerant piping>



5 REF	RIGERAN	Γ PIPING WO	RK (4/5)	)					
How to op	erate the stop val	lve) (Refer to Fig. 10)							
<u> </u>	Use hexagonal wrenches 5mm.								
	To open:								
	ne hex-wrench onto	o the valve rod and turn	counter-clockwise.	e					
		o longer turns. It is now		•					
To close:		U	•			Fig. 10			
		he valve rod and turn cl		<l< td=""><td>iquid side&gt; <gas side=""></gas></td><td>-</td></l<>	iquid side> <gas side=""></gas>	-			
2. Stop wh	nen the valve rod no	o longer turns. It is now	closed.		(77777777	×			
(PRECAU	TIONS FOR HAN	IDLING VALVE CAP	)						
• A seal is a	attached to the poir	nt indicated by the arrow	. Take care not to da	mage it.	Valve cap				
<ul> <li>Be sure to</li> </ul>	o tighten the valve of	cap securely after opera	ting the valves.						
	alve size (mm) Tighten		Valve size (mm) Tighter	<b>-</b>	) Stop valve (cap attachn	nent) Fig. 11			
Liquid side	Ø9.5 2	2.0 ± 2 Gas side	Ø15.9 3	32.0 ± 3		i ig. i i			
(PRECAU	TIONS FOR HAN	IDLING SERVICE PO	DRT)						
• Use a pus	h-rod provided char	ging hose for operation.	Tightening to						
		ap securely after opera		3					
		which pressing stick is slipped out ge due to deformation fo the valve							
Pronibited		·							
(PRECAU	TIONS FOR CO	NECTING PIPING)							
		igerant piping between t	he outdoor and indoo	or may not tou	uch the compressor bo	olt and sound proof			
	the plate as shown								
		higher than the indoor ur		round insulat	ion and tubes because	e condensation on			
		ough to the indoor unit s	ade.						
<u>`</u>		DING INSULATION)			Interunit	piping for the			
		e refrigerant piping acco				nd outdoor units			
		is not done, condensati ase refer to the target v			Compressor				
		d humidity conditions a		or more:					
		is 15 mm or more.							
		d humidity conditions a	re 30℃ and RH 80%	or more:					
		is 20 mm or more.		Perform	treatment				
		d and gas sides interuni		such as	caulking				
		refrigerant leakage if it i aterial which can resista		Insulati	on				
			-	(field su					
- IV - •		hit piping must be carrie	d out up to the						
	connection inside the	used to the atmosphere,	it may cause sweat		on around the piping				
CAUTION	or burn due to touc	hing the piping, electric	shocks or a fire due	to and ther	n cover the				
	the wiring touching	the piping.			n with vinyl tape/	Insulation (field supply)			
PRECAL	<b>JTIONS WHEN T</b>	<b>IGHTENING FLARE</b>	NUTS		Fig. 12 Refrigerant pipin	g must be protected			
$\sim$		uts with two spanners.			from physical da	mage. Install a plastic			
Then afte	r the piping connect	ion, tighten them using a	spanner and torque v	vrench.	cover or equivale				
<ul> <li>For the di</li> <li>When ma</li> </ul>	mension of flared pa	art, see the table 1. ion. coat ether or ester of	il only to the flare inne	r surface					
Then, turi	n the nut 3 to 4 times	s with your hand and scre	ew in the nut.	a sundee.					
Ş	а <sub>т</sub>	Sp	anner						
<b>S</b>	-	orque wrench	T Union joint	Coat	the flare inner surface c	only			
Ŕ				with	Ester oil or ether oil				
	Flare nut		<b>Š</b>	Mr.					
-	Piping connecti	on Time	Flare nut		<u></u>				
<ul> <li>For the tig</li> </ul>	htening torque, see	the table 1.							
• After all the piping has been connected, use nitrogen to perform a refrigerant leakage test.									
Table 1	Ť.		1	Table 2	Ť				
PIPING SIZE (mm)	TIGHTENING TORQUE	A DIMENSIONS FOR PROCESSING FLARES (mm)	FLARE SHAPE		FURTHER TIGHTENING ANGLE	RECOMMENDED ARM			
Ø6.4	16 ± 2 N•m	8.9 ± 0.2		(mm) Ø6.4	60 to 90 degrees	About 150 mm			
Ø9.5	22 ± 2 №m	13.0 ± 0.2	α ( <sup>2</sup> γ) R0.6 ± 0.2 mm	Ø9.5	60 to 90 degrees	About 200 mm			
Ø12.7	32 ± 2 N•m	16.4 ± 0.2		Ø12.7	30 to 60 degrees	About 250 mm			
Ø15.9	50 ± 2 N•m	19.5 ± 0.2	Flare shape	Ø15.9 Ø19.1	30 to 60 degrees 20 to 35 degrees	About 300 mm About 450 mm			
Ø19.1	70 ± 2 N•m	23.8 ± 0.2		1.610	2010 33 degrees				


If there is no torque wrench, use table 2 as a rule of thumb. When tightening a flare nut with a spanner harder and harder, there is a point where the tightening torque suddenly increases. From that position, tighten the nut additionally the angle shown in table 2. After the work is finished, check securely that there is no gas leakage. If the nut is not tightened as instructed, it may cause slow refrigerant leakage and result in malfunction(such as does not cool /heat).




7 CHARGING THE REFRIGERANT (2/2)
<ul> <li>When recharging refrigerant, follow the procedure below.</li> <li>In case of recharge refrigerant (cause of refrigerant leak) please follow suggestion below (reference detail from service guide)</li> <li>In case of outdoor PCB (A1P) set refrigerant recovery mode at ON please press switch BS2 during 5 second.</li> <li>In case remote was set refrigerant recovery mode ON please follow caution label that sticked at backside of front plate.</li> <li>Shut down the power at least 1 minute after setting process (1) is performed.</li> <li>If the power is turned on before the process (3) - (6) are completed, the refrigerant recovery mode is turned of and the refrigerant cannot be recovered or charged normally. If the power is turned on by necessary, turn on refrigerant recovery mode again.</li> <li>Recover the refrigerant from both the refrigerant recovery port and liquid stop valve service port (or gas stop valve service port) simultaneously until the pressure drops below 0.09 MPa (gauge pressure: 0.011MPa) by using a refrigerant recovery machine.</li> <li>Modify the leakage points.</li> <li>Sherform the airtightness test and air-purge accordance with (6) AIRTIGHTNESS TEST AND AIR-PURGE.</li> <li>Charge the refrigerant from beservice port of the liquid side stop valve when recharging refrigerant. (Note) Do not turn on power during evacuation. The motor may be damaged due to vacuum discharge.</li> <li>Be sure to write down the additional amount of refrigerant charged or the entire amount re-charged on the precaution plate on the rear of the front panel, as this information is needed in case of after-sales service.</li> </ul>
• Before charging, check whether the cylinder has a siphon attached or not.
Charging a cylinder with an attached siphon       Charging other cylinders         Stand the cylinder upright at charging.       Stand the cylinder upside-down and charge.         (There is a siphon piping inside, so that cylinder need not be upside-down to charge with liquid.)       Stand the cylinder upside-down at charging.)         • To prevent entry of any impurities and ensure sufficient pressure resistance, always use the special tools dedicated for R410A or R32.         • The refrigerant should be charged from the service port of the liquid side stop valve.
CAUTION
(To plumbing persons)
• After completing installation, be sure to open the valves. (Operating the unit with the valve shut will break the compresssor).
• After complete charging of refrigerant carry out refrigerant leak check and heat insulation work. (Failure to carry out heat
insulation work may result in leakage of water)
• Do not allow refrigerant to escape into the atmosphere recklessly for earth environment protection.
<b>2</b> FLECTRICAL WIRING WORK $(1/3)$
8 ELECTRICAL WIRING WORK $(1/3)$
8 ELECTRICAL WIRING WORK (1/3)
WARNING
Make sure to install the earth leakage breaker.
WARNING
Make sure to install the earth leakage breaker. (The earth leakage breaker is required in order to prevent electric shocks or a fire.)
Make sure to install the earth leakage breaker. (The earth leakage breaker is required in order to prevent electric shocks or a fire.) • Electrical wiring must be carried out by qualified personnel.
Make sure to install the earth leakage breaker. (The earth leakage breaker is required in order to prevent electric shocks or a fire.) • Electrical wiring must be carried out by qualified personnel. • Before obtaining access to terminal devices, all supply circuits must be interrupted.
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>(The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>Electrical wiring must be carried out by qualified personnel.</li> <li>Before obtaining access to terminal devices, all supply circuits must be interrupted.</li> <li>CAUTION</li> <li>To the electrician</li> <li>Make sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>Do not remove the thermistors or sensors when the power supply and transmission wiring are connected. (Operating the unit with the thermistors and sensors removed will break the compressor.)</li> <li>Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.</li> <li>An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.</li> <li>The wiring between the indoor unit and outdoor unit must be for 230V.</li> </ul>
Make sure to install the earth leakage breaker.         (The earth leakage breaker is required in order to prevent electric shocks or a fire.)         • Electrical wiring must be carried out by qualified personnel.         • Before obtaining access to terminal devices, all supply circuits must be interrupted.         Image: CAUTION         • To the electrician         • Make sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.).         • Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)         • Do not run the unit with the thermistors or sensors when the power supply and transmission wiring are connected. (Operating the unit with the termistors and sensors removed will break the compressor.)         • Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.         • An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.         • The wiring between the indoor unit must be for 230V.         • For electric wiring work, refer to also the "WIRING DIAGRAM".
Make sure to install the earth leakage breaker.         The earth leakage breaker is required in order to prevent electric shocks or a fire.)         • Electrical wiring must be carried out by qualified personnel.         • Before obtaining access to terminal devices, all supply circuits must be interrupted.         Image: CAUTION         • Device the install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)         • Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)         • Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)         • Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical current on the nuit and using the interview of the term the torder unit and outdoor unit must be for 230V.         • An insufficient power supply circuit to work may lead to electric shocks or a fire.         • The wiring between the indoor unit and outdoor unit must be for 230V.         • For electric wiring work, refer to also the "WIRING DIAGRAM".         • When doing the electric wiring work is complete. should be according to applicable legislation.         • When doing the electric wiring work is complete. should be according to applicable legislati
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>Electrical wiring must be carried out by qualified personnel.</li> <li>Before obtaining access to terminal devices, all supply circuits must be interrupted.</li> <li>CAUTION</li> <li>To the electricain</li> <li>A hake sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity or improper electrical construction may lead to electric shocks or a fire.</li> <li>An insufficient power supply capacity or improper electrical construction may lead to electric shocks or a fire.</li> <li>An insufficient oper supply capacity or work may lead to electric shocks or a fire.</li> <li>The wiring between the indoor unit and outdoor unit must be for 230V.</li> <li>For electrical viring work, refer to also the "WIRNG DIAGRAM".</li> <li>When doing the electrical wiring, always shut off the power souple to applicable legislation.</li> <li>Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.</li> <li>Do not connect the earth wiring to gas or water piping, lighting conductor or telephone earth wiring.</li> </ul>
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>Electrical wiring must be carried out by qualified personnel.</li> <li>Before obtaining access to terminal devices, all supply circuits must be interrupted.</li> <li>CAUTION</li> <li>To the electrician</li> <li>Make sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor).</li> <li>Make sure to install a current balance type earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor).</li> <li>Make cartain that al electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electric al construction may lead to electric work may lead to electric shocks or a fire.</li> <li>An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.</li> <li>An insufficient ower, refer to also the "WIRING DIAGRAM"."</li> <li>When doing the electric wiring ways shut off the power source before working, and do not turn on the branch switch until all work is complete.</li> <li>Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.</li> <li>Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring.</li> <li>Gas pipingHard wiri (tubes are not effective earths.</li> </ul>
(b) WARNING Make sure to install the earth leakage breaker. The earth leakage breaker is required in order to prevent electric shocks or a fire.) Electrical wiring must be carried out by qualified personnel. Before obtaining access to terminal devices, all supply circuits must be interrupted.      (b) CAUTION     (b) CAUTION     (b) CAUTION     (b) CAUTION     (b) CAUTION     (c) CAUTION
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>Electrical wiring must be carried out by qualified personnel.</li> <li>Before obtaining access to terminal devices, all supply circuits must be interrupted.</li> <li>CAUTION</li> <li>To the electrician</li> <li>Make sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor).</li> <li>Make sure to install a current balance type earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor).</li> <li>Make cartain that al electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electric al construction may lead to electric work may lead to electric shocks or a fire.</li> <li>An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.</li> <li>An insufficient ower, refer to also the "WIRING DIAGRAM"."</li> <li>When doing the electric wiring ways shut off the power source before working, and do not turn on the branch switch until all work is complete.</li> <li>Make sure to earth the air conditioner. Earthing resistance should be according to applicable legislation.</li> <li>Do not connect the earth wiring to gas or water piping, lightning conductor or telephone earth wiring.</li> <li>Gas pipingHard wiri (tubes are not effective earths.</li> </ul>
A instificient over supply capacitor of a fire.     An instificient cover supply cover the gas a supply during the sector cover before working, and do not turn on the branch switch until all work is complete.     Some supply cover before working and the sector of the gas cover before working and not turn the air conditions.     The wing between the indicor unit and outdoor unit must be for 230V.     Some supply capacitor of the sector of the supply cover before working and not turn on the branch switch until all work is complete.     Some supply capacitor of the sector of the supply cover before working is a done to the supply capacitor before working is a done to the sector wing work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circul. Insufficient cover supply circuit fire work may lead to electric shocks or a fire.     An insufficient cover supply capacitor of the power supply circuit or improver electric shocks or a fire.     An insufficient cover supply capacitor fire.     So not connect the earth wing to gas or water pipinggliphting conductor or telephone earth wiring.     Capacitor wing work is carried out by qualified personnel according to applicable legislation.     Capacitor wing work is a carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circul. Insufficient cover supply carcuit on improve the electrical according to the separate circul.     So not conneet the individent capacitor or the sease leave the acting the ai
Make sure to install the earth leakage breaker.         The earth leakage breaker is required in order to prevent electric shocks or a fire.)         •Electrical wiring must be carried out by qualified personnel.         •Before obtaining access to terminal devices, all supply circuits must be interrupted.         Image: CAUTION         Image: CAUTION         •Make sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)         •Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)         •Do not run the unit until the terringerant charging is complete. (Operating the unit before the completion will break the compressor.)         •Do not run the unit until the terringer and sensors removed will break the compressor.)         •Make certain that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or a fire.         •An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.         •An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.         •An insufficient power supply capacity or improper electric work may lead to electric shocks or a fire.         •An insufficient power
Image: Control of the end of the provided of the proversided of the provided of the provided of
WARNING         Make sure to install the earth leakage breaker.         (The earth leakage breaker is required in order to prevent electric shocks or a fire.)         Electrical wiring must be carried out by qualified personnel.         Before obtaining access to terminal devices, all supply circuits must be interrupted.         Image: Control of the electrician         Image: Cont entower the themistors or sensors when the pow
Warning         Make sure to install the earth leakage breaker.         (The earth leakage breaker is required in order to prevent electric shocks or a fire.)         (Electrical wiring must be carried out by qualified personnel.         (Before obtaining access to terminal devices, all supply circuits must be interrupted.         (Make sure to install a current balance type earth leakage breaker coping with high harmonics.         (This our un the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)         (Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)         (Do not run the unit with the thermistors and sensors removed will break the compressor.)         (Do not run the unit with the thermistors or sensors when the power supply and transmission wiring are connected.         (Operating the unit with the thermistors or sensors when the power supply and transmission wiring are connected.         (Denot run the unit with the thermistors and sensors removed will break the compressor.)         (Bake sure to eatin that all electric wiring work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of the power supply accurator thereoner ender there inder wiring works is carried out by qualified personnel according to applicable legislation.         (Deretice wiring work, refer to also the "WIRIND DIAGRAM".         (When doing the electrick wiring works sourd do out unit musthe
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>(The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>(Electrical wiring must be carried out by qualified personnel.</li> <li>(Before obtaining access to terminal devices, all supply circuits must be interrupted.</li> <li>(Make sure to install a current balance type earth leakage breaker coping with high harmonics.</li> <li>(The electrician)</li> <li>(Make sure to install a current balance type earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>(Do not un the unit until the refigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>(Do not un the unit until the refigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>(Do not run the unit with the thermistors and sensors removed will break the compressor.)</li> <li>(Dorating the unit with the thermistors or sensors when the power supply and transmission wiring are connected.</li> <li>(Operating the unit with the thermistors or ansors removed will break the compressor.)</li> <li>(Do not run the unit with the thermistors or sensors removed will break the compressor.)</li> <li>(Do and train that all electric wiring works is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient copacity of improper electric work may lead to electric shocks or a fire.</li> <li>(The wiring between the indoor unit and outdoor unit must be for 320V.</li> <li>(For electric wiring work, refer to also the "WIRING DIAGRAM".</li> <li>(When doing the electric burds, wiring the senset and to releption earth wiring.</li> <li>(Lighting conductor or telephone earth wiring</li></ul>
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>(The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>Electrical wining must be carried out by qualified personnel.</li> <li>Electrical wining must be carried out by qualified personnel.</li> <li>Electrical wining must be carried out by qualified personnel.</li> <li>Electrical wining must be carried out by qualified personnel.</li> <li>Cautrion</li> <li>Cautrion</li> <li>Nake sure to install a current balance type earth leakage breaker coping with high harmonics. (This unit is equipped with an inverter device. Use an earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>Do not run the unit until the refrigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>Make carain that al electric winng work is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient capacity of improper electric work may lead to electric shocks or a fire.</li> <li>The winnig between the indoor unit and outdoor unit must be for 2000.</li> <li>Make carein that all electric shocks or a fire.</li> <li>The winnig between the indoor unit and window. Electric potential may rise abcording to applicable legislation and this installation manual, using a separate circuit, insufficient capacity of improper electric work may lead to electric shocks or a fire.</li> <li>Make care as earther along alwayer that for the sites and according to applicable legislation.</li> <li>Make care as earther window, there that all electric potential may rise abcording to applicable legislation and this installation manual, using a separate circuit mission or explosion may lead to the potential may rise abcording the applicable legislat</li></ul>
<ul> <li>WARNING</li> <li>Make sure to install the earth leakage breaker.</li> <li>(The earth leakage breaker is required in order to prevent electric shocks or a fire.)</li> <li>(Electrical wiring must be carried out by qualified personnel.</li> <li>(Before obtaining access to terminal devices, all supply circuits must be interrupted.</li> <li>(Make sure to install a current balance type earth leakage breaker coping with high harmonics.</li> <li>(The electrician)</li> <li>(Make sure to install a current balance type earth leakage breaker coping with high harmonics to prevent wrong actuation.)</li> <li>(Do not un the unit until the refigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>(Do not un the unit until the refigerant charging is complete. (Operating the unit before the completion will break the compressor.)</li> <li>(Do not run the unit with the thermistors and sensors removed will break the compressor.)</li> <li>(Dorating the unit with the thermistors or sensors when the power supply and transmission wiring are connected.</li> <li>(Operating the unit with the thermistors or ansors removed will break the compressor.)</li> <li>(Do not run the unit with the thermistors or sensors removed will break the compressor.)</li> <li>(Do and train that all electric wiring works is carried out by qualified personnel according to the applicable legislation and this installation manual, using a separate circuit. Insufficient copacity of improper electric work may lead to electric shocks or a fire.</li> <li>(The wiring between the indoor unit and outdoor unit must be for 320V.</li> <li>(For electric wiring work, refer to also the "WIRING DIAGRAM".</li> <li>(When doing the electric burds, wiring the senset and to releption earth wiring.</li> <li>(Lighting conductor or telephone earth wiring</li></ul>

# 8 ELECTRICAL WIRING WORK (2/3)

• Please fix power supply wiring, transmission wiring, and earth wiring by clamp material as below figure.





3. Breaker type and capacity shall be selected in accordance with local laws and regulations.

## **A** CAUTION

## To the electrician

- Do not operate the unit until the refrigerant charging is completely.
- (If it is operation before that, the compressor will be broken.)

# 9 CHECK ITEMS BEFORE TEST OPERATION AND FIELD SETTINGS

## PRE-RUN CHECKS

	ITEM TO CHECK	CHECK
Power supply Wiring	Is the wiring as mentioned on the wiring diagram? make sure no wiring has been forgotten and that there are no missing phases or reverse phases.	
vviing	Does wiring between units put in and changed in continuation installation?	
	Is the unit properly grounded?	
	Are any of the wiring attachment screws loose?	10
	Is the insulation resistance at least 1MΩ? • Use a 500V mega-tester when measuring insulation • ※ Do not use a mega-tester to low voltage circuit except 220-240V.	
	Is an earth leakage circuit breaker used as a current operated type which is compatible to the higher harmonic wave?	22
	Does the earth leakage circuit breaker have appropriate rated current?	
Refrigerant	Is the size of the piping appropriate?	
piping	Is the insulation material for the piping attached securely? Are both the liquid and gas pipes insulated?	
	Are the stop valves for both the liquid side and the gas side open?	
Extra refrigerant	Did you write down the extra refrigerant and the refrigerant piping length?	
Indoor unit	Is the indoor unit fully installed? When the test run is started, the fan automatically begins turning.	

• When a power supply is switched on, when you leave from the outdoor unit, be sure to close the cover plate. (It becomes the cause of an electric shock).

In field setting for an outdoor unit, make sure to shut down the power and check that there is no residual voltage before start installing. (It may cause an electric shock.)

THE METHOD OF LOW NIGHT NOISE SETTING USING THE REMOTE CONTROLLER

The functions of the "Low Night Noise Setting" outdoor unit can be set by using the remote controller. During installation, make the field settings according to the description below, after the service inspection and repair. Mistakes in the setting could cause malfunctions.

#### (HOW TO MAKE THE FIELD SETTINGS)

Make the field setting according to "How to make the field settings" which come with the remote controller. The settings are set by switching between "Mode No.", "FIRST CODE No.", and "SECOND CODE No.". (CONTENT OF SETTINGS AND SETTING NUMBER)

						: Facto	ory settings
	FIRST	Description	SECOND CODE NO.				
NO.	CODE NO.	Description	01	02	03	04	05
	0	Night time low noise operation		Automatic Low noise activation			
16 (26)	1	Automatic low noise start and stop time			22h00 06h00	22h00 08ĥ00	20h00 08h00
	2	High sensible cooling setting	-		Server room setting	Anti-Frozent + Server room setting (combine)	

See the service manual for details on the content of the settings.

#### NOTES

 Settings are done in a batch for the group. For this reason, when performing group control\* using the remote controller from one unit to set individual outdoor units, set each unit separately (for each connected indoor unit no.) using the mode number in parentheses. Checking after changing settings can also only be done using the mode numbers in parentheses. (For group batch control, the display will always read "01" even though the settings have been changed.) Furthermore, when performing control with two remote controllers\*, field settings using a remote controller can only be done using the main remote controller.


\* For details on controlling the units using the remote controllers, see applicable service manual.


2. Do not set any values not shown in the table above.



- For settings other than the above, refer to the caution label or the service manual.
- Low night noise operation and demand operation using an external command requires a demand adapter
- PC board (option). For more details, refer to the manual supplied with the adapter.

Vovor porform a tost and	MARNING	
removed, as this might b f the technician must lea	ration with the discharge piping thermist reak the compressor.	or(R2T) and suction piping thermistor(R3T) itch places with another installation technician
OW TO TEST OPERA	TION After the indoor and outdoor un the test operation in accordance	t installation, be sure to perform with the following procedure.
Se sure to close the from Note: After doing an air- valves are opened electronic expansion Attach the stop valve cov outdoor unit to protect the	on with the remote controller.	sk of electric shock)> It pressure may not rise even if the stop ath is closed off by the outdoor unit e unit is run.
(In this case, the remote "heating operation.") Thi to open the stop valve du If the outside air tempera operation is set, the syst Operate normally.	to heating operation, but this is not abnorm controller display will continue to display is is in order to detect if someone has forgot ring trial operation. ture is about 24°C or more, even if HEATING em may not operate, but this is not abnorm adoor and outdoor units according to the	tten
ALFUNCTION DIAGN	SIS	
t the time of a test run, w	hen the following malfunction code is disp	
	t of installation construction can be consid	
Malfunction code		Gered. Remedial action "Open" operation of a stop valve
Malfunction code [E3] [E5] [U0] [L8]	Installation error	Remedial action
Malfunction code [E3] [E5] [U0] [L8] [E3] [E5] [L4] [L8]	Installation error A failure of a stop valve to open	Remedial action "Open" operation of a stop valve
Malfunction code [E3] [E5] [U0] [L8] [E3] [E5] [L4] [L8] [U1]	Installation error A failure of a stop valve to open Closing of an air passage	Remedial action "Open" operation of a stop valve Removing closing thing from air passage 2 Phase of power supply 3 Phase
Malfunction code [E3] [E5] [U0] [L8] [E3] [E5] [L4] [L8] [U1] [U2]	Installation error         A failure of a stop valve to open         Closing of an air passage         Missing phase, negative phase	Remedial action "Open" operation of a stop valve Removing closing thing from air passage 2 Phase of power supply 3 Phase (L1, L2, L3 Phase) are replaced
Malfunction code [E3] [E5] [U0] [L8] [E3] [E5] [L4] [L8] [U1] [U2] [U4] [UF]	Installation error         A failure of a stop valve to open         Closing of an air passage         Missing phase, negative phase         Power supply unbalancing	Remedial action "Open" operation of a stop valve Removing closing thing from air passage 2 Phase of power supply 3 Phase (L1, L2, L3 Phase) are replaced Unbalanced dissolution
	Installation error         A failure of a stop valve to open         Closing of an air passage         Missing phase, negative phase         Power supply unbalancing         Incorrect connection of field wiring         Connection of incompatible	Remedial action "Open" operation of a stop valve Removing closing thing from air passage 2 Phase of power supply 3 Phase (L1, L2, L3 Phase) are replaced Unbalanced dissolution Correction of wiring Connect appropriate indoor unit
Malfunction code [E3] [E5] [U0] [L8] [E3] [E5] [L4] [L8] [U1] [U2] [U4] [UF] [UA] NO INDICATION Vhen malfunction codes of etween an indoor and an for the malfunction codes and and the thing which is not. The followings can be con - The capacity of a break - The leakage circuit break	Installation error           A failure of a stop valve to open           Closing of an air passage           Missing phase, negative phase           Power supply unbalancing           Incorrect connection of field wiring           Connection of incompatible indoor unit           Mistake wiring or not connect wiring of power supply, indoor, outdoor, field wiring between indoor unit           wher than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayed on rem outdoor unit           other than the above are displayeed on rem outdoor unit </td <td>Remedial action         "Open" operation of a stop valve         Removing closing thing from air passage         2 Phase of power supply 3 Phase (L1, L2, L3 Phase) are replaced         Unbalanced dissolution         Correction of wiring         Connect appropriate indoor unit (Refer to the catalogue)         To correct wiring or connect correctly         note control, considering that the failure of on manual or outdoor service manual. f the interior of a room and an outdoor unit, er supply trips. guired capacity of the leakage circuit breaker.</td>	Remedial action         "Open" operation of a stop valve         Removing closing thing from air passage         2 Phase of power supply 3 Phase (L1, L2, L3 Phase) are replaced         Unbalanced dissolution         Correction of wiring         Connect appropriate indoor unit (Refer to the catalogue)         To correct wiring or connect correctly         note control, considering that the failure of on manual or outdoor service manual. f the interior of a room and an outdoor unit, er supply trips. guired capacity of the leakage circuit breaker.





# **13** REFRIGERANT RECOVERY

### [Working procedure]

- 1. Recovery retaining oil in existing pipe Approx. 1 min Close gas stop valve (liquid stop valve: open) and recovery refrigerant from gas stop valve port.(Fig.1)
- Recovery retaining oil in existing liquid pipe Approx. 1 min Recovery refrigerant from liquid stop valve port. (Fig.2)
- Recovery refrigerant in outdoor unit Approx. 2-3 min Recovery refrigerant from outdoor unit refrigerant recovery port \*1 .(Fig.3)
   NOTE 1 Can be omit this procedure if there is no refrigerant recovery port
- NOTE 1 Can be omit this procedure if there is no refrigerant recovery port 4. Recovery refrigerant in accordance with Fluorocarbons Recovery and Destructive Law

If refrigerant recovery port \*<sup>2</sup> pressure become lower than gas stop valve port pressure, refrigerant will recover at the simultaneous from the gas stop valve port, open gas stop valve (Fig.3-1) gradually to avoid from pressure rising rapidly. (Fig.3-2)

NOTE 1 Can be omit this procedure if there has no refrigerant recovery port simultaneously if there has no refrigerant recovery port.

Retaining oil recovery amount improved approx. 5 times from regular refrigerant recovery method

(pipe length, height difference, pipe path etc. is difference by installation condition)

#### ABOUT FLARE PROCESSING

- Flare connection area of existed piping will cause processing deterioration, make sure to do newly re-processing.
- Flare processing [Unit: mm]

		1
T	ΪN.	
A	ΙΓ	

- Piping outside diameter
   A (+0, -0.4)

   Ø 9.5
   13.2

   Ø 15.9
   19.7
- Please use flare nut which attached with product (Do not use existed flare nut)
- Flare nut [Unit: mm]



Fig. 1

Fig. 2

Fig.3 Indoor Unit

Indoor Unit

Indoo Unit

Piping outside	B (+0 , -0.6)
diameter	For R32
Ø9.5	22
Ø 15.9	29

-Ref. recovery

recovery port

Ref. recovery port (\*1,\*2)

Outdoor

OPEN

Outdoor

Unit

Gas. stop valve

Outdoor

Unit

Gas. pipe

OPEN

Gas, pipe

OP Valve

Gas, pipe

(OPEN)

64

Ref. recovery machine

sure guage

00

Ref. recovery machine

Ref. recovery machine

Tank

# **REFRIGERANT PIPE SIZE TABLE**

Outdoo	r Unit	Existing pipe size	9.5/15.9	Height difference	Design pressure (High pressure)
RZA100AV16		Standard pipe length	7.5m		
RZA125AV16 RZA140AV16	9.5/15.9	Max. pipe length	50m	Max 30m	4.15 MPa
		Chargeless pipe length	30m		

Refer to the installation manual for details other than those mentioned above table such as additional refrigerant charge amount.


- Clean the existing piping if it length is exceed 30m.
- Clean the existing pipe if chargeless length is exceed limit of existing pipe pump down refrigerant recovery.

#### Standard pipe (R32)

Pipe size (mm)	ø9.5	Ø15.9
Thickness (mm)	t 0.8	t 1.0

# 14. Unpacking & Packing of the Outdoor Unit


## 14-1 Unpacking




 Cut all the straps (a) from the unit using strap cutter(b) as shown in figure.

3


- a) Strap b) Starp Cutter c) Top corrugated cardboard sheet with EPS
  - d) Cardboard Box
  - e) Bottom Skid



 Remove the Top corrugated cardboard sheet with EPS from the unit by pulling it up as shown in figure.




Remove the bottom skid(d) with EPS by pulling the unit up, then remove the polythene product cover by pulling it up



 Remove the cardboard box from the unit by pulling it up as shown in figure.

### 14-2 Packing



Cover the unit with polythene product cover, then pick the unit up and settle it down on the bottom skid(e) as shown in figure.


- Strap a)
- Starp Cutter b)
- Top corrugated c) cardboard sheet with EPS

2


- d) Cardboard Box
- e) Bottom Skid
- f) Portable strap fixing machine
- d

4

Put the cardboard box (d) upon the unit as shown in figure.



Put the top corrugated cardboard sheet and EPS (c) on the top of the unit as shown in figure.



Fix the straps (a) on the unit with help of strap • fixing machine (f) as shown in figure. Use marked reference for placing straps)



# **OPERATION MANUAL**

# **SPLIT SYSTEM**

# **Air Conditioner**

### MODELS (Ceiling-mounted Duct type)

OUTDOOR
RZA100AV16
RZA125AV16
RZA140AV16

Operation Manual Split Type Air Conditioner

English

Thank you for purchasing this product unit. Carefully read this operation manual to ensure proper operation.

After reading the manual, file it away for future reference.

Furthermore, make certain that this operation manual is handed to new user when he/she takes over the operation.

As this operation manual is dedicated for the indoor unit, refer to also the operation manual attached to the remote controller.

## CONTENTS

1.SAFETY PRECAUTIONS	43
2.WHAT TO DO BEFORE OPERATION	46
3.OPERATION RANGE	47
4.INSTALLATION SITE	48
5. OPERATION PROCEDURE	
6. OPERATION CHARACTERISTICS	48
7.OPTIMUM OPERATION	50
8.MAINTENANCE	
(FOR SERVICE PERSONNEL)	50
9.NOT MALFUNCTION OF THE AIR	
CONDITIONER	52
10.TROUBLESHOOTING	54

## **1. SAFETY PRECAUTIONS**

Read the precautions in this manual carefully before operating the unit



This appliance is filled with R32

To gain full advantage of the air conditioner's functions and to avoid malfunction due to mishandling, please read this operation manual carefully before use.

Read the precautions thoroughly to avoid misuse of the equipment.


This product comes under the term "appliances not accessible to the general public".

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. children shall not play with the appliance. Cleaning and user maintenance shall only be done by persons described in manual. The appliance is not intended for use by unattended young children or persons who are incompetent to operate air conditioners. It may result in injury or electric shocks.

• The precautions described herein are classified as WARNING and CAUTION. they both contain important information regarding safety.

Be sure to observe all precautions without fail.

• There are two kinds of safety precaution and tips listed in the following.



- After reading, keep this manual in a convenient place so that you can refer to it whenever necessary. If the equipment is transferred to a new user, be sure also to hand over the manual.
  - DISPOSAL REQUIREMENTS



### **Disposal requirements**

Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by qualified installer in accordance with relevant local and national legislation. Air conditioners must be treated at a specialized treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

Batteries must be removed from the remote controller and disposed of separately in accordance with relevant local and national legislation.

## 

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance must be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).

Do not pierce or burn.

Be aware that refrigerants may not contain an odor.

Floor area required for installation of the equipment, refer to the installation manual of the outdoor unit.

Do not place burners or heaters in places exposed to the airflow from the unit as this may impair combustion of the burner or heater.

#### When the air conditioner is malfunctioning (giving off a burning odor, etc.), turn off the power to the air conditioner and contact your local dealer.

Continued operation under such circumstances may result in a failure, electric shocks or a fire.

# Consult your local dealer regarding modification, repair and maintenance of the air conditioner.

Improper workmanship may result in water leakage, electric shocks or a fire .

# Be sure to use fuses with the correct ampere reading.

Do not use improper fuses, copper or other wiring as a substitute, as this may result in electric shocks, a fire, injury or damage to the air conditioner.

#### Consult your local dealer if the air conditioner submerges owing to a natural disaster, such as a flood or typhoon.

Do not operate the air conditioner in that case, or otherwise a malfunction, electric shocks, or a fire may result.

# Start or stop the air conditioner with the remote controller. Never use the power circuit breaker for this purpose.

Otherwise, it may cause a fire or water leakage. Furthermore, if an automatic restart control is provided against power failure and the power is recovered, the fan will rotate suddenly and may cause injury.

Do not use the air conditioner in the atmosphere contaminated with oil vapor, such as cooking oil or machine oil vapor. Oil vapor may cause crack damage to the air conditioner, electric shocks, or a fire .

# Do not use flammable materials (e.g., hairspray or insecticide) near the air conditioner.

#### **Do not clean the air conditioner with organic solvents such as paint thinner.** The use of organic solvents may cause crack

damage to the air conditioner, electric shocks, or a fire .

#### Do not use the air conditioner in places with excessive oily smoke, such as cooking rooms, or in places with flammable gas, corrosive gas or metal dust.

Using the air conditioner in such places may cause a fire or air conditioner failures.

# Beware of a fire in case of refrigerant leakage.

If the air conditioner is not operating correctly, i.e. not generating cool or warm air, refrigerant leakage could be the cause. Consult your local dealer for assistance. The refrigerant used for the air conditioner is safe and normally does not leak. However, if the refrigerant leaks and gets in contact with a naked burner, heater or cooker, it may generate hazardous compounds. Turn off the air conditioner and call your local dealer. Turn on the air conditioner after the qualified service person makes sure to confirm that the leakage is repaired.

# Do not place objects, including rods, your fingers, etc., in the air inlet or outlet.

Injury may result due to contact with the air conditioner's highspeed fan blades.

# Consult your local dealer regarding cleaning the inside of the air conditioner.

Improper cleaning may cause breakage of plastic parts, water leakage and other damage as well as electric shocks.

Be aware that prolonged, direct exposure to cool or warm air from the air conditioner, or to air that is too cool or too warm can be harmful to your physical condition and health.

# Consult your local dealer about installation work.

Doing the work yourself may result in water leakage, electric shocks or a fire .

#### Contact professional personnel about attachment of accessories and be sure to use only accessories specified by the manufacturer.

If a defect results from your own workmanship, it may result in water leakage, electric shocks or a fire .

# Consult your local dealer regarding relocation and reinstallation of the air conditioner.

Improper installation work may result in leakage, electric shocks or a fire.

### Be sure to earth the air conditioner.

Do not earth the air conditioner to a utility piping, lightning conductor or telephone earth lead. Imperfect earthing may result in electric shocks or a fire.

A high surge current from lightning or other sources may cause damage to the air conditioner.

### Be sure to install an earth leakage breaker.

Failure to install an earth leakage breaker may result in electric shocks or a fire.

# Be sure to use a dedicated power supply for the air conditioner.

The use of any other power supply may cause heat generation, a fire, or air conditioner failures.

# Consult your local dealer regarding what to do in case of refrigerant leakage.

When the air conditioner is installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen depletion.

# 

#### Children should be watched so that they do not play with the indoor unit or its remote controller.

Accidental operation by a child may result in injury or electric shocks.

#### **Do not allow a child to mount on the outdoor unit or avoid placing any object on it.** Falling or tumbling may result in injury.

# Do not let children play on or around the outdoor unit.

If they touch the unit carelessly, injury may be caused.

Be sure that children, plants or animals are not exposed directly to airflow from the indoor unit, as adverse effects may ensue.

Do not place flammable sprays or operate spray containers near the air conditioner as this may result in a fire.

Do not wash the air conditioner or the remote controller with water, as this may result in electric shocks or fire.

#### Do not place water containers (flower vases, etc.) on the indoor unit, as this may result in electric shocks or a fire.

# **Do not put flammable containers, such as spray cans, within 1 m from the air outlet.** The containers may explode because the warm air from the indoor or outdoor unit will affect them.

# Turn off the main power switch when the air conditioner is not to be used for prolonged periods.

When the main power switch is left on, some electrical power (watts) is still consumed even if the air conditioner is not operating. Therefore, switch off the main power switch to save energy. When resuming operation, to ensure smooth running, turn on the main power switch 6 hours before operating the air conditioner again.

#### Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.

Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or a fire when making contact with electrical parts.

# Before cleaning, be sure to stop the air conditioner operation, turn the power circuit breaker off.

Otherwise, an electric shocks and injury may result.

# To avoid electric shocks, do not operate with wet hands.

# Never touch the internal parts of the remote controller.

Touching certain internal parts will cause electric shocks and damage to the remote controller. Consult your local dealer about checking and adjustment of internal parts.

To avoid oxygen deficiency, ensure that the room is adequately ventilated if equipment such as a burner is used together with the air conditioner.

# Do not leave the remote controller wherever there is a risk of wetting.

If water gets into the remote controller there is a risk of electrical leakage and damage to electronic components.

# Watch your steps at the time of air filter cleaning or inspection.

High-place work is required, to which utmost attention must be paid.

If the scaffold is unstable, you may fall or topple down, thus causing injury.

# Do not remove the outdoor unit's outlet side grille.

The grille protects against the unit's high speed fan, which may cause injury.

# To avoid injury, do not touch the air inlet or aluminum fins of the air conditioner.

#### Do not place objects that are susceptible to moisture directly beneath the indoor or outdoor units.

Under certain conditions, condensation on the unit or refrigerant piping, air filter dirt or drain blockage may cause dripping, resulting in fouling or failure of the object concerned.

# Do not place heaters directly below the indoor unit, as resulting heat can cause deformation.

Do not place appliances that produce naked flames in places exposed to the airflow from the air conditioner as this may impair combustion of the burner.

### Do not block air inlets nor outlets.

Impaired airflow may result in insufficient performance or trouble.

# Do not use the air conditioner for purposes other than those for which it is intended.

Do not use the air conditioner for cooling precision instruments, food, plants, animals or works of art as this may adversely affect the performance, quality and/or longevity of the object concerned.

#### Do not install the air conditioner at any place where there is a danger of flammable gas leakage.

In the event of a gas leakage, build-up of gas near the air conditioner may result in a fire .

# Carry out drain piping properly to ensure complete drainage.

If drain piping is not carried out properly, drain will not flow out. Then, dirt and debris may be accumulated in the drain piping and may cause water leakage. If it occurs, stop the air conditioner and call your local dealer for assistance.

# After prolonged use, check the unit stand and its mounts for damage.

If left in a damaged condition, the unit may fall and cause injury.

# **Do not sit or place objects on the outdoor unit.** Falling yourself or falling objects could cause injury.

# Arrange the drain hose to ensure smooth drainage.

Imperfect drainage may cause wetting of the building, furniture etc.

# Ensure that the remote controller is not exposed to direct sunlight.

This will cause discoloration of the LCD display with resulting loss of readability.

# Do not wipe the controller panel with benzene or other organic solvent.

This will cause discoloration and/or peeling. If the panel needs cleaning, use a damp cloth with some water-diluted neutral detergent. Wipe with a dry cloth afterwards.

# Never operate remote controller buttons with hard, pointed objects.

**Do not pull or twist the remote controller cord.** This may cause malfunctioning.

# Do not operate the air conditioner when using a room fumigation type insecticide.


Fumigation chemicals deposited in the unit could endanger the health of those who are hypersensitive to such chemicals.

Take care of scaffolding and exercise caution when working high above ground level.

**Do not operate with the control panel lid open.** If water gets inside the panel, it may result in equipment failure or electric shock.

### 2. WHAT TO DO BEFORE OPERATION

This operation manual is for the following system with standard control. Before initiating operation, contact your local dealer for the operation that corresponds to your system



• Heat pump type This system provides COOLING, HEATING, AUTOMATIC, PROGRAM DRY, and FAN OPERATION modes.

### PRECAUTIONS FOR GROUP CONTROL SYSTEM OR TWO REMOTE CONTROLLERS CONTROL SYSTEM

This system provides two other control systems beside individual control (one remote controller controls one indoor unit) system. Confirm the following if your unit is one of the following control system type.

Group control system

One remote controller controls up to 16 indoor units. All indoor units are equally set.

#### • Two remote controllers control system

Two remote controllers control one indoor unit (In case of group control system, one group of indoor units).


The unit is individually operated.

### NOTE 🖘

- Contact your local dealer in case of changing the combination or setting of group control and two remote controllers control system.
- Please do not change the combination and settings for the group operation and two remote controllers control systems by yourself, but be sure to ask your local dealer.
- Read the operation manual attached to the remote controller you are using.

If your installation has a customized control system, ask your local dealer for the operation that corresponds to your system.

### Names and functions of parts



- 1 Air outlet (Field supply)
- 2 Exhaust duct (Field supply)
- 3 Drain pipe
- 4 Refrigerant piping
- 5 Wiring between indoor and outdoor unit
- 6 Remote controller (Sold separately)
- 7 Drain discharge device (built-in)7 Discharge indoor moisture removed during cooling operation.
- 8 Power line

Ground wire

- **9** This wire releases electricity from the indoor unit to the ground in order to prevent electric shock or fire.
- 10 Air filter (inside filter chamber) (Sold separately)
- 11 Suction filter chamber (Sold separately)
- 12 Suction duct (Field supply)
- Machine nameplateThe nameplate is imprinted with the machine name and specifications.
- **14** Suction grille (Field supply)

### 3. OPERATION RANGE

If the temperature or the humidity is beyond the following conditions, safety devices may work and the air conditioner may not operate, or sometimes, water may drop from the indoor unit.

#### COOLING

OUTDOOF		INDC		0	UTDOOR
UNIT	TE	MPERA- TURE	HUMIDITY	TE	EMPERA- TURE
RZA100AV16 RZA125AV16	D B	19 to 35	80%	D	01 to 50
RZA125AV16 RZA140AV16	W B	14 to 24	or below	B	21 to 52

#### HEATING

OUTDOOR UNIT		INDOOR MPERATURE	Т	OUTDOOR EMPERATURE
RZA100AV16 RZA125AV16	D	10 to 27	D B	-15to 24
RZA140AV16	В	10 10 27	W B	–15to 18

DB: Dry bulb temperature (°C)

WB: Wet bulb temperature (°C)

# 4. INSTALLATION SITE

### **Regarding places for installation**

- Is the air conditioner installed at a well-ventilated place where there are no obstacles around?
- Do not use the air conditioner in the following places.
  - a. Filled with much mineral oil such as cutting oil.
  - b. Where there is much salt such as a beach area.
  - c. Where sulfured gas exists such as a hot-spring resort.
  - d. Where there are considerable voltage fluctuation such as a factory or plant.
  - e. Vehicles and vessels.
  - f. Where there is much spray of oil and vapor such as a cookery, etc.
  - g. Where there are machines generating electromagnetic waves.
  - h. Filled with acid and/or alkaline steam or vapor.
- Is a snow protection measure taken? For details, consult your local dealer about snow protection hoods, etc.

### **Regarding wiring**

• All wiring must be performed by a qualified personnel.

To do wiring, ask your local dealer. Never do it by yourself.

 Make sure that a separate power supply circuit is provided for this air conditioner and that all electrical work is carried out by qualified personnel according to local laws and regulations.

# Pay attention to running noises, too

- Are the following places selected?
  - a. A place that can sufficiently withstand the mass of the air conditioner with less running noises and vibrations.
  - b. A place where the hot wind discharged from the air outlet of the outdoor unit and the running noises do not cause a nuisance to neighbours.
- Are you sure that there are no obstacles near the air outlet of the outdoor unit? Such obstacles may result in declined performance and increased running noises.
- If abnormal noises occur in use, stop the operation of the air conditioner, consult your local dealer.

### Regarding drainage of drain piping

• Is the drain piping carried out properly to ensure complete drainage?

If drain piping is not carried out properly, dirt and debris may be accumulated in the drain piping and cause water leakage. If it occurs, stop the air conditioner and consult with your local dealer for assistance.

### System relocation

• Consult your Daikin dealer about remodelling and relocation.

# 5. OPERATION PROCEDURE

- Operating procedure varies with heat pump type and cooling only type. Contact your local dealer to confirm your system type.
- To protect the air conditioner, turn on the main power switch 6 hours before operation.
- Do not shut off the power supply during seasonal use of the air conditioner. This is required in order to activate the air conditioner smoothly.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

Read the operation manual attached to the remote controller.

# 6. OPERATION CHARACTERISTICS

### CHARACTERISTICS OF THE COOLING OPERATION (COOLING OPERATION AND AUTOMATIC COOLING OPERATION)

- If the COOLING OPERATION is used when the indoor temperature is low, frost forms on the heat exchanger of the indoor unit. This can decrease the cooling capacity. In this case, the air conditioner automatically switches to the DEFROST OPERATION for a while. During the DEFROST OPERATION, the low fan speed is used to prevent the discharge of melt water. (The remote controller displays the fan speed that is set.)
- When the outdoor temperature is high, it takes some time until the indoor temperature reaches the set temperature.

### CHARACTERISTICS OF THE HEATING OPERATION (HEATING OPERATION AND AUTOMATIC HEATING OPERATION)

### START OF OPERATION

 It generally takes a longer time for indoor temperature of the HEATING OPERATION to reach the set temperature compared to the COOLING OPERATION. It is advisable to start operation in advance using the TIMER OPERATION.

#### Perform the following operation to prevent heating capacity decrease and discharge of cool air.

### AT THE START OF OPERATION AND AFTER THE DEFROST OPERATION

- A warm air circulating system is employed, and therefore it takes some time until the entire room is warmed up after the start of operation.
- The indoor fan runs to discharge a gentle wind automatically until the temperature inside the air conditioner reaches a certain level. At this time, the remote controller displays " (a) a ". Leave it as it stands and wait for a while.

(The remote controller displays the fan speed that is set.)

### **DEFROST OPERATION**

# (Frost removal operation for the outdoor unit)

- As the frost on the coil of an outdoor unit increase, heating effect decreases and the air conditioner goes into the DEFROST OPERATION.
- The indoor unit fan stops and the remote controller display shows " Image: Optimized Stops and the wireless remote controller, the warm air stops, and the DEFROST OPERATION lamp on the light receiving unit turn on. (The remote controller displays the fan speed that is set.)
- After maximum 10 minutes of the DEFROST OPERATION, the air conditioner returns to the HEATING OPERATION.
- During or after the DEFROST OPERATION, white mist comes out from the air inlet or outlet of the air conditioner.

(Refer to **4.** on page 49.)

• A hissing and "Shuh" sound may be heard during this particular operation.

# Regarding outside air temperature and heating capacity

- The heating capacity of the air conditioner declines as the outside air temperature falls. In such a case, use the air conditioner in combination with other heating systems. (When a combustion appliance is used, ventilate the room regularly.) Do not use the combustion appliance where the air from the air conditioner is blown directly toward it.
- When the warm air stays under the ceiling and your feet are cold, we recommend that you use a circulator (a fan to circulate the air inside the room). For details, consult your local dealer.
- When the indoor temperature exceeds the set temperature, the indoor unit discharges a gentle breeze (switches to gentle wind). (The remote controller displays the fan speed that is set.)

### CHARACTERISTICS OF THE PROGRAM DRY OPERATION

• This operation lowers the humidity without lowering the indoor temperature. The indoor temperature when the operation button is pressed will be the set temperature. At this time, the fan speed and temperature are set automatically, so the remote controller does not display the fan speed and set temperature.

To efficiently lower the indoor temperature and humidity, first use the COOLING OPERATION to lower the indoor temperature, and then use the PROGRAM DRY OPERATION. When the indoor temperature is lowered, airflow from the air conditioner may stop.

• If the PROGRAM DRY OPERATION is used when the indoor temperature is low, frost forms the heat exchanger of the indoor unit. In this case, the air conditioner automatically switches to the DEFROST OPERATION for a while. The low fan speed or a gentle wind is used to prevent the discharge of melt water.

## 7. OPTIMUM OPERATION

Observe the following precautions to ensure the air conditioner operates.

- Prevent direct sunlight from the window by using curtains or blinds during the COOLING OPERATION.
- Keep doors and windows closed. If the doors and windows remain open, room air will flow out and decrease the effect of cooling and heating.
- Never place objects near the air inlet and the air outlet of the air conditioner. It may decrease the effect or stop the operation.
- Set the airflow flap of the air discharge grille horizontally not to obstruct the wind. Otherwise, the wind will not come out and a failure may result.
- Adjust the room temperature properly for a comfortable environment. Avoid excessive heating or cooling.
- Not doing so wastes electricity.
- When the display shows " 🐨 " or "Time to clean filter", ask a qualified service person to clean the filters.

(Refer to **8. MAINTENANCE** on this page.) Operating the indoor unit with stained air filter may decrease capacity or cause malfunction.

 Install TVs, radios, and stereos 1 m or more away from the indoor unit and remote controller. Images may become fuzzy and noise may be generated.

Turn off the power circuit breaker when it is not in use for a long period. When the power circuit breaker is turned on, small amount of power is consumed even if the air conditioner is not in operation. (\*1)

Turn off the power circuit breaker for saving energy. When reoperating, turn on the power circuit breaker 6 hours before operation for smooth running.

(Refer to 8. MAINTENANCE on this page.) (\*2)

- \*1 The consumed power while the outdoor unit is not in operation depends on the model.
- \*2 The setting before the power circuit breaker is cut off is stored. (The timer setting is cleared.)
- Use the TIMER OPERATION effectively. It takes some time until the indoor temperature reaches the set temperature. It is advisable to start operation in advance using the TIMER OPERATION.

## 8. MAINTENANCE (FOR SERVICE PERSONNEL)

# ONLY A QUALIFIED SERVICE PERSON IS ALLOWED TO PERFORM MAINTENANCE

### 

- Do not use flammable gas (such as hair sprays and insecticides) near the air conditioner.
- Do not wipe the air conditioner with benzine or thinner.

It may cause cracks, electric shocks or a fire.

# 

- Do not wash the air conditioner with water. It may cause electric shocks or a fire due to leakage.
- Make sure to turn off the air conditioner when taking care of the air conditioner and disconnect the power supply breaker. Unless the power supply is disconnected, it may cause electric shocks and injuries.
- When working at a high place, give caution to your footing.

If the scaffold is unstable, it may cause injuries due to fall and stumbling.

### HOW TO CLEAN THE AIR FILTER

When the remote controller indicates " 👘" or "Time to clean filter", clean the air filter.

• It indicates after running for a certain time.

### NOTE 🗐

• You may change the time of indication " Time to clean filter".

#### If the indoor unit is used in a space where the air is too contaminated, ask your local dealer for solution.

Contamination	Time until indication is displayed
Normal	200 hours (equivalent to 1 month)
More contaminated	100 hours (equivalent to 2 weeks)

 If it becomes difficult to remove contamination from the air filter, replace the air filter. (Air filter for replacement is an optional accessory)

Increase the frequency of cleaning if the unit is installed in a room where the air is extremely contaminated.

### NOTE -

- Do not remove the air filter except when cleaning. Unnecessary handling may damage the filter. (This product is not provided with an air filter as a standard accessory.)
- Do not attach objects other than the genuine air filter (e.g., kitchen paper) to the air inlet. Otherwise, the performance of the air conditioner will be degraded, and icing or water leakage may result.
- This product is a ceiling mounted duct type air conditioner.

### Installing under roof

If the air filter (optional parts) is used, request a special contractor for the cleaning of the air filter. **Not installing under roof** 

Always use the long-life filter chamber (optional parts). Be sure to request your dealer for the installation of the long-life chamber. For the methods of mounting, dismounting, and cleaning the air filter, refer to the manual provided with the air filter.

- Be sure to use the optional filter chamber. Request your dealer for the installation of the filter chamber.
- Be sure to clean the air filter at the beginning of the cooling or heating season.
   (A decrease in the airflow volume of the air conditioner will result and the performance of the air conditioner will be degraded if the air filter is clogged with dust or dirt.)

# After completing cleaning and installing an air filter, turn off the indication of " 4<sup>th</sup>" or "AIR FILTER CLEANING TIME" on the remote controller.

- Press the FILTER SIGN RESET button.
- The indication can be turned off while the unit is either operating or stopped.

# HOW TO CLEAN AIR OUTLET, OUTSIDE PANELS AND REMOTE CONTROLLER

- 1. Clean with soft cloth.
- 2. When it is difficult to remove stains, use water or neutral detergent.

### NOTE -

- Do not wash the suction grille with water of 50°C or higher.
- It may cause discoloration and deformation. • When drying the suction grille, do not heat it
- when drying the suction grille, do not heat it with fire. It may cause burning.
- Do not use substances such as gasoline, benzine, thinner, polishing powder and liquid insecticide sold in the market. It may cause discoloration and deformation.

# WHAT TO DO WHEN START UP AFTER A LONG STOP

### **Confirm the following**

 Check that the air inlet and outlet of indoor and outdoor unit are not blocked.
 Remove any obstacle.
 Obstacles decrease the fan speed, and cause performance decrease and breakage of the

### Clean the air filter

devices.

- After cleaning the air filter, make sure to attach it.
- For information on how to install, remove, or clean an optional sold air filter, refer to the user's manual attached to the air filter.
- Turn off the indication """ or "Time to clean filter" displayed on the remote controller after turning on the power.

The indication can be turned off whether in operation or at stop.

For details, refer to the operation manual attached to the remote controller.

# Turn on the power circuit breaker at least 6 hours before operation.

- This is required in order to activate the air conditioner smoothly, and to protect air conditioner.
- The display on the remote controller will be shown when the power circuit breaker is turned on.

# HEATING OPERATION within 6 hours after the power is supplied to the air conditioner.

• Some models perform the following operation to protect the devices.

If the HEATING OPERATION is performed within 6 hours after the power is supplied to the air conditioner, the indoor fan stops for about 10 minutes during the outdoor unit operation to protect the devices.

The above operation is performed not only at the time of installation, but every time the power circuit breaker is turned off/on.

For comfortable use, do not turn off the power circuit breaker during seasonal use of the HEATING OPERATION.

### WHAT TO DO TO STOP THE AIR CONDI-TIONER FOR A LONG PERIOD

# Turn on FAN OPERATION for a half day on the fine day and dry the indoor unit.

• This can prevent the causes of mould.

### Turn off the power circuit breaker.

- During the power circuit breaker is turned on, some watts of electricity is being used even if the air conditioner is not operating. Turn off the power circuit breaker for saving energy.
- The display on the remote controller will vanish when the power circuit breaker is turned off.

### Clean the air filter and outside panel

• Be sure to replace the air filter to its original place after cleaning.

For information on how to install, remove, or clean an optional sold air filter, refer to the user's manual attached to the air filter.

### NOTE -

The inside of the air conditioner may become contaminated after several seasons of use, potentially causing performance degradation and water leakage.

Ask your local dealer for details on cleaning the inside of the indoor unit. This operation requires a qualified service person.

### 9. NOT MALFUNCTION OF THE AIR CONDITIONER

# The following symptoms do not indicate air conditioner malfunction

• HEATING OPERATION within 6 hours after the power is supplied to the air conditioner. Some models perform the following operation to protect the devices.

If the HEATING OPERATION is performed within 6 hours after the power is supplied to the air conditioner, the indoor fan stops for about 10 minutes during the outdoor unit operation to protect the devices.

The above operation is performed not only at the time of installation, but every time the power circuit breaker is turned off/on.

For comfort heating, it is recommended not to turn off the power circuit breaker during the HEATING OPERATION.

- 1. THE AIR CONDITIONER DOES NOT OPERATE
  - The air conditioner does not restart immediately after the ON/OFF button is pressed.
  - The air conditioner does not restart immediately when TEMPERATURE SETTING button is returned to the former position after pushing the button.
     If the OPERATION lamp lights, the air conditioner is in normal condition.
     It does not restart immediately because a safety device operates to prevent overload of the air conditioner.
     After approx. 3 minutes, the air conditioner will turn on again automatically.
  - The air conditioner does not start when the display shows " <u>\*</u>" and it flashes for few seconds after pressing an operation button.

This is because the air conditioner is under centralized control.

Flashes on the display indicates that the air conditioner cannot be controlled by the remote controller.

• HEATING OPERATION within 6 hours after the power is supplied to the air conditioner.

Some models perform the following operation to protect the devices. If the HEATING OPERATION is performed within 6 hours after the power is supplied to the air conditioner, the indoor fan stops for about 10 minutes during the outdoor unit operation to protect the devices. The above operation is performed not only at the time of installation, but every time the power circuit breaker is turned off/on. For comfortable use, do not turn off the power circuit breaker during seasonal use of the HEATING OPERATION.

• The outdoor unit stops. This is because the indoor temperature has reached the set temperature.

The indoor unit is in the FAN OPERATION. COOLING OPERATION (AUTOMATIC COOLING OPERATION): Lower the set temperature. HEATING OPERATION (AUTOMATIC HEATING OPERATION): Raise the set temperature.

The operation starts after a while when the air conditioner is in normal condition.

• The remote controller displays " <a>(main: %)</a> ", and airflow stops.

This is because the air conditioner automatically switches to the DEFROST OPERATION to prevent a decrease in heating capacity when frost on the outdoor unit increases.

After maximum 10 minutes, the air conditioner returns to its original operation.

### 2. THE OPERATION SOMETIMES STOPS

• The remote controller displays "U4" and "U5", and the operation stops. However, it will restart in a few minutes.

This is because communication between the indoor and outdoor units or indoor units and remote controllers is shut off and stops the operation due to noise caused by devices other than the air conditioner.

When the electrical noise decreases, the air conditioner automatically restarts.

# 3. THE FAN SPEED IS DIFFERENT FROM THE SETTING

# • Pressing the fan speed control button does not change the fan speed.

During the COOLING OPERATION, the low fan speed or a gentle wind is used to prevent the discharge of melt water.

During the DEFROST OPERATION (HEATING OPERATION), the wind from the air conditioner stops to prevent air discharge directly toward your body.

After a while, the fan speed can be changed. (The fan speed cannot be set for the PROGRAM DRY OPERATION.) When the room temperature reaches the

set temperature during the HEATING OPERATION, the outdoor unit stops and the indoor unit goes into gentle wind. It takes some time until the fan speed changes. Raise the set temperature. After a while, the fan speed changes.

### 4. WHITE MIST COMES OUT OF THE AIR CONDITIONER

• When humidity is high during the COOL-ING OPERATION (In oily or dusty places) If the inside of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the inside of the indoor unit. Ask your local dealer for details on cleaning the indoor unit.

This cleaning requires a qualified service person.

Check the usage environment.

• When the air conditioner is changed over to the HEATING OPERATION after the DEFROST OPERATION and in the DE-FROST OPERATION.

Moisture generated by defrost becomes steam and will float around.

When the remote controller display shows " (화군)", DEFROST OPERATION is being used.

### 5. NOISE OF AIR CONDITIONERS

• A low continuous flow "Shuh" sound which is heard when the air conditioner is in the COOLING or DEFROST OPERA-TION or a trickling sound which is heard when the air conditioner is in the DE-FROST OPERATION.

This is the sound of refrigerant gas flowing through both indoor and outdoor units.

• A "Shuh" sound which is heard at the start or immediately after the stop of operation or which is heard at the start or immediately after the stop of the DE-FROST OPERATION.

This is the noise of refrigerant caused by flow stop and flow change.

During the HEATING OPERATION, the air conditioner switches to the DEFROST OPERATION automatically.

The remote controller shows " (a) a ". After maximum 10 minutes, the air conditioner returns to its original operation.

• A "Pishi-pishi" squeaking sound is heard when the air conditioner is in operation or after the stop of operation.

Expansion and contraction of resin parts caused by temperature change makes this noise.

### 6. DUST FROM THE INDOOR UNITS

• Dust may blow out from the unit after starting operation from long resting time. Dust absorbed by the unit blows out.

### 7. THE INDOOR UNITS GIVE OFF ODOURS

### During operation

The unit absorbs the smell of rooms, furniture, cigarettes, etc., and then emits them.

If odour is a concern, you can set to zero fan speed when the indoor temperature reaches the set temperature.

For details, contact your local dealer.

### 8. THE AIR CONDITIONER DOES NOT COOL EFFECTIVELY

• The air conditioner is operating in the PROGRAM DRY OPERATION.

This is because program dry mode operates so that the indoor temperature decreases as little as possible.

Lower the indoor temperature using the COOLING OPERATION, and then use the PROGRAM DRY OPERATION.

(Refer to CHARACTERISTICS OF THE PROGRAM DRY OPERATION on page 49.)

• Read through characteristics of the COOLING OPERATION, characteristics of the HEATING OPERATION, and characteristics of the PROGRAM DRY OPERATION on page 48-49.

# **10. TROUBLESHOOTING**

### Please check before requesting a service.

- 1. If the air conditioner does not operate at all.
  - Check if fuse has blown. Turn off the power supply.
  - Check if the power circuit breaker is blown. If the tab of power circuit breaker is in the OFF position, turn the power on with the power circuit breaker switch.

If the tab of power circuit breaker is in the trip position do not turn the power on with the power circuit breaker switch. Contact your local dealer.



Power circuit breaker (Earth leakage breaker)  Check if there is a power failure. Wait until power is restored. If power failure occurs during operation, the air conditioner automatically restarts immediately after the power supply recovers.

# 2. If the air conditioner stops after operating the air conditioner.

- Check if the air inlet or outlet of outdoor or indoor unit is blocked by obstacles. Remove the obstacle and make it wellventilated.
- Check if the air filter is clogged. Ask a qualified service person to clean the air filters.

A decrease in the airflow volume of the air conditioner will result and the performance of the air conditioner will be degraded and power consumption will increase if the air filter is clogged with dust or dirt.

In addition, this may cause dew condensation at the air outlet.

(Refer to 8. MAINTENANCE on page 50.)

- 3. The air conditioner operates but it does not sufficiently cool or heat.
  - Check if the air inlet or outlet of outdoor or indoor unit is blocked by obstacles.
     Remove the obstacle and make it well-ventilated.
     Obstacles decrease the fan speed, and cause performance decrease and breakage when discharged air is suctioned.

They cause a waste of electricity, and that may stop the devices.

• Check if the air filter is clogged. Ask a qualified service person to clean the air filters.

A decrease in the airflow volume of the air conditioner will result and the performance of the air conditioner will be degraded and power consumption will increase if the air filter is clogged with dust or dirt.

In addition, this may cause dew condensation at the air outlet.

- (Refer to 8. MAINTENANCE on page 50.)
- Check if the set temperature is not proper. Set to an appropriate temperature and fan speed.
- Check if the FAN SPEED button is set to LOW SPEED.

Set to an appropriate temperature and fan speed.

• Check if the doors or the windows are open. Shut doors or windows to prevent wind from coming in. • Check if direct sunlight enters the room (when cooling).

Use curtains or blinds.

- When there are too many inhabitants in the room (when cooling).
- Check if the heat source of the room is excessive (when cooling).
- 4. Operation was performed or stopped although the ON/OFF button was not pressed.
  - Are you sure that the ON/OFF timer operation is not used? Turn off the ON/OFF timer. Please refer to operation manual attached to
  - the remote controller.
    Are you sure that any remote control device is not connected?
    Contact the central control room that directed the stop.
  - Are you sure that the display for centralized control is not lit? Contact the central control room that directed

the stop.

If the problem is not solved after checking the above points, please do not try to repair it yourself.

In such cases, always ask your local dealer. At this time, please tell the symptom and model name (written on the model name plate).

#### If one of the following malfunctions occurs, take the measures shown below and contact your local dealer.

The air conditioner must be repaired by a qualified service person.

# 

#### When the air conditioner is malfunctioning (giving off a burning odour, etc.), turn off power to the air conditioner and contact your local dealer.

Continued operation under such circumstances may result in a failure, electric shocks or a fire. Contact your local dealer.

 If a safety device such as a fuse, a power circuit breaker or an earth leakage breaker frequently actuates;

Measure: Do not turn on the main power switch.

- If the ON/OFF switch does not properly work; **Measure:** Turn off the main power switch.
- If water leaks from the indoor unit. **Measure:** Stop the operation.

• If a malfunction occurs, either one of the following messages will appear on the Basic screen on the wired remote controller during operation.

"Error: Push Menu button."
(\* The Operation lamp will blink.)
"Warning: Push Menu button."
(\* The Operation lamp will not blink.)

 Press Menu/Enter button. The Malfunction (Error) code blinks. For more information, refer to the operation manual attached to the remote controller.

Measure: Notify your local dealer and inform malfunction code of the display.

## DAIKIN DAIKIN AIRCONDITIONING INDIA PVT. LTD.

210, 1st FLOOR, OKHLA INDUSTRIAL AREA, PHASE 3, DELHI-110020

### PROTECT THE ENVIRONMENT FROM E-WASTE ( GUIDELINES)

Meaning of E-waste under E-Waste (Management) Rules,2022 (E-waste Rules) -Waste electrical and electronic equipment, whole or in part of reject from their manufacturing and repair process, which are intended to be discarded. Our product is RoHS compliant.

DO'S & DONT'S



# Don't dump Electrical and Electronic Products in Garbage Bins

DO'S	
Run and maintain the air conditioner as per the instructions given in the operation / instruction manual	~
Ensure that an authorised person repairs your air conditioner	~
Call our local authorised dealer or our toll free number to dispose your air conditioner	~
Contact an authorised dealer in case or installation or de-installation	~
Consult our local authorised dealer or our toll free number on the life span of the air conditioner	-
DONT'S	
Do not try to repair your air conditioner on your own	×
Do not sell or dispose your air conditioner or parts to an unauthorised Kabbadi wala / Scrap Dealer / Ragpickers	×
Do not dismantle your air conditioner on your own	×
Do not get your air conditioner or any parts repaired by an unauthorised person	X
	×
Do not dispose off the E-waste in landfills	

- In the event that there is any conflict in the interpretation of this manual and any translation of the same in any language, the English version of this manual shall prevail.
- The manufacturer reserves the right to revise any of the specification and design contain herein at any time without prior notification.

### DAIKIN AIRCONDITIONING INDIA PVT. LTD.

12th floor, Building No. 9, Tower A, DLF Cyber City, DLF Phase-III Gurgaon - 122002, Haryana (India) Tel: 0124-4555444 Fax: 0124-4555333

# MEMO

# MEMO

## MEMO

3P727715-6 J